



ENGLISH

# **JH(2)-SERIES DIESEL ENGINE**

OPERATION MANUAL

# **YANMAR**

## **MARINE DIESEL ENGINE**

### **MODELS : JH(2) SERIES**

### **OPERATION MANUAL**

Thank you purchasing a YANMAR Marine Diesel Engine.

#### **[INTRODUCTION]**

- This Operation Manual describes the operation, maintenance and inspection of the JH(2) series Yanmar marine diesel engine.
- Read this Operation Manual carefully before operate the engine to ensure that the engine is used correctly and that it stays in the best possible condition.
- Keep this Operation Manual in a convenient place for easy access.
- If this Operation Manual is lost or damaged, order a new one from your dealer or distributor.
- Make sure this manual is transferred to subsequent owners. This manual should be considered a permanent part of the engine and remain with it.
- Constant efforts are made to improve the quality and performance of Yanmar products, so some details included in this Operation Manual may differ slightly from your engine . If you have any questions about such differences, please contact your Yanmar Dealer or Distributor.
- For handling of the marine gear, refer to the Marine Gear Operation Manual.

Operation Manual (Marine Engine)	Models	<b>JH(2) Series</b>
	Code No.	<b>49961-201372</b>

## FOR YOUR IN SAFETY

---

### WARNING SYMBOLS

Most operation, maintenance and inspection problems arise due to users failure to comply with the rules and precautions for safe operation described in this operation manual.

Often, users don't understand or recognize the signs of approaching problems. Mis-handling may cause burns and other injuries and can result in death.

**Be sure to read and understand this operation manual carefully before operating the engine and observe all of the instructions and precautions described it.**

- These are the warning signs and their meanings which are used in this manual. Pay special attention to these parts.



**DANGER**-indicates an imminently hazardous situation which, if not dealt with, **WILL** result in death or serious injury.



**WARNING**-indicates a potentially hazardous situation which, if not dealt with, **COULD** result in death or serious injury.



**CAUTION**-indicates a potentially hazardous situation which, if not dealt with, **MAY** result in minor or moderate injury.

**This sign is also used to alert you against unsafe practice.**

- The descriptions captioned by **[NOTICE]** are for the particularly important items for handling. If you ignore them, the performance of your machine may be deteriorated leading to a problems.

## FOR YOUR IN SAFETY

---

### SAFETY PRECAUTIONS

(Observe these instructions for your own safety!)

#### ■ Precautions for Operation



##### Fresh Water Tank Filler Cap

- Never open the cap of the fresh water tank while the engine is still hot. Steam and hot water will spurt out and seriously burn you. Wait until the temperature of the fresh water tank has dropped, wrap a cloth around the filler cap and loosen the cap slowly. After inspection, refasten the cap firmly.



##### Battery

- Never smoke or permit sparks near the battery, because the battery may emit explosive hydrogen gas. Place the battery in a well ventilated place.



##### Fuel

- Use only diesel fuel. Never use other fuels, including gasoline, kerosene, etc., because they could cause a fire. The wrong fuel could also cause the fuel injection pump and valve to fail due to lack of proper lubrication. Be sure to check that you have selected diesel fuel before filling the fuel tank.



##### Fire Prevention

- Be sure to stop the engine and confirm that there are no open flames in the vicinity before supplying fuel.
- If you do spill fuel, wipe such spillage carefully and properly dispose of the wiping materials. Wash your hands thoroughly with soap and water.
- Never place oils or other flammables material in the engine room.
- Install a fire extinguisher near the engine room and familiarize yourself with its use.



##### Exhaust Gas

- Exhaust gas contains poisonous carbon monoxide and should not be inhaled. Be sure to install ventilation ports or ventilators in the engine room and ensure good ventilation during engine operation.



##### Moving parts

- Do not touch or let your clothing get caught in the moving parts of the engine, such as the front drive shaft, V-belt or propeller shaft, during engine operation. You will be injured.
- Never operate the engine without the covers on the moving parts.

## FOR YOUR IN SAFETY

---

### CAUTION



#### Burns

- The whole engine is hot during operation and immediately after stopping. The turbocharger, exhaust manifold, exhaust pipe, intercooler and high pressure fuel pipe are very hot. Never touch these parts with your body or clothing.

### WARNING

#### Alcohol

- Never operate the engine while you are under the influence of alcohol. Never operate the engine when you are ill or feel unwell.

## ■ Safety Precautions for Inspection

### DANGER



#### Battery Fluid

- Battery fluid is dilute sulfuric acid. It can blind you if it gets in your eyes, or burn your skin. Keep the fluid away from your body. Wash it off immediately, if you touch it, with a large quantity of fresh water and call your doctor for treatment.

### WARNING



#### Fire by Electric Short-Circuits

- Always turn off the battery switch before inspecting the electrical system. Failure to do so could cause short-circuiting and fires.

### WARNING



#### Stop Engine before Servicing,

- Stop the engine before you service it, Turn off the battery switch. If you must inspect while the engine is operating, never touch moving parts. Keep your body and clothing well clear of all moving parts.

### CAUTION



#### Scalds

- If extracting oil from the engine while it is still hot, don't let the oil splash you.
- Wait until the temperature has dropped before extracting cooling water from the engine. Don't let it splash you.

### WARNING

#### Forbidden Modifications

- Never release the limiting devices such as the engine speed limiter, fuel injection limiter etc.  
Modification will impair the safety and performance of the product and shorten its product life.  
Also note that any troubles arising from such modification are not be covered by our warranty.

## FOR YOUR IN SAFETY


### LOCATION FOR WARNING DEVICE LABELS

To insure safe operation, warning device labels have been attached. Their location is shown in the diagram below. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also, replace labels when parts are replaced, ordering them in the same way parts are ordered.

#### Warning device labels, Parts numbers

No.	Part Code No.
①	128296-07360
②	128296-07260
③	128296-07300

#### [ 3JH2 series ]



## FOR YOUR IN SAFETY


### LOCATION FOR WARNING DEVICE LABELS

To insure safe operation, warning device labels have been attached. Their location is shown in the diagram below. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also, replace labels when parts are replaced, ordering them in the same way parts are ordered.

#### Warning device labels, Parts numbers

No.	Part Code No.
①	128296-07360
②	128296-07260
③	128296-07300

#### [ 4JH2 series ]



## Explanation of Product

---

### USE, DRIVING SYSTEM, etc.

In the case of Model JH2 series engines with marine gear, connect the marine gear output shaft to the propeller shaft.

In order to obtain full performance from your engine, it is imperative that you check the size and structure of the hull and use a propeller of the appropriate size.

The engine must be installed correctly with safe cooling water and exhaust piping and electrical wiring. The PTO work should be easy to use for onboard equipment.

To handle the drive equipment, driven systems (including the propeller) and other onboard equipment, be sure to observe the instructions and cautions given in the operation manuals supplied by the shipyard and equipment manufactures.

The laws of some countries may require hull and engine inspections, depending on the use, size and cruising area of the boat.

The installation, fitting and surveying of this engine all require specialized knowledge and engineering skills. Consult Yanmar's local subsidiary in your region or your distributor or dealer.


#### WARNING

**Never modify this product or release the limit devices (which limit engine speed, fuel injection quantity, etc.). Modification will impair the safety and performance of the product and functions and shorten the product life.**

**Please note that any troubles arising from modification of the product will not be covered by our warranty.**

### DETAIL OF NAME PLATE

The nameplate shown below is attached on the engine's cylinder block. Check the engine's model number, output, rpm and serial number on the nameplate.






---

## CONTENTS


1. Name of parts .....	1
2. Specifications .....	5
3. Basic rules that must be kept for engine handling.....	17
4. Installation .....	20
5. Fuel oil, lube oil and cooling water .....	25
6. Breaking-in operation .....	28
7. Operating your engine .....	33
8. Periodic checks and maintenance .....	37
9. Long-term storage .....	44
10. Troubleshooting .....	45
11. Piping diagrams .....	A01
12. Wiring diagrams .....	A07

## 1. Name of parts

### 1-1. Name of parts



Exhaust Side of 3JH2-T(B)E




Operation side of 3JH2-T(B)E


## 1. Name of parts

---

### 1-2. Name of parts




**Exhaust Side of 4JH-HT(B)E**




**Operation side of 4JH-HT(B)E**

## 1. Name of parts

### 1-3. Name of parts



**Exhaust Side of 4JH-UT(B)E**




**Operation side of 4JH2-UT(B)E**

## 1. Name of parts

---


### Cylinder Number

- (1) The cylinder numbers of the 3 cylinder engine described in this manual are designated as follows.



The sequence of cylinder numbers is given as No. 1, No. 2, and No. 3 starting from the flywheel side.

- (2) The cylinder numbers of the 4 cylinder engine described in this manual are designated as follows.



The sequence of cylinder numbers is given as No.1, No.2, and No.3 starting from the flywheel side.

- (3) These cylinder numbers are consistently used for devices and parts connected with the cylinder head and valve moving mechanism. However, please note that items related to the fuel injection pump do not correspond to the numbering of the cylinders.

## 2. Specifications

### 2-1 3JH2E series

Engine Model			3JH2E	3JH2-TE
Type			Vertical 4-cycle water cooled diesel engine	
Combustion system			Direct injection	
Aspiration			Natural aspiration	Turbocharger
Number of cylinders			3	
Bore × stroke		mm (in.)	82 × 86 (3.23 × 3.39)	
Displacement		ℓ (cu.in.)	1.363 (83.14)	
One hour rating output (DIN6270B) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	28.5/3600 (38.7/3600)	35.0/3600 (47.6/3600)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.97 (99.10)	8.62 (122.57)
	Piston speed	m/sec. (ft./sec.)	10.3 (33.79)	10.3 (33.79)
Continuous rating output (DIN6270A) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	25.7/3400 (34.9/3400)	31.6/3400 (43.0/3400)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.8 (96.69)	8.35 (118.73)
	Piston speed	m/sec. (ft./sec.)	9.75 (32.0)	9.75 (32.0)
Compression ratio			18.1	18.0
Fire order			270°    270°    270° 1 — 3 — 2 — 1	
Fuel injection pump			Inline type, YPES-CL	
Fuel injection timing (b.T.D.C.)		degree	bTDC 10° ± 1°	bTDC 12° ± 1°
Fuel injection pressure		kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	200 ± 5 (2844 ± 71)	220 ± 5 (3128 ± 71)
Fuel injection nozzle			Hole type	
Direction of rotation	Crankshaft		Counter-clockwise viewed from stem	
	Propeller shaft		Clockwise viewed from stem	
Power take off			At flywheel side	
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump	
Lubrication system			Forced lubrication with trochoid pump	
Starting system	Starting motor		DC 12V, 1.4kW	
	AC generator		12V, 55A (12V, 80A: option)	
Turbo-charger	Type		—	RHB52 (IHI)
	Model		—	MY75
	Cooling system		—	Water cooling
Air cooler system	Type		—	
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—	

## 2. Specifications

Engine Model			3JH2E	3JH2-TE
Dry weight/ Dimensions (L×W×H) (with Marine gear)	KBW10-E	kg(lbs)/ mm(in.)	183 (400)/ 782.2×511.5×587.5	192 (422)/ 782.2×511.5×587.5
Lubricating oil capacity Effect/max.		ℓ (cu.in.)	2.1/4.9 (128.14/229.50) at engine installation angle 0°	
Cooling water capacity (Fresh water)	Fresh water tank	ℓ (cu.in.)	4.7 (286.80)	
	Sub tank	ℓ (cu.in.)	0.8 (48.82)	

### 2-1-1 Marine gear specifications

#### KBW10-E

Model		KBW10-E		
Type		Multi disc, wet, mechanical clutch		
Reduction ratio	Ahead	2.14	2.45	※ 2.83
	Astern	2.50		
Lubricating system		Splash		
Lube oil capacity		0.7ℓ		
Cooling system		Rodiant Cooling		

## 2. Specifications

### 2-2 3JH2BE series

Engine Model			3JH2BE	3JH2-TBE
Type			Vertical 4-cycle water cooled diesel engine	
Combustion system			Direct injection	
Aspiration			Natural aspiration	Turbocharger
Number of cylinders			3	
Bore × stroke		mm (in.)	82 × 86 (3.23 × 3.39)	
Displacement		ℓ (cu.in.)	1.363 (83.14)	
One hour rating output (DIN6270B) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	28.5/3600 (38.7/3600)	35.0/3600 (47.6/3600)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.97 (99.10)	8.62 (122.57)
	Piston speed	m/sec. (ft./sec.)	10.3 (33.79)	10.3 (33.79)
Continuous rating output (DIN6270A) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	25.7/3400 (34.9/3400)	31.6/3400 (43.0/3400)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.8 (96.69)	8.35 (118.73)
	Piston speed	m/sec. (ft./sec.)	9.75 (32.0)	9.75 (32.0)
Compression ratio			18.1	18.0
Fire order			270° 270° 270° 1 — 3 — 2 — 1	
Fuel injection pump			Inline type, YPES-CL	
Fuel injection timing (b.T.D.C.)		degree	bTDC 10° ± 1°	bTDC 12° ± 1°
Fuel injection pressure		kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	200 ± 5 (2844 ± 71)	
Fuel injection nozzle			Hole type	
Direction of rotation	Crankshaft		Counter-clockwise viewed from stem	
	Propeller shaft		Clockwise viewed from stem	
Power take off			At flywheel side	
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump	
Lubrication system			Forced lubrication with trochoid pump	
Starting system	Starting motor		DC 12V, 1.4kW	
	AC generator		12V, 55A (12V, 80A: option)	
Turbo-charger	Type		—	RHB52 (IHI)
	Model		—	MY75
	Cooling system		—	Water cooling
Air cooler system	Type		—	
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—	



## 2. Specifications

Engine Model			3JH2BE	3JH2-TBE
Dry weight/ Dimensions (L×W×H) (with Marine gear)	KM3A	kg(lbs)/ mm(in.)	173 (378)/ 753.3×511.5×587.5	187 (411)/ 753.3×511.5×587.5
Lubricating oil capacity Effect/max.		ℓ (cu.in.)	2.1/4.9 (128.14/229.50) at engine installation angle 0°	
Cooling water capacity (Fresh water)	Fresh water tank	ℓ (cu.in.)	4.7 (286.80)	
	Sub tank	ℓ (cu.in.)	0.8 (48.82)	

### 2-2-1 Marine gear specifications

#### KM3A

Model		KM3A		
Type		Constant mesh gear with servo cone clutch (Wet type)		
Reduction ratio	Ahead	2.33	2.66	※ 3.21
	Astern	3.04	3.04	※ 3.04
Lubricating system		Splash		
Lube oil capacity		0.45ℓ		
Cooling system		Note ※ : Available only for 3JH2E forced cooling with fan mounted on flywheel		

## 2. Specifications

### 2-3 4JHE series

Engine Model			4JHE	4JH-TE	4JH-HTE	4JH-DTE
Type			Vertical 4-cycle water cooled diesel engine			
Combustion system			Direct injection			
Aspiration			Natural aspiration	Turbocharger	Turbocharger with intercooler	
Number of cylinders			4			
Bore x stroke		mm (in.)	78 x 86 (3.07 x 3.39)			
Displacement		ℓ (cu.in.)	1.644 (100.33)			
One hour rating output (DIN6270B)	Output/crankshaft speed	HP/rpm (kW/rpm)	44/3600 (32.4/3600)	55/3600 (40.5/3600)	66/3600 (48.6/3600)	77/3600 (56.7/3600)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.69 (95.15)	8.36 (118.91)	10.0 (142.20)	11.7 (166.37)
	Piston speed	m/sec.(ft./sec.)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)
Continuous rating output (DIN6270A)	Output/crankshaft speed	HP/rpm (kW/rpm)	40/3500 (29.5/3500)	50/3500 (36.8/3500)	60/3500 (44.2/3500)	70/3500 (51.5/3500)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.26 (89.04)	7.82 (111.23)	9.39 (133.53)	11.0 (156.42)
	Piston speed	m/sec. (ft./sec.)	10.0 (32.81)	10.0 (32.81)	10.0 (32.81)	10.0 (32.81)
Compression ratio			17.8	16.2	15.9	15.9
Fire order			180° 180° 180° 180° 1 — 3 — 4 — 2 — 1			
Fuel injection pump			In-line type, YPES-CL			
Fuel injection timing (b.T.D.C.)		degree	bTDC 12° ±1°	bTDC 17° ±1°	bTDC 17° ±1°	bTDC 17° ±1°
Fuel injection pressure		kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	200 ± 5 (2844 ± 71)			
Fuel injection nozzle			Hole type			
Direction of rotation	Crankshaft		Counter-clockwise viewed from stern			
	Propeller shaft (Forward)		Clockwise viewed from stern			
Power take off			At flywheel side			
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump			
Lubrication system			Forced lubrication with trochoid pump			
Starting system	Starting motor		DC 12V, 1.8kW			
	AC generator		12V, 55A			
Turbo-charger	Type		—	RHB52 (IHI)	RHB52HW (IHI)	
	Model		—	MY29	MY31	MY34
	Cooling system		—	Air cooling	Water cooling	
Air cooler system	Type		—		Sea-water cooled Plate fin type	Sea-water cooled, Corrugated fin type
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—		0.76 (1178)	0.67 (1038)

## 2. Specifications

Engine Model			4JH-E	4JH-TE	4JH-HTE	4JH-DTE
Marine gear system	Model		KBW20		KBW21	KBW21
	Type		Mechanical, constant mesh gear with multiple friction disc clutch			
	Reduction ratio (Forward/Reverse)		2.17/3.06, 2,62/3,06, 3,28./3.06			2.17/3.06, 2.62/3.06
	Propeller speed DIN6270A rating (Forward/Reverse)		1615/1145, 1336/1145, 1068/1145			1615/1145, 1336/1145
	Lubricating oil capacity Effect/max	ℓ (cu.in.)	0.15/1.2 (9.15/73.22)			
	Weight	kg (lb.)	26 (57.33)		30 (66.15)	30 (66.15)
Dimensions	Overall length	mm (in.)	906.3 (35.68)		906.3 (35.68)	906.3 (35.68)
	Overall width	mm (in.)	561 (22.09)		561 (22.09)	561 (22.09)
	Overall height	mm (in.)	659 (25.94)		668 (26.30)	668 (26.30)
Engine weight with clutch (dry)		kg (lb.)	236 (520)	232 (511)	246 (542)	246 (542)
Lubricating oil capacity Effect/max.		ℓ (cu.in.)	4.2/8.0 (256.28/488.16)at engine installation angle 8°			
Cooling water capacity (Fresh water)	Fresh water tank	ℓ (cu.in.)	6.0 (366.12)			
	Sub tank	ℓ (cu.in.)	0.8 (48.82)			

## 2. Specifications

### 2-4 4JHBE series

Engine Model			4JH-BE	4JH-TBE	4JH-HTBE	4JH-DTBE
Type			Vertical 4-cycle water cooled diesel engine			
Combustion system			Direct injection			
Aspiration			Natural aspiration	Turbocharger	Turbocharger with intercooler	
Number of cylinders			4			
Bore x stroke		mm (in.)	78 x 86 (3.07 x 3.39)			
Displacement		l (cu.in.)	1.644 (100.33)			
One hour rating output (DIN6270B)	Output/crankshaft speed	HP/rpm (kW/rpm)	44/3600 (32.4/3600)	55/3600 (40.5/3600)	66/3600 (48.6/3600)	77/3600 (56.7/3600)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.69 (95.15)	8.36 (118.91)	10.0 (142.20)	11.7 (166.37)
	Piston speed	m/sec.(ft./sec.)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)
Continuous rating output (DIN6270A)	Output/crankshaft speed	HP/rpm (kW/rpm)	40/3500 (29.5/3500)	50/3500 (36.8/3500)	60/3500 (44.2/3500)	70/3500 (51.5/3500)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.26 (89.04)	7.82 (111.23)	9.39 (133.53)	11.0 (156.42)
	Piston speed	m/sec. (ft./sec.)	10.0 (32.81)	10.0 (32.81)	10.0 (32.81)	10.0 (32.81)
Compression ratio			17.8	16.2	15.9	15.9
Fire order			180° 180° 180° 180° 1 — 3 — 4 — 2 — 1			
Fuel injection pump			In-line type, YPES-CL			
Fuel injection timing (b.T.D.C.)		degree	bTDC 12° ±1°	bTDC 17° ± 1°	bTDC 17° ± 1°	bTDC 17° ±1°
Fuel injection pressure		kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	200 ± 5 (2844 ± 71)			
Fuel injection nozzle			Hole type			
Direction of rotation	Crankshaft		Counter-clockwise viewed from stern			
	Propeller shaft		Bi-rotation			
Power take off			At flywheel side			
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump			
Lubrication system			Forced lubrication with trochoid pump			
Starting system	Starting motor		DC 12V, 1.8kW			
	AC generator		12V, 55A			
Turbo-charger	Type		—	RHB52 (IHI)	RHB52HW (IHI)	
	Model		—	MY29	MY31	MY34
	Cooling system		—	Air cooling	Water cooling	
Air cooler system	Type		—		Sea-water cooled Plate fin type	Sea-water cooled, Corrugated fin type
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—		0.76 (1178)	0.67 (1038)

## 2. Specifications

Engine Model			4JH-BE	4JH-TBE	4JH-HTBE	4JH-DTBE
Marine gear system	Model		KM4A			
	Type		Mechanical, constant mesh gear with servo cone clutch (Down angle 7 degree)			
	Reduction ratio (Forward/Reverse)		2.14/2.14, 2.63/2.63, 3.30/3.30			
	Propeller speed DIN6270A rating (Forward/Reverse)		1637, 1332, 1062			
	Lubricating oil capacity Effect/max	ℓ (cu.in.)	0.2/1.3 (12.20/79.33)			
	Weight	kg (lb.)	28 (61.74)			
Dimensions	Overall length	mm (in.)	888.4 (34.98)	888.4 (34.98)	888.4 (34.98)	888.4 (34.98)
	Overall width	mm (in.)	565 (22.24)	565 (22.24)	565 (22.24)	565 (22.24)
	Overall height	mm (in.)	634.5 (24.98)	634.5 (24.98)	643.5 (25.33)	643.5 (25.33)
Engine weight with clutch (dry)		kg (lb.)	228 (503)	234 (516)	244 (538)	244 (538)
Lubricating oil capacity Effect/max.		ℓ (cu.in.)	2.5/7.0 (155.55/427.14) at engine installation angle 0°			
Cooling water capacity (Fresh water)	Fresh water tank	ℓ (cu.in.)	6.0 (366.12)			
	Sub tank	ℓ (cu.in.)	0.8 (48.82)			

## 2. Specifications

### 2-5 4JH2 series

Engine Model			4JH2E	4JH2-TE	4JH2-HTE	4JH2-DTE	4JH2-UTE	
Type			Vertical 4-cycle water cooled dissel engine					
Combustion system			Direct injection					
Aspiration			Natural aspiration	Turbocharger	Turbocharger with intercooler			
Number of cylinders			4					
Bore × stroke		mm (in.)	82 × 86 (3.23 × 3.39)					
Displacement		ℓ (cu.in.)	1.817 (110.87)					
One hour rating output (DIN6270B) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	37.5/3600 (51.0/3600)	46.5/3600 (63.2/3600)	56.0/3600 (76.1/3600)	65.0/3600 (88.4/3600)	74.0/3600 (100.6/3600)	
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.88 (97.83)	8.53 (121.29)	10.32 (146.75)	12.11 (172.2)	13.26 (188.55)	
	Piston speed	m/sec.(ft./sec.)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	
Continuous rating output (DIN6270A) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	33.8/3400 (46.0/3400)	41.9/3400 (57.0/3400)	50.7/3400 (68.9/3400)	58.8/3400 (79.9/3400)	66.9/3400 (91.0/3400)	
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.7 (95.3)	8.3 (118.05)	10.05 (142.94)	11.65 (165.7)	13.76 (195.67)	
	Piston speed	m/sec.(ft./sec.)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)	
Compression ratio			18.1	18.0	18.0	17.2	17.2	
Fire order			180° 180° 180° 180° 1 — 3 — 4 — 2 — 1					
Fuel injection pump			Inline type, YPES-CL					Distributor type VE-HDI
Fuel injection timing (b.T.D.C.)		degree	bTDC 10°±1°	bTDC 12°±1°	bTDC 14°±1°	bTDC 10°±1°	bTDC 12°±1°	
Fuel injection pressure		kg/cm <sup>2</sup> (lb/in. <sup>2</sup> )	220 ± 5 (3128 ± 71)					
Fuel injection nozzle			Hole type					
Direction of rotation	Crankshaft	Counter-clockwise viewed from stern						
	Propeller shaft	Clockwise viewed from stern (KBW21) Bi-rotation (KM 4A)						
Power take off			At flywheel side					
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump					
Lubrication system			Forced lubrication with trochoid pump					
Starting system	Starting motor	DC 12V, 1.4kW						
	AC generator	12V, 55A (12V, 80A: option)						
Turbo-charger	Type	—	RHB52 (IHI)	RHB52HW (IHI)				
	Model	—	MY67	MYBE	MYBD	MYAZ		
	Cooling system	—	Water cooling					
Air cooler system	Type	—			Sea-water cooled Plate fin type	Sea-water cooled, Corrugated fin type		
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—			0.76 (1178)	0.85 (1317)	

## 2. Specifications

Engine Model			4JH2E	4JH2-TE	4JH2-HTE	4JH2-DTE	4JH2-UTE
Dry weight/ Dimensions (L×W×H) (with Marine gear)	KBW20	kg(lbs)/ mm(in.)	226 (498)/ 898.3 × 561 × 634.5 (35.37 × 22 × 24.98)	232 (511)/ 898.3 × 561 × 634.5 (35.37 × 22 × 24.98)	—	—	—
	KBW21		—	—	246 (542)/ 898.3 × 561 × 643.5 (35.37 × 22 × 25.33)	246 (542)/ 898.3 × 561 × 643.5 (35.37 × 22 × 25.33)	246 (542)/ 898.3 × 561 × 643.5 (35.37 × 22 × 25.33)
Lubricating oil capacity Effect/max.		ℓ(cu. in.)	2.5/7.0 (155.55/427.14) at engine installation angle 0°				
Cooling water capacity (Fresh water)	Fresh water tank	ℓ(cu. in.)	6.0 (366.12)				
	Sub tank	ℓ(cu. in.)	0.8 (48.82)				

### 2-5-1 Marine gear specifications

#### (1) KM3P2

Model	KM3P2	
Type	Constant mesh gear with servo cone clutch (Wet type)	
Reduction ratio	Ahead	2.36
	Astern	2.61
Lubrication system	3.16	
Lube oil capacity	Splash	
Cooling system	0.35ℓ	
	Forced cooling with fan mounted on flywheel	

#### (2) KM4A

Model	KM4-A			
Type	Constant mesh gear with servo cone clutch (Wet type)			
Reduction ratio	Ahead	1.47	2.14	2.63
	Astern	1.47	2.14	2.63
Lubricating system	3.30			
Lube oil capacity	Splash			
Cooling system	1.3ℓ			
	Sea water cooling and forced cooling with fan mounted on flywheel			

## 2. Specifications

### 2-6 4JH2BE series

Engine Model			4JH2BE	4JH2-TBE	4JH2-HTBE	4JH2-DTBE	4JH2-UTBE
Type			Vertical 4-cycle water cooled dissel engine				
Combustion system			Direct injection				
Aspiration			Natural aspiration	Turbocharger	Turbocharger with intercooler		
Number of cylinders			4				
Bore × stroke		mm (in.)	82 × 86 (3.23 × 3.39)				
Displacement		ℓ (cu.in.)	1.817 (110.87)				
One hour rating output (DIN6270B) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	37.5/3600 (51.0/3600)	46.5/3600 (63.2/3600)	56.0/3600 (76.1/3600)	65.0/3600 (88.4/3600)	74.0/3600 (100.6/3600)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.88 (97.83)	8.53 (121.29)	10.32 (146.75)	12.11 (172.2)	13.26 (188.55)
	Piston speed	m/sec.(ft./sec.)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)	10.3 (33.79)
Continuous rating output (DIN6270A) flywheel output	Output/crankshaft speed	kW/rpm (HP/rpm)	33.8/3400 (46.0/3400)	41.9/3400 (57.0/3400)	50.7/3400 (68.9/3400)	58.8/3400 (79.9/3400)	66.9/3400 (91.0/3400)
	Brake mean effective pressure	kg/cm <sup>2</sup> (lb./in. <sup>2</sup> )	6.7 (95.3)	8.3 (118.05)	10.05 (142.94)	11.65 (165.7)	13.76 (195.67)
	Piston speed	m/sec.(ft./sec.)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)	9.75 (32.0)
Compression ratio			18.1	18.0	18.0	17.2	17.2
Fire order			180° 180° 180° 180° 1 — 3 — 4 — 2 — 1				
Fuel injection pump			Inline type, YPES-CL				Distributor type VE-HDI
Fuel injection timing (b.T.D.C.)		degree	bTDC 10°±1°	bTDC 12°±1°	bTDC 14°±1°	bTDC 10°±1°	bTDC 12°±1°
Fuel injection pressure		kg/cm <sup>2</sup> (lb/in. <sup>2</sup> )	200 ± 5 (2844 ± 71)				
Fuel injection nozzle			Hole type				
Direction of rotation	Crankshaft	Counter-clockwise viewed from stern					
	Propeller shaft	Clockwise viewed from stern (KBW21) Bi-rotation (KM 4A)					
Power take off			At flywheel side				
Cooling system			Constant high temperature fresh water cooling Fresh water: Centrifugal pump Sea-water: Rubber impeller pump				
Lubrication system			Forced lubrication with trochoid pump				
Starting system	Starting motor	DC 12V, 1.4kW					
	AC generator	12V, 55A (12V, 80A: option)					
Turbo-charger	Type	—	RHB52 (IHI)	RHB52HW (IHI)			
	Model	—	MY29	MY31	MY34		
	Cooling system	—	Water cooling				
Air cooler system	Type	—	Sea-water cooled Plate fin type		Sea-water cooled, Corrugated fin type		
	Radiation area	m <sup>3</sup> (in. <sup>3</sup> )	—		0.76 (1178)		0.67 (1038)



## 2. Specifications

Engine Model			4JH2BE	4JH2-TBE	4JH2-HTBE	4JH2-DTBE	4JH2-UTBE
Dry weight/ Dimensions (L×W×H) (with Marine gear)	KM3P2	kg(lbs)/ mm(in.)	217 (478)/ 864.3 × 561 × 634.5 (34 × 22 × 24.98)	—	—	—	—
	KM4A		228 (503)/ 888.4 × 565 × 634.5 (34.98 × 22.24 × 24.98)	234 (516)/ 888.4 × 565 × 634.5 (34.98 × 22.24 × 24.98)	244 (538)/ 888.4 × 565 × 634.5 (34.98 × 22.24 × 25.33)	244 (538)/ 888.4 × 565 × 634.5 (34.98 × 22.24 × 25.33)	244 (538)/ 888.4 × 565 × 634.5 (34.98 × 22.24 × 25.33)
Lubricating oil capacity Effect/max.		ℓ (cu. in.)	2.5/7.0 (155.55/427.14) at engine installation angle 0°				
Cooling water capacity (Fresh water)	Fresh water tank	ℓ (cu. in.)	6.0 (366.12)				
	Sub tank	ℓ (cu. in.)	0.8 (48.82)				

### 2-6-1 Marine gear specifications

#### KBW20, KBW 21

Model		KBW20		KBW21	
Type		Multi disc, wet, mechanical clutch			
Reduction ratio	Ahead	2.17	2.62	3.28	
	Astern	3.06			
Lubricating system		Splach			
Lube oil capacity		1.2 l			
Cooling system		Forced cooling with fan mounted on flywheel		Sea water cooling and forced cooling with fan mounted on flywheel	

### 3. Basic rules that must be kept for engine handling

---

### 3. Basic rules that must be kept for engine handling

Observe the following rules strictly to prolong the life of your engine.

No.	Items to be observed	Details and troubles which may arise if the instructions are neglected
1	Be sure to conduct run-in operation while your engine is still new.	Applications of heavy loads may shorten the life of the engine while it is still new.
2	Be sure to warm-up the engine.	Warm-up the engine at idling speed for about 5 minutes after starting to permeate the lube oil to all parts of the engine. If the engine is not warmed up, there will be excessive wear of the moving parts.
3	Use fuel with a cetane value of over 45.	Inferior quality fuel can cause starting failure, and the engine will emit bluish white exhaust.
4	Drain the fuel tank on a regular basis.	Before operating the engine, open the drain cock of the fuel tank and remove the precipitates from the fuel. 1st time . . . . . After 50 hrs. 2nd time and thereafter . . Every 300 hrs.
5	Use high quality lube oil.	Inferior quality lube oil will cause seizure of the piston and liner, excessive wear of moving parts and other troubles. The engine's durability will also be lowered.
6	Be sure to replace the lube oil and lube oil filter element on a regular basis.	Lube oil replacement: 1st time . . . . . After 50 hrs. 2nd time and thereafter . . Every 150 hrs. Element replacement: 1st time . . . . . After 50 hrs. 2nd time and thereafter . . Every 300 hrs.  <b>NOTE:</b> <ul style="list-style-type: none"><li>• Use of old lube oil will make engine parts wear fast and cause engine troubles.</li><li>• The oil pressure drops if the element is old or clogged with dust. This causes main bearing seizures and any dust in the bearing makes it wear faster.</li></ul>

### 3. Basic rules that must be kept for engine handling


No.	Items to be observed	Details and troubles which may arise if the instructions are neglected
7	Use clean tap water for cooling.	Hard water from wells causes scale deposits on the cooling water system. This lowers the cooling efficiency and raises the cooling water temperature too high, causing seizures of the piston and liner.
8	Be sure to add anti-rust agent to the cooling water.	Rust in the cooling water system not only accelerates the corrosion of the system but shortens the engine's life on account of the loss of cooling efficiency.
9	Use the anti-freeze in cold areas.	The anti-freeze prevents the cooling water from freezing and cracking the engine. If the cooling water freezes, it may crack the cylinder block, or cooling water pump. So, if anti-freeze is not used, be sure to drain the cooling water completely after operation.
10	Replace cooling water every year.	Contaminated cooling water has a lower cooling efficiency, so the cooling water temperature is liable to rise too high. This causes engine seizure.
11	Prior to operation, always check the cooling water level in the sub tank (Eng. w/sub tank only). In addition, check the cooling water level in the fresh water cooler (heat exchanger) at least once a week.	If the cooling water runs short, the cooling water temperature will rise too high. This causes engine seizure.
12	Check and adjust the drive belt tension of the alternator / cooling water pump.	An improper belt tension will either fail to transmit power satisfactorily or cause overheating. The belt will be damaged.
13	Do not make the starting motor run for more than 15 sec. continuously.	Continuous use of the starting motor for more than 15 sec. will damage the motor.

## 4. Installation


---

### 4-1. Procedures of Installation


1 Matching engine and boat




7 Installation of kingston valve and fuel tank




12 Installation of pipes, wires and exhaust pipe etc.




2 Make sure all engine parts and standard accessories are included.




8 Engine running test




13 Completion check




3 Finding the propeller shaft




14 Launching




4 Centering




9 Installation of engine and propeller shaft




5 Installation of engine bed using propeller shaft as a center




10 Adjustment of propeller shaft alignment



15 Adjustment of the propeller shaft alignment when boat is in the water



6 Installation of stern tube



11 Tightening the engine mounting bolts



16 Trial run



## 4. Installation

### 4-2. Notes for the installation

If you (boat owners) want to install the engine on your boat by yourself, please ask advice of your neighboring YANMAR distributors or dealers.


YANMAR has prepared "INSTALLATION MANUAL (PLEASURE BOAT USE)", so you are kindly requested to obtain this manual and work carefully to install the engine following the details in it.

For your reference, brief notes for your work during and after installation are mentioned as follows:

#### (1) Flexible engine mount

Be sure to use a flexible mount for the installation of every Yanmar engine model. Do not install the engine directly to the engine bed. The use of a flexible mount reduces vibration and noise by absorbing the vibrations at the couplings between the engine and the engine bed.

The dimensions for both front and rear-side use flexible mounts are identical. However, the rubber elastic modulus is different for port and starboard, so be sure to remember their indication numbers.




Indication No. of flexible mount		
	Port	starboard
3JH2(-T)E	150	100
4JH Series	200	150
4JH2 Series		


When fabricating the engine bed, be sure to leave a 20 mm or larger clearance between the engine bed, and the engine body and marine gear. In addition, be sure to leave 20 mm or larger clearance between the hull bottom, and the engine's oil pan and marine gear. (Measure these values with the height adjusting nuts of the engine's flexible mount brought down to the lower-most point, where they come into contact with the fixing nut of the stud bolts).

#### NOTE:

*The use of flexible mounts for too many hours makes the rubber lose its tension. This reduces the clearance and there will be interference between the engine and the hull bottom.*




## 4. Installation



### (2) Centering the engine

Before connecting the marine gear drive shaft with the propeller shaft, make sure that the flange surfaces of both parts are parallel to each other, and that their centers are aligned. Then adjust the centering of the engine.




	mm (in.)
Coupling disalignment A	0.1 - 0.3 (0.0039 - 0.0118)
Coupling face run-out B	0 - 0.2 (0 - 0.0079)

### (3) Exhaust system

It is necessary to arrange the piping to allow for inspection of the whole system. Also, a suitable arrangement is necessary to prevent sea-water from flowing back into the engine. A water-lock must be equipped to prevent water remaining in the hose from flowing back to the engine side when stopping the engine or immediately after starting.

The water-lock must be fixed at the lowest possible position, and the hose must be tilted downward as much as possible. It is also necessary to elevate the exhaust hose at the exhaust outlet to more than 350 mm (13.78 in.) above the loading draft line.


- 1) When the water outlet of the engine (A) is above the water line:



- 2) When the water outlet of the engine (A) is below the water line:


In this case attach a vacuum valve to the elbow of the cooling water pipe.

#### 4. Installation




##### (4) Sea water cooling system

The cooling water inlet consists of the kingston cock and the cooling water hose which connects the cock to the cooling water pump. When the boat is operated in dirty water, provide a sea-water strainer between the kingston cock and the cooling water pump. The sea-water pump will be damaged if foreign matter is allowed to get into it. Therefore, if the sea-water cock is not already equipped with a strainer, one should be attached between sea-water cock and the pump inlet.




##### NOTE:

*Locate the sea-water inlet well under the draft line. Even when the hull rolls, the inlet must remain under water.*



##### (5) Fuel system

- 1) The fuel tank should be installed as far as possible from the engine itself.
- 2) The height of the fuel tank must not be more than 1 meter below the fuel feed pump attached to the engine. If lower, an extra feed pump should be attached.



- 3) Since the fuel that overflows from the injection nozzle returns to the injection pump, connect the fuel return rubber hose between the fuel injection pump and fuel tank.

## 4. Installation

### (6) Electric system

- 1) Select battery of sufficient capacity.

Recommended battery capacity
12V—120AH


- 2) To wire the battery, connect (+) wire to the (+) terminal and the (–) wire to the (–) terminal.  
Do not confuse them.

#### NOTE:

*If connect the (+) wire to the (–) terminals, the I.C. regulator built in the AC alternator will be damaged.*

#### NOTE:

*Route the cable so that it doesn't come in contact with the sharp edges of the engine or heated areas.*



#### NOTE:

*Do not clamp the cables together with the fuel pipes. Keep them away from the fuel pipes as much as possible.*

- 3) Use wire of the correct size. Carry out correct wiring according to the wiring diagram for each model.

### (7) Remote control system

Only use the single lever remote control head.

#### NOTE:

*The dual lever remote control head cannot be used because of the large torque needed to operate the marine gear shift lever at engine high speeds (over 1800 rpm). This exceeds its capacity, and make the clutch inoperable.*


- 1) Adjustment of the remote control head

#### - Marine gearbox control side -

- (a) Equal distribution of the control lever stroke.

The stroke between neutral → forward (S2), and neutral → reverse (S1) must be equalized.

When either stroke is too short, clutch engagement becomes faulty.




- (b) Equalizing the travel distance of the control cable.

After ensuring the equal distribution of the stroke described in (a), connect the cable to the control head, and check that the cable shift travel is 35 mm (1.38 in.) when the control lever is moved from "Neutral" to "Forward" or to "Reverse".




## 4. Installation



### - Engine speed control side -


- (a) Confirmation of the control cable shift travel.

Connect the cable to the control head. Move the control lever to full stroke, and confirm that the cable shift travel is more than 35 mm (1.38 in.). Then connect the cable to the connection part of the governor lever. If the cable shift travel is below 35 mm (1.38 in.), max. engine speed may not be obtained. If the cable shift travel distance falls below 35 mm after connection, due to cable shift stress, use the cable adjusting screw to adjust it back to 35 mm.




### 2) Wiring precautions

- The minimum radius of cable bend should be 200 mm (7.9 in.).
- The outer cable should be bent, if required, at a point more than 100 mm (3.9 in.) from an outer cable clamp so that the clamp can be protected from strain.



- The exposed portion of the inner cable should be coated with a water resistant grease for rust prevention and also for smooth movement of the cable.




- The cable should be routed so that it does not come into contact with the heated area of the engine, sharp edges of metallic parts or moving parts.

- 4. Installation
  - 5. Fuel oil, lube oil and cooling water
- 

**NOTE:**

*Avoid clamping a wire harness or any other electrical wire to the cable.*



## 5. Fuel oil, lube oil and cooling water


### 5-1. Selection and handling of fuel oil

#### (1) Selection of fuel oil

Use the diesel fuel oil which is most suitable for the engine. (Use diesel fuel oil with a cetane value of over 45, less than 0.5% sulphur content and 0.1% water content.)

#### (2) Handling of fuel oil

- 1) Water and dust in the fuel oil cause engine failure.
- 2) Stand the drum for several days to precipitate the water and dust to the bottom. Use the fuel at the top.




### 5-2. Selection of lube oil, and refilling

#### (1) Selection

Nothing affects the performance and durability of your engine more than the lube oil you use. If inferior oil is used, or if your engine oil is not changed regularly, the risk of piston seizure, piston ring sticking, and accelerated wear of the cylinder liner, bearing and other moving components increases significantly. Your engine life may be seriously shortened.

Use Class CD (API Service Classification) oil.


## 5. Fuel oil, lube oil and colling water



### (2) Lube oil supply

- 1) Open the oil filler port and supply the oil to upper limit of dipstick.

<For 3JH2(-T)E series>




For Marine gear, use the following lube oil.


KM series	Mechanical cone clutch	Same lube oil as the engine
KBW series	Wet multi-disc clutch	ATF-A oil

#### NOTE:


Don't use the ATF-A oil for the mechanical cone clutch (KM series) due to protecting a slip or seizure.



<For 4JH series and 4JH2E, -TE, -HTE, -DTE>




<For 4JH2-UTE>



## 5. Fuel oil, lube oil and cooling water

---



### NOTE:

- *It takes a little while for the lube oil supplied from the filler port to fill the crankcase. Wait for about 3 minutes and then check the oil level.*
- *Make sure that your boat is sitting level when you check the oil. You cannot get the correct reading if it is tilted.*
- *The lube oil quantity in the crankcase falls during the breaking-in operation of a new engine because the oil spreads to the lube oil cooler and lube oil piping. Stop the engine once and wait for about 3 minutes before checking the oil level again.*

### 5-3. Cooling water (Fresh water cooled engine)

#### (1) Handling the cooling water

- 1) Be sure to use clean tap water (with anti-rust agent).

### NOTE:

*Hard water from wells or sea water causes rusting of the cooling water system. This lowers the cooling efficiency and may cause overheating.*

#### 2) Use of anti-freeze

Use anti-freeze, if the temperature is expected to fall below freezing point. The use of anti-freeze removes the need for daily draining of the cooling water. For safety, choose a temperature which is about 5°C lower than the lowest temperature of your area, and then decide the mixing ratio according to the instructions given by the anti-freeze maker.

### NOTE:

- *To use the anti-freeze, first drain the cooling water completely from the engine, pour in the anti-freeze to the specified amount, and fill the cooling water up to the mouth of cooling water filler port. Operate the engine for about 30 minutes to fully mix the anti-freeze with water, and then store the engine.*
  - *Anti-freeze is usually effective for one year. Refer to the instructions given by the anti-freeze maker.*
- 3) If no anti-freeze is used in winter, be sure to drain the cooling water from the engine after operation.

### NOTE:



*If the cooling water is left in the engine, it may freeze and cause cracking in cooling water pump and cylinder block.*

#### (2) Supply and check of cooling water

##### 1) Supplying water to the engine


Remove the cap on the heat exchanger top to supply cooling water. The cap can be removed by turning it about 120 degrees counterclockwise. Before breaking-in the engine, fill with clean tap water up to the mouth of the filler port. To tighten, slot the cap rear lobe into the filler port notch and press-turn the cap about 120 degrees clockwise.

## 6. Breaking-in operation



### 2) Checking and refilling with cooling water (Engine w/sub-tank)

Check the cooling water level against the "Full" and "Low" marks on the sub-tank. Remove the cap on top to refill. Fill to the "Full" mark.




## 6. Breaking-in operation

Operate your new engine in accordance with the following procedures.

### 6-1. Fuel oil

Supply fuel to the fuel tank.




In subsequent engine operations, observe the following rules:

#### (1) Draining

Even when only using fuel from the top of drum, there will still be some dust or water impurities. These must be drained off before they get into the inner parts of the engine.

#### (2) Draining the fuel tank

Be sure to install the precipitation trap and draining cock on the bottom of the fuel tank. Before operating the engine, open the cock and remove the sediments from the fuel.



#### NOTE:


To avoid fire hazards, be sure to stop the engine before refilling with fuel.

## 6. Breaking-in operation



### 6-2. Supply of lube oil

#### (1) Lube oil supply to the crankcase

Remove the filler port cap (yellow) to supply lube oil to the crankcase.



Insert the oil dipstick to the port and check that the oil comes up to the upper limit of the oil dipstick.



(2) While operating the priming knob on the fuel feed pump or the fuel filter.


### 6-3. Air bleeding

The fuel system runs from the fuel tank, through the fuel filter, fuel injection pump and high pressure piping, to the fuel injection nozzles. Fuel is not injected if air is admitted into the fuel system.

Bleed the air according to the following steps.


- (1) Pull out the engine warm up knob on the remote control head and place the control lever in the "HALF SPEED" position.

<For 3JH2(B)E series, 4JH(B)E series, 4JH2(B)E, -T(B)E, -HT(B)E, -DT(B)E>





## 6. Breaking-in operation

< For 4JH2-UT(B)E >




- 1) Bleed air by loosening the air bleeding screws of the fuel filter and fuel injection pump.


< For 3JH2(B)E series, 4JH(B)E series, 4JH2(B)E, -T(B)E, -HT(B)E, -DT(B)E >



< For 4JH2-UT(B)E >



- 2) Vent air in the fuel injection piping. Loosen the fuel injection pipe nipple on the fuel injection valve side. Repeat this procedure several times. After venting, tighten the fuel injection pipe nipple firmly.



## 6. Breaking-in operation

### 6-4. Lubricating engine parts

- (1) Lubricate the governor linkage.
- (2) Lubricate the shaft of the regulator handle mount.

### 6-5. Safety checks

Tidy the area around the engine. Remove any tools or other obstacles from the vicinity of flywheel, rotating parts and the top of the engine.


### 6-6. Spreading the lube oil

When using the engine after a period of non-use (for more than a month), it is necessary to circulate the lube oil as follows before starting regular engine operation.

- (1) Turn the battery switch "ON"
- (2) Shift the speed control lever to the "Neutral" position.
- (3) Open the kingston cock.
- (4) Yanmar offers two lube oil spreading methods. Conduct the following procedure depending on your engine stop method.

#### 1) Manual engine stop type

While pulling on the engine stop cable, insert the key into the starter switch, and turn it to "START". Run the engine for 3 - 5 seconds with the starting motor, and check for abnormal sounds.



#### 2) Electrical engine stop type

While pushing the engine stop button on the instrument panel, turn the key switch to "START". Follow the same procedure as with the manual stop type.

#### NOTE:

- Do not release the engine stop cable or stop button when handling the key.

### 6-7. Checking the pilot lamps

Check that the pilot lamps on the instrument panel are as shown below when the starter key is turned on:

Pilot lamps	Low L.O. pressure alarm lamp	Lit
	Charge lamp	Lit
	Cooling water temp. alarm lamp	Off

#### NOTE:

*All these signals will continue until the engine starts up or the key is turned off.*







## 6. Breaking-in operation

### INSTRUMENT PANELS

Available: ● Not available: —



		B2-type	C-type	D-type	E-type
1.	Tachometer	●	●	●	● (Bargraph) ● (Digital)
2.	Alarm buzzer	C.W. high temperature	●	●	●
		L.O. low pressure	●	●	●
		Fuel/water separator	—	—	●
3.	Alarm lamp unit	Battery not charging	●	●	●
		C.W. high temperature	●	●	●
		L.O. low pressure	●	●	●
		Fuel/water separator	—	—	●
4.	Tachometer illumination switch and alarm buzzer/lamps check switch		●	●	●
5.	Starting key switch		●	●	●
6.	Push button switch for eng. stop		●	●	●
7.	Hole for manual stop cable		●	—	—
8.	Operating hour meter		—	●	●
9.	L.O. pressure meter		—	●	●
10.	C.W. temperature meter		—	●	●
11.	Fuse		—	●	●
12.	Yanmar marine quartz clock		—	—	●
13.	Turbocharger boost meter		—	—	●

Unit: mm (in.)



			New C-type	New D-type
①	Switch unit	Key switch (Starter switch)	●	●
		Engine stop switch	●	●
		Alarm buzzer (C.W. temp., L.O. pressure)	●	●
		Alarm buzzer stop switch	●	●
		Illumination switch for tachometer	●	●
②	Alarm lamp unit	Battery not charging	●	●
		C.W. high temperature	●	●
		L.O. low pressure	●	●
		F.O. drain separator (Water level)	●	●
③	Tachometer unit	Tachometer with hour meter	●	●
④	Sub meter unit	L.O. pressure meter	●	●
		C.W. temperature meter	●	●
⑤	Clock unit	Quartz clock	—	●

Unit: mm (in.)



## 7. Operating your engine

### 7. Operating your engine

Before operating the engine, check that there are no obstacles around the engine, especially around the rotational parts.

#### ⚠ WARNING



- **To prevent exhaust gas poisoning, ensure good ventilation during operation. Install ventilation windows, ports or ventilators in the engine room.**



- **Never touch or allow your clothes to touch the moving parts of the engine during operation. If the front drive shaft, V-belt, propeller shaft, etc. catches your body or clothes, serious injury may result. Check that no tools, cloth, etc. are left on or around the engine.**

#### ⚠ CAUTION



**The engine is very hot during operation and immediately after stopping, especially the turbocharger, fresh water tank, exhaust pipe and high pressure fuel pipe. Avoid burns! Never touch or allow your clothes to touch these parts.**

#### 7-1. Starting

- (1) Turn the battery switch "ON"
- (2) Pull out the engine warm up knob and place the control lever in the "HALF SPEED" position.

#### NOTE:

*The knob for engine warm up can only be operated when the control lever is placed in the "Neutral" position.*

- (3) Open the kingston cock

- (4) Turn the starter switch key to "START". The engine should start.

Once the engine is started, release the key. The key automatically returns to "ON". (Do not turn off the battery switch and the key switch even after the engine is started). At "ON", the gauges on the instrument panel start operating.

#### NOTE:

##### Protecting the battery

*Do not run the starter motor for more than 15 seconds at a time. If the engine can't be started, wait for about 15 seconds before using the starter motor again.*

##### Engine re-starting

*Be sure to check that the flywheel has come to a standstill before turning the starter switch to "START".*

- *The starter motor or flywheel gear may be damaged if the starter switch is operated with the flywheel still moving.*
- *Engines with a safety relay in the circuit can't be re-started unless the starter switch has been turned off once the starter motor was run.*

##### Battery and key switch

*Do not turn off the battery switch and the key switch even after the engine start due to protecting alternator.*

*When the engine is operated at a low idling speed (below 1000 rpm) for a long time (over 2 hours), excessive carbon and fuel residue tends to accumulate due to incomplete combustion.*

*Carbon deposits on the injection holes of the fuel injection valve, exhaust valve, the turbine blades of the turbocharger, etc. cause a drop in engine output, knocking, and other troubles. To prevent these problems, be sure to blow off the carbon accumulations by full speed operation.*

*Operate the engine at over 2500 rpm for one minute in every two (2) hours of continuous low idling operation.*

## 7. Operating your engine

### Cold weather starting aid

- Turn the starter key counterclockwise to the "Heat" (or Glow) position and hold it in that position for about 15 seconds.
- Then, return the starter key to "START" to start the engine.

### Boost Compensator

In the case of cold weather, pull the cancel knob of boost compensator for easy starting (4JH(2)-TE, 4JH(2)-HTE, 4JH(2)-DTE). In normal weather, this procedure is not necessary.

- (5) When the engine is started, return the remote control handle to the "NEUTRAL" position.

### 7-2. Cautions after engine starting

Once the engine is started, observe the following instructions.

- (1) Warm-up the engine for more than 5 minutes.

#### NOTE:

- The lube oil will not spread all the way to the main bearing and other moving parts for some time after starting. To protect these parts from wear, the engine must be idled for about 5 minutes at low speed.
- For breaking-in, idle the engine at low speed for 15 - 20 minutes.


- (2) Raise the engine speed above 1000 rpm, and check that the low oil pressure alarm lamp and the charge lamp go out.

#### NOTE:

If the warning lamps still do not go out when the engine speed is raised above 1000 rpm, the engine is faulty. Stop the engine immediately and consult your nearest Yanmar dealer.

### 7-3. During engine operation

During engine operation, check the following items once or twice a day.



**⚠ DANGER**

**Do not open the filler cap during operation or immediately after stopping the engine. Hot steam and water will spout out. To remove the cap, wait until the engine has cooled down, wrap the cap with a cloth and loosen the cap slowly. After checking, fasten the filler cap firmly.**

#### (1) Exhaust color

Black exhaust indicates that the engine is under strain. Continued operation will shorten the lives of the intake and exhaust valves, piston rings, cylinder liner and fuel injection valves. Stop engine operation when black exhaust is emitted.

#### (2) Water and oil leakage

Check that there are no water, oil or gas leaks, loose bolts and abnormal noise, overheating and excessive vibrations. If any abnormality is found, contact your nearest Yanmar dealer.

#### (3) Avoid resonance range operation

#### NOTE:

Depending on the driven machine, engine vibrations will be excessive in a certain speed range due to resonance of the engine with the engine bed. Avoid engine operation in this range.

#### (4) Alarm lamps

- Low oil pressure alarm lamp ("OIL")

If the low oil pressure alarm lamp is lit while the engine is running at higher than low idle, check whether the lube oil is too low. If not, there is an abnormality in the lube oil circuit. Continued operation will cause engine seizure. Stop the engine soon, and consult your nearest Yanmar dealer.

## 7. Operating your engine

### NOTE:

*To check the lube oil level, stop the engine and wait for more than 3 minutes.*

- Charge alarm lamp ("CHG")

If the charge alarm lamp is lit while the engine is running at over 750 rpm, there is a fault in either the charging circuit or the V-belt (slippage or damage). Stop the engine and check. If the V-belt is OK, consult your nearest Yanmar dealer.

- Cooling water temp. alarm lamp ("WATER")

If the cooling water temp. alarm lamp is lit during load operation of the engine, the engine is overheated. Stop the engine immediately and check the cooling water level. If it is OK, consult your nearest Yanmar dealer.



### (5) Abnormal noise

If abnormal sounds are heard during engine operation, stop the engine soon and locate the cause. If it can't be located, consult your nearest Yanmar dealer.

## 7-4. Engine stopping

### (1) Idle the engine before stopping

- 1) To stop the engine, place the control lever to the "Neutral" position and operate the engine at low idling speed for about 5 minutes.
- 2) Cut the fuel by the following steps and stop the engine.



### NOTE:

*If the engine is stopped suddenly at a high temperature, the temperature of various parts will increase, and engine troubles may occur.*

- 3) Turn off the key switch.

### NOTE:

*When stopping the engine with the starter switch "ON", the lube oil pressure warning buzzer will sound. This is normal and does not indicate engine trouble.*

- (2) Be sure to close the kingston cock after stopping.

### NOTE:

*Emergency stop*


*If the engine can't be stopped with the engine stop cable (or stop button on the instrument panel) or the engine speed can't be lowered by the speed control lever, stop the engine as follows:*

*Loosen all the nuts on either the fuel injection pump side or the fuel injection nozzle side. This cuts off the fuel supply, and the engine stops. In such cases, consult your nearest*

## 7. Operating your engine

---

*Yanmar dealer to locate the cause and have them repair the engine.*



### (3) Draining the cooling water

#### **NOTE:**

*Cooling water freezes in cold temperatures. If anti-freeze is not used, be sure to drain the cooling water after stopping the engine. Also drain the cooling water completely before long storage. Otherwise, water in the cylinder may freeze and crack the cylinder.*

- *Before draining the cooling water, remove the pressure cap and the drain plugs of the engine, air cooler and heat exchanger. If the cap is not removed, draining will be hard and may be incomplete.*
  - *Do not remove the pressure cap when the engine is in hot condition.*
- (4) Wipe off dust and soil and clean the engine.
- (5) Turn off the battery switch (if your engine has one).
- (6) Pull out the starter key.

## 8. Periodic checks and maintenance

### 8. Periodic checks and maintenance

Periodic checks and maintenance are very important for keeping the engine in good condition and durable.

The chart below indicates which checks to make and when to make them.

System	Item	Before starting	After 50 hrs or one month	Every 150 hrs	Every 300 hrs	Every 600 hrs
Fuel system	Check the fuel level, and refill	○				
	Drain the fuel tank		○ (First)		○	
	Replace the fuel filter				○	
	Check the injection timing					○
	Check the injection spray condition					○
Lubricating system	Check the lube oil level	○				
	Marine gear	○				
	Replace the lube oil		○ (First)	○		
	Marine gear		○ (First)	○		
	Check the oil pressure warning lamp function	○				
	Replace the lube oil filter		○ (First)		○	
Cooling system	Seawater outlet	○ During operation				
	Check cooling water level	○				
	Adjust the tension of cooling water pump driving belt		○ (First)		○	
	Replace the impeller of the cooling water pump (sea water pump)					○ (Replace)
	Replace the cooling fresh water	Every year				
Air intake and exhaust system	Clean the element of the air intake silencer				○	
	Clean the exhaust/water mixing elbow				○	
	Clean the breather pipe				○	
	Check the exhaust gas condition	○ During operation				
	Clean the compressor for turbocharger			○		
Electrical system	Check the charge lamp function	○				
	Check the electrolyte level in the battery	○				
	Adjust the tension of the alternator driving belt		○ (First)		○	
	Check the wiring connectors				○	
Cylinder head, etc.	Check for leakage of water and oil	○ (After starting)				
	Retighten all major nuts and bolts					○
	Retighten the cylinder head bolts					○
	Adjust intake/exhaust valve clearance		○ (First)			○
Remote control system, etc.	Checking the remote control operation		○ (First)			○
	Adjust the propeller shaft alignment		○ (First)			○

## 8. Periodic checks and maintenance


### 8-1. Check and adjustment of fuel oil system

#### (1) Fuel level check and resupply

Resupply clean fuel to the fuel tank.

Interval	Daily (after each day's operation)
----------	------------------------------------


Fill the fuel tank at the end of each day's operation. This prevents water condensation in the fuel tank.



#### (2) Draining of the fuel tank

Open the drain cock at the bottom of the tank and drain off the sediment.

Interval	1st time ... after 50 hrs.
	2nd time and thereafter ....every 300 hrs. ✓




#### (3) Replacing the fuel filter

Remove the fuel filter and replace.


Interval	Every 300 hrs.
----------	----------------

<For 3JH2(B)E series, 4JH(B)E series, 4JH2(B)E, -T(B)E, -HT(B)E, -DT(B)E>




## 8. Periodic checks and maintenance

<For 4JH2-UTE>



### (4) Check of fuel injection timing


- 1) Remove the high pressure pipe from the fuel injection pump.
- 2) Pull the engine warm up knob out and place the control lever in the "half speed" position.
- 3) Crank the engine lightly to check the fuel injection timing.



- 4) Timing marks on the flywheel can be seen through the hole on the flywheel housing.

### NOTE:

All timing marks on the flywheel are indicated by number; for example, 1.4 or 2.3. These indicate top dead center of the pistons. Fuel injection timing marks are specified degree before this TDC mark.




- 5) Fuel should bubble out at the same time the timing mark on the flywheel and the indication mark on the flywheel housing line up.
- 6) To adjust the fuel injection timing, adjust the installation position at the long hole of the pump. When it falls to the cylinder block side, injection timing is slower; when it falls to the other side, injection timing is faster.

### Fuel injection timing

3JH2(B)E	FID (b.T.D.C.) : $10^{\circ} \pm 1^{\circ}$
3JH2-T(B)E	FID (b.T.D.C.) : $12^{\circ} \pm 1^{\circ}$
4JH(B)E	FID (b.T.D.C.) : $12^{\circ} \pm 1^{\circ}$
4JH -T(B)E -HT(B)E -DT(B)E	FID (b.T.D.C.) : $17^{\circ} \pm 1^{\circ}$
4JH2(B)E	FID (b.T.D.C.) : $10^{\circ} \pm 1^{\circ}$
4JH2-T(B)E	FID (b.T.D.C.) : $12^{\circ} \pm 1^{\circ}$
4JH2-HT(B)E	FID (b.T.D.C.) : $14^{\circ} \pm 1^{\circ}$
4JH2-DT(B)E	FID (b.T.D.C.) : $10^{\circ} \pm 1^{\circ}$
4JH2-UT(B)E	FID (b.T.D.C.) : $12^{\circ} \pm 1^{\circ}$



## 8. Periodic checks and maintenance



- 7) Check the fuel injection timing for all of the cylinders.

Interval	Every 600 hrs.
----------	----------------

### (5) Check the injection spray condition

Remove the fuel injection nozzle and check the injection spray condition. The spray should be cone-shaped.

#### NOTE:

*For disassembly, adjustment and inspection of the fuel injection pump and fuel injection valve, consult your nearest Yanmar dealer.*

Interval	Every 600 hrs.
----------	----------------

## 8-2. Lube oil system

### (1) Checking the oil level in the crank-case and the marine gear

Prior to the engine operation, pull out the oil dipstick and check that the oil level is between the upper and lower limits. If the oil is low, resupply.

Check interval	Daily (prior to operation)
----------------	----------------------------



#### CAUTION


**Beware of oil splashes if extracting the lube oil while it is hot.**

### (2) Replacement of lube oil

It is most effective to drain the lube oil while the engine is still warm. Replace the lube oil as follows:


Replace- ment interval	1st time . . . After 50 hrs.
	2nd time and thereafter . . . Every 150 hrs.

Drain out the lube oil by using oil evacuation pump.



### (3) Replacement of lube oil filter

Remove the filter and replace.




Replace- ment interval	1st time . . . After 50 hrs.
	2nd time and thereafter . . . Every 300 hrs.

## 8. Periodic checks and maintenance

### 8-3. Cooling water system

- (1) Make sure that water is coming out of the cooling water outlet pipe during operation.



- (2) Checking the cooling water level  
(Fresh water cooled engine)

#### [Engines w/sub-tank]

Daily checks of the cooling water level can be done by observing the sub-tank water level. If it is low, refill up to the "FULL" limit. Then press-fit the cover completely back on.

#### NOTE:

- Heat exchanger checks are not necessary for daily checks and refilling.
- Check the cooling water level when the engine is cold. Engine cooling water flows to the sub-tank when the engine is still hot and makes accurate checks impossible.

#### [Engines w/o sub-tank]

Remove the water filler cap on the heat exchanger and check the water level.

#### NOTE:

- Do not check the cooling water level while the engine is still hot. Steam or hot water may burst out if the water filler cap is removed soon after the engine is stopped.

- (3) Checking and adjustment of cooling water pump driving belt tension

Check the belt condition, and adjust the tension of the belt.

Adjustment standard.  
(For fresh water pump driving belt)  
10 mm (with 10kg thumb force)


Adjustment interval	1st time . . . After 50 hrs.
	2nd time and thereafter . . . Every 300 hrs.

- (4) Replace the impeller of the sea water cooling pump

Replace the impeller.

#### NOTE:

1. When inserting the impeller in the pump, make sure that the impeller lies in the proper direction.
2. Coat the inside of pump body impeller housing with grease.



### (5) Replacing fresh cooling water

The effectiveness of the anti-corrosive agent will be lowered if the cooling water becomes contaminated.


Replacement interval	Every year
----------------------	------------

## 8. Periodic checks and maintenance

### 8-4. Air intake system


#### (1) Cleaning the Intake silencer element

Wash the element inside the air intake silencer with neutral detergent.



Interval	Every 300 hrs.
----------	----------------

#### (2) Cleaning the turbocharger compressor



Consult your nearest Yanmar dealer for cleaning the turbocharger.

- 1) With the engine at maximum load, add 50cc of cleaning agent ("Blower Wash") for about 10 seconds using a feeder.
- 2) After 3 – 5 minutes, add 50cc of fresh water for about 10 seconds.

- 3) Use a vinyl container or the like for adding the cleaning agent and water. If a large amount of cleaning agent or fresh water is fed into the turbocharger all at once, trouble (damage to the compressor fan wheel, etc.) may occur. Pay careful attention to the amount fed and the time.

- 4) If there is no change in the turbocharging pressure or in the exhaust temperature, repeat the above cleaning procedures after 10 minutes. If there is still no change after repeating the cleaning procedures 3 – 4 times, the blower is heavily contaminated, or there is some other problem.

- 5) After cleaning, run the engine with load for at least 15 minutes to allow it to dry.

Interval	Every 150 hrs.
----------	----------------

\* If cleaned with fresh water, clean every 50 hrs.

### 8-5. Checking and maintenance of the battery.

#### WARNING



- Before inspecting the electrical system, be sure either to turn off the battery switch or to disconnect the (-) terminal of the earth cable. Otherwise, a short-circuit could cause a fire.



- Ensure good ventilation when charging the battery. The use of open flames is strictly prohibited. Hydrogen gas may also catch fire.


## 8. Periodic checks and maintenance




• Battery fluid is diluted sulfuric acid. It can blind or burn your eyes or skin. Wear goggles and gloves when handling battery fluid. Should the fluid be deposited on your skin, wash with a large quantity of fresh water and seek treatment from a doctor.

Proper battery maintenance is vital for dependable service.

- (1) Keep the battery clean by wiping it with a damp cloth. Keep all connections clean and tight. Remove any corrosion, and wash the terminals with a solution of baking soda and water.
- (2) Keep the battery fully charged, especially during cold weather. If the battery needs to be charged, charge it after disconnecting the battery cables from the battery.
- (3) Check the level of the electrolyte in each cell before starting. If low, fill to the bottom of the filler neck with distilled water.



- (4) To check the battery, use a battery hydrometer. Check the specific gravity of the electrolyte in each cell. Charge the battery if the reading is below 1.215.




### NOTE:

*When adding distilled water in freezing weather, run the engine at least 30 minutes to ensure thorough mixing.*

### 8-6. Checking and adjusting the V-belt tension

Too much V-belt tension accelerates V-belt wear, and too little V-belt tension leaves the pulley idle, overheats the engine, and no power is generated. Adjust the belt tension as follows:

- (1) Loosen the adjust bolt, and move the charging generator outwards to increase the tension, or move the charging generator inwards to decrease the tension.
- (2) Do not stain the belt with oil. The belt will idle if stained. Wipe off the oil soon.



Adjustment standard

10 mm (with 10 kg thumb force)

## 8. Periodic checks and maintenance

### 9. Long-term storage

---

Check interval	1st time . . . 50 hrs.
	2nd time and thereafter . . . Every 300 hrs.

#### 8-7. Checking the engine body

##### (1) Engine body

For checking and adjusting the following items, consult your nearest Yanmar dealer.

Check and adjustment item	Service interval
Retightening of bolts	Every 600 hrs.
Adjustment of intake/exhaust valve clearance	1st time . . . 50 hrs. 2nd time and thereafter . . . Every 600 hrs.

##### (2) Lubrication of the governor linkage

Lubricate the governor linkage to ensure smooth operation.

Lubrication interval	Daily (prior to operation)
----------------------	-------------------------------

#### 8-8. Checking the remote control operation

Make sure that the remote control system is working properly.

Check interval	1st time . . . 50 hrs.
	2nd time and thereafter . . . 600 hrs.

#### 8-9. Adjust the propeller shaft alignment

For checking and adjustment the propeller shaft alignment, contact your nearest Yanmar dealer or boatbuilder.

### 9. Long-term storage


- (1) Store your engine in a well ventilated place free from excessive humidity and dust.
- (2) Carefully follow these directions when storing your engine for a long period (3 months or more):
  - 1) Clean dust, oil, etc. off the surface of your engine.
  - 2) Change the lube oil.  
Change the lube oil filter.
  - 3) Run your engine once a month whenever possible. If not, follow these directions when beginning storage and every subsequent 6 months.
    - Remove fuel injection valves on the cylinder head. Supply each combustion chamber with about 2 cc of clean lube oil using an oilcan. Attach and tighten the injection valves.
    - Turn the stop lever to "STOP".
    - Turn the starter key. Crank up for about 10 seconds so that cylinder walls are uniformly oiled.
  - 4) Leave the cooling water with its anti-freeze, provided that the anti-freeze is not too old.
  - 5) Apply a thin coat of clean oil to the uncoated surface of the engine.
  - 6) Cover the exhaust silencer, air intake silencer, etc. with a PVC film to prevent humid air from entering your engine. Carefully protect the electric system from humidity in the same way.
  - 7) Remove the batteries from the engine and charge them fully before storage. Charge the batteries every month during storage, because they run down naturally (self-discharge).

## 10. Troubleshooting

### 10. Troubleshooting


The following description summarizes the probable cause of and the remedy for general failure by item.

Immediate countermeasures should be taken before a failure is inflamed if any symptom is detected.



## 10. Troubleshooting

---



# APPENDIX


---



11 Piping diagrams 11-1 4JH(2)-E	11 Schémas de tuyauterie 11-1 4JH(2)-E	11 Rohrleitungspläne 11-1 4JH(2)-E	11 Diagramas de tuberías 11-1 4JH(2)-E	11 Diagramma dei tubi e dei condotti 11-1 4JH(2)-E	11 kylvattenledningsdiagram 11-1 4JH(2)-E
English	Français	Deutsch	Español	Italiano	Svensk
1 Fuel oil filter (Cartridge type) 2 Lub. oil pump 3 Fresh water temperature switch 4 Hot water connection inlet 5 Cooling water pump (Sea water) 6 Hot water connection outlet 7 Thermostat 8 Cooling water pump (Sea water) 9 Detail of part (A) 10 Detail of part (B) 11 Detail of part (C) 12 Detail of part (D) 13 Main bearing 14 Lub. oil inlet filter 15 Fresh water cooler 16 Piston cooling oil jet 17 Mixing elbow 18 Lub. oil cooler 19 Oil pressure switch 20 Fuel injection nozzle 21 Fuel high pressure pipe 22 Pressure control valve 23 Lub. oil filter (Cartridge type) 24 Fuel injection pump 25 Fuel injection pump 26 Fuel oil inlet 27 Fuel oil inlet 28 Fuel oil inlet 29 From cylinder head 30 To cam shaft	1 Filtre de combustible (type à cartouche) 2 Pompe à huile de lubrification 3 Contacteur de température d'eau douce 4 Raccord d'admission d'eau chaude 5 Pompe à eau de refroidissement (eau douce) 6 Raccord de refroidement d'eau chaude 7 Thermostat 8 Pompe à eau de refroidissement (eau de mer) 9 Détail de (A) 10 Détail de (B) 11 Détail de (C) 12 Détail de (D) 13 Admission d'eau de mer 14 Palier de vilebrequin 15 Filtre d'admission d'huile de lubrification 16 Refroidisseur d'eau douce 17 Tubulure d'huile de refroidissement du piston 18 Coude de mélange 19 Refroidisseur d'huile de lubrification 20 Contacteur de pression d'huile 21 Injecteur de combustible 22 Tuyau haute pression de combustible 23 Soupape régulatrice de pression 24 Filtre d'huile de lubrification (Type à cartouche) 25 Pompe d'injection de combustible 26 Pompe d'alimentation de combustible 27 Admission de combustible 28 Débordement de combustible 29 De la culasse 30 Vers l'arbre à cames	1 Kraftstofffilter (Einsatzfilter) 2 Schmierölpumpe 3 Frischwasser-Temperaturschalter 4 Warmwasser-einlaß 5 Kühlwasserpumpe 6 Warmwasserauslaß 7 Thermostat 8 Kühlwasserpumpe (Salzwasser) 9 Detail (A) 10 Detail (B) 11 Detail (C) 12 Detail (D) 13 Salzwasserauslaß 14 Hauptlager 15 Schmieröleinlaßfilter 16 Frischwasserkühler 17 Kühleinspritzung für Pleiben 18 Mischkrümmer 19 Schmierölkühler 20 Öldruckschalter 21 Kraftstoff-Druckleitung 22 Druckregelventil 23 Schmierölfilter (Einsatzfilter) 24 Einspritzpumpe 25 Einspritzpumpe 26 Kraftstoffpumpe 27 Kraftstoff-einlaß 28 Kraftstoff-einlaß 29 Vom Zylinderkopf 30 Zur Nockenwelle	1 Filtro de combustible (Tipo cartucho) 2 Bomba de aceite de lubricación 3 Interruptor de la temperatura de agua dulce 4 Entrada de la conexión de agua caliente 5 Bomba de agua de enfriamiento (agua dulce) 6 Salida de la conexión de agua caliente 7 Termostato 8 Bomba del agua de enfriamiento (agua salada) 9 Detalle de la parte (A) 10 Detalle de la parte (B) 11 Detalle de la parte (C) 12 Detalle de la parte (D) 13 Entrada de agua salada 14 Cojinete principal 15 Filtro de entrada del aceite de lubricación 16 Entrad de agua dulce 17 Espesa de aceite enfriador del piston 18 Codo mezclador 19 Enfriador del aceite lubricante 20 Interruptor de la presión del aceite 21 Tubería de inyección de combustible 22 Tubo de alta presión de combustible 23 Válvula de control de la presión 24 Filtro del combustible (Tipo cartucho) 25 Bomba de inyección de combustible 26 Bomba de alimentación de combustible 27 Entrada de combustible 28 Derrame de combustible 29 Desde la cabeza del cilindro-V 30 Al cojinete del árbol	1 Filtro del carburante (tipo a cartuccia) 2 Pompa dell'olio lubrificante 3 Interruttore della temperatura dell'acqua dolce 4 Bocca di collegamento dell'acqua calda 5 Pompa dell'acqua di raffreddamento (acqua dolce) 6 Uscita del collegamento dell'acqua calda 7 Termostato 8 Popa dell'acqua di raffreddamento (acqua di mare) 9 Dettaglio della parte (A) 10 Dettaglio della parte (B) 11 Dettaglio della parte (C) 12 Dettaglio della parte (D) 13 Pressa dell'acqua di mare 14 Cuscinetto principale 15 Filtro d'ingresso dell'olio lubrificante 16 Refrigeratore dell'acqua dolce 17 Getto dell'olio di raffreddamento del pistone 18 Gomito di miscelaggio 19 Refrigeratore dell'olio lubrificante 20 Interruttore della pressione dell'olio 21 Ugello di iniezione del carburante 22 Tubo del carburante ad alta pressione 23 Valvola di controllo della pressione 24 Filtro dell'olio lubrificante (tipo a cartuccia) 25 Pompa di iniezione del carburante 26 Pompa di alimentazione del carburante 27 Ingresso del carburante 28 Scarico del troppo pieno del carburante 29 Dalla testata del cilindro a V 30 All'albero a camme	1 Bränslefilter (Patrontyp) 2 Smörjolepump 3 Vattentemperaturkopplare 4 Varmvatteninläg 5 Kylvattenpump 6 Varmvattenutläg 7 Termostat 8 Kylvattenpump (Havsvatten) 9 Detalj av del (A) 10 Detalj av del (B) 11 Detalj av del (C) 12 Detalj av del (D) 13 Havsvatteninläg 14 Huvudlager 15 Smörjoleinlägs filter 16 Färskvattenkylare 17 Kolvens kylingsmunstycke 18 Blandingskrör 19 Smörjolekylare 20 Öljetrycksomkopplare 21 Bränsleinjektionsmunstycke 22 Bränslets höjtrycksrör 23 Tryckkontrollventil 24 Smörjolefilter 25 Bränsleinjektionspump 26 Bränslemätarpump 27 Bränsleinläg 28 Övertöfödnäslse 29 Från topplocket 30 Till kamaxeln
Marks of piping:	Marquage des tuyauteries:	Kennzeichnungseinstellung:	Señalización de la tubería:	Contrassegni dei tubi:	Marken av kylvattenlednings:
MARKS NAME RH Rubber hose STS Carbon steel pipe C1201T Copper pipe — Screw joint — Flange joint — Eye joint — Insertion joint — Drill hole — Cooling fresh water piping — Cooling sea water piping — Lubo oil piping — Fuel oil piping	MARQUAGE DESIGNATION RH Flexible en caoutchouc STS Tuyau en acier au carbone C1201T Tuyau en cuivre — Joint à vis — Joint à bride — Joint à cosse — Joint par insertion — Trou percé — Tuyau d'eau douce de refroidissement — Tuyau d'eau de mer de refroidissement — Tuyau d'huile de lubrification — Tuyau de combustible	Kennzeichnung Bezeichnung RH Gummischlauch STS Stahlrohr C1201T Kupferrohr — Schraubverbindung — Flanschverbindung — Gabelverbindung — Steckverbindung — Bohrloch — Frischwasserkühlleitung — Salzwasserkühlleitung — Schmierölleitung — Kraftstoffleitung	SEÑALIZACION NOMBRE RH Manguera de corcho STS Tubo de acero al carbón C1201T Tubo de cobre — Junta de tornillo — Junta de reborde — Junta de ojo — Junta de inserción — Barreno — Tubería de agua dulce de enfriamiento — Tubería de agua salada de enfriamiento — Tubería de aceite de lubricación — Tubería de combustible	Contrassegni Nome RH Flessibile di gomma STS Tubo di acciaio al carbone C1201T Tubo di rame — Giunto a vite — Giunto a flangia — Giunto ad occhiello — Giunto ad inserzione — Foro a mandrino — Tubo acqua dolce di raffreddamento — Tubo acqua di mare di raffreddamento — Tubo dell'olio lubrificante — Tubo del carburante	MÄRKEN NAMN RH Gummislang STS Koldstör C1201T Kopparrör — Skruvled — Flänsled — Ögjeled — Isättningsled — Borrhål — Färskvattenör för kylning — Havsvattenör för kylning — Smörjoleör — Bränsleör
The diagram shows in the case of KM3P2/KBW20	Le schéma s'applique aux boîtes de vitesses KM3P2/KBW20	Der Plan zeigt dasSchiffgetriebe KM3P2/KBW20.	El diagrama es para los cajas de engranaje marino KM3P2/KBW20.	Il diagramma indica il caso dell'ingranaggio marino KM3P2/KBW20	Diagrammet visar kopplingen för KM3P2/KBW20.

## 11. Piping diagrams


### 11. Piping diagrams 11-1 4JH(2)-E



[illegible]

## 11. Piping diagrams


### 11-2 4JH(2)-TE





## 11. Piping diagrams

### 11-3 4JH(2)-HTE. 4JH(2)-DTE



12 Wiring diagrams 12-1 For B2-type instrument panel	English	Français	Deutsch	Español	Italiano	Svensk
12 Schémas de câblage 12-1 Tableau de bord de type B2	1 Batterie over 12V—120AH 2 Battery switch 3 Starting motor 4 Alternator 5 Water temp. switch 6 L.O. Pressure switch 7 Tachometer sensor 8 Extension wireharness 9 Tachometer 10 Buzzer 11 L.O. Pressure lamp 12 Water temp. lamp 13 Charge lamp 14 Key switch 15 STOP button 16 Illumination switch 17 Air heater 18 Relay 19 Engine STOP 20 Option 21 Fuel oil lamp	1 Batterie plus de 12V—120AH 2 Contacteur de batterie 3 Moteur de démarrage 4 Alternateur 5 Contacteur de température d'eau 6 Contacteur de pression d'huile de lubrification 7 Capteur de compic-tours 8 Faisceau de fils prolongateur 9 Compic-tours 10 Rofleur 11 Lampe de pression d'huile de lubrification 12 Lampe de température d'eau 13 Lampe de charge 14 Contacteur de démarrage 15 Bouton d'arrêt 16 Contacteur (Contrôle des lampes/éclairage) 17 Réchauffeur d'air 18 Relais 19 Arrêt du moteur 20 Option 21 Lampe de carburant	1 Batterie mehr als 12V, 120AH 2 Batterieschalter 3 Startermotor 4 Drehstromlichtmaschine 5 Wassertemperaturschalter 6 Schmierdruckschalter 7 Tachometersensor 8 Verlängerungskabelbaum 9 Tachometer 10 Summer 11 Schmierdruckschalter 12 Wassertemperaturlampe 13 Ladekontrolllampe 14 Schlüsselschalter 15 Stoppknopf 16 Beleuchtungsschalter 17 Luftvorwärmer 18 Relais 19 Motorschlopp 20 Option 21 Brennstofflampe	1 Descarga de batería 2 Interruptor de la batería 3 Motor en arranque 4 Alternador 5 Interruptor de la temperatura del agua 6 Interruptor de la presión del aceite de lubricación 7 Sensor del tacómetro 8 Cableado de extensión 9 Tacómetro 10 Zumbador 11 Lámpara indicadora de la presión del aceite de lubricación 12 Lámpara indicadora de la temperatura del agua. 13 Lámpara indicadora de la carga 14 Interruptor de la llave 15 Botón de "STOP" 16 Controlador de iluminación 17 Cámara de calefacción 18 Relé 19 Paro del motor 20 Opcional 21 Lámpara indicadora del combustible	1 Batteria oltre 12V—120AH 2 Interruttore della batteria 3 Motore di avviamento 4 Alternatore 5 Interruttore della temperatura dell'acqua 6 Interruttore della pressione dell'olio lubrificante 7 Sensore dei contagiri 8 Estensione dei cavi conduttori 9 Contagiri 10 Cicalino 11 Spia della pressione dell'olio lubrificante 12 Spia della temperatura dell'acqua 13 Spia della ricarica 14 Interruttore a chiave 15 Tasto di arresto (STOP) 16 Interruttore di illuminazione 17 Riscaldatore dell'aria 18 Relais 19 Arresto del motore 20 Opzione 21 Spia del carburante	1 Batteri över 12V—120 anperetiminär 2 Batteriomkopplare 3 Startmotor 4 Generator 5 Vattentemperaturkopplare 6 Smörjtrycks omkopplare 7 Takometergivare 8 Förlängningskabelbåt 9 Takometer 10 Sumner 11 Smörjtryckslampa 12 Vattentemperaturlampa 13 Laddninglampa 14 Nyckelomkopplare 15 Stoppknapp 16 Belysningsomkopplare 17 Luftvärmare 18 Relä 19 Stoppknapp för motor 20 Tillval 21 Bränslelampa
12 Diagramma elettrico 12-1 Pannello degli strumenti di tipo B-2						
12 Diagramas de cableado 12-1 Panel de mando tipo B2						
12 Kabelnåtsdiagram 12-1 För instrumentbråda av typ B2						

Color coding	
R	Red
W	White
B	Black
L	Blue
Y	Yellow
O	Orange
G	Green

Note: (A) (B) wireharness for additional, 80A alternator (optional) use.

Code des couleurs	
R	Rouge
W	Blanc
B	Noir
L	Bleu
Y	Jaune
O	Orange
G	Vert

Note: (A) (B) Faisceau de fils supplémentaires, utilisation d'un alternateur 80 A (en option)

Farbcode	
R	Rot
W	Weiß
B	Schwarz
L	Blau
Y	Gelb
O	Orange
G	Grün

Zur Bezeichnung: (A) (B) bezeichnet Kabelbündel zur Verwendung einer Zusatzleuchte 80-A-Lichtmaschine (Option).

Código de Colores	
R	Rojo
W	Blanco
B	Negro
L	Azul
Y	Amarillo
O	Naranja
G	Verde

Note: Cableado preformado (A) (B) para uso adicional X del alternador 80A (opcional).

Codice colori	
R	Rosso
W	Bianco
B	Nero
L	Blu
Y	Giallo
O	Arancione
G	Verde

Note: I fasci conduttori (A) e (B) sono per l'uso addizionale con un alternatore (opzionale) da 80A.


Färgkod	
R	Röd
W	Vit
B	Svart
L	Blå
Y	Gul
O	Orangefärgad
G	Grön

OBS: Kabelnär (A) (B) för övrig användning med 80A generator (tillval).

## 12. Wiring diagram

### 12. Wiring diagrams

#### 12-1 For B2-type instrument panel






12-2 C-type instrument panel	English	Français	Deutsch	Español	Italiano	Svensk
12-2 C-type instrument panel	<p>1 Lube oil pressure gauge 2 Tachometer 12V 3.4W 3 Cooling water thermometer 12V 4 Integral hour meter 5 Buzzer switch 6 Light switch 7 Starter switch 8 FUSE (3A) 9 Stop switch 10 C.W. temperature 11 Engine L.O. pressure 12 C.W. pressure 13 Charging 14 3P Coupler 15 Engine stop (option) 16 Solenoid 17 Relay 18 L.O. pressure gauge sensor 19 C.W. temp. gauge sensor 20 Tachometer sensor 21 C.W. temp. switch 22 L.O. pressure switch 23 Earth bolt (Flywheel housing) 24 Alternator 25 Starting motor 26 Battery switch 27 Battery 28 Air heater (option) 29 Extension wire/harness 30 6P connector M 31 4P connector M 32 4P connector F 33 To alarm buzzer</p>	<p>1 Jauge de pression d'huile de lubrification 2 Compteur-tours 3 Thermomètre d'eau de refroidissement 4 Compteur horaire intégré 5 Contacteur de rouleur 6 Contacteur d'éclairage 7 Contacteur de démarrage 8 Fusible (3 A) 9 Contacteur d'arrêt du moteur 10 Température d'eau de refroidissement 11 Pression d'huile de lubrification moteur 12 Pression d'huile de boîte de vitesses 13 Charge 14 Coupleur à 3 broches 15 Arrêt du moteur (Option) 16 Solénoïde 17 Relais 18 Capteur de jauge de pression d'huile de lubrification 19 Capteur de jauge de température d'eau de refroidissement 20 Capteur de compteur-tours 21 Contacteur de température d'eau de refroidissement 22 Contacteur de pression d'huile de lubrification 23 Boulon de masse (carter de volant moteur) 24 Alternateur 25 Moteur de démarreur 26 Contacteur de batterie 27 Batterie 28 Réchauffeur d'air (Option) 29 Faisceau de fils prolongateur 30 Connecteur M à 6 broches 31 Connecteur M à 4 broches 32 Connecteur F à 4 broches 33 Vers le rouleur d'alarme</p>	<p>1 Schmierölmanometer 2 Tachometer 3 Kühlwasserthermometer 4 Betriebsstundenzähler 5 Summenschalter 6 Lichtschalter 7 Startschalter 8 Sicherung (3 A) 9 Motorschalter 10 Kühlwassertemperatur 11 Motorwasserdruck 12 Getriebeastendruck 13 Laden 14 3-polige Kupplung 15 (bei Serie JH nicht vorhanden) 16 Motorschalt (Option) 17 Elektromagnet 18 Relais 19 Schmieröldrucksensor 20 Kühlwassertempersensor 21 Tachometersensor 22 Kühlwassertempersenschalter 23 Erdschraube 24 Erdschraubgehäuse 25 Drehstromlichtmaschine 26 Startermotor 27 Batterie 28 Luftvorwärmer (Option) 29 Verlängerungskabelbaum 30 6poliger Stecker M 31 4poliger Stecker M 32 4poliger Stecker F 33 Zum Alarmsummer</p>	<p>1 Indicador de la presión del aceite de lubricación 2 Tacómetro 3 Temperatura del agua de enfriamiento 4 Medidor de horas integral 5 Interruptor del zumbador 6 Interruptor de la lámpara 7 Interruptor de arranque 8 Fusible 9 Interruptor del paro del motor 10 Temperatura del agua de enfriamiento 11 Presión del aceite de lubricación del motor 12 Caja de engranaje de la presión de aceite 13 Cargador 14 Acoplador (No se usa para la serie JH) 15 Paro del motor 16 Solenoide 17 Relé 18 Sensor del indicador de la presión del aceite de lubricación 19 Sensor del indicador de la temperatura del agua de enfriamiento 20 Sensor del tacómetro 21 Interruptor de la temperatura del agua de enfriamiento 22 Interruptor de presión de aceite de lubricación 23 Perno de tierra (Caja del volante) 24 Alternador 25 Motor de arranque 26 Interruptor de la batería 27 Batería 28 Cámara de calefacción (Opcional) 29 Cableado de extensión 30 6P Conector M 31 4P Conector M 32 4P Conector F 33 Al zumbador de alarma</p>	<p>1 Indicatore della pressione dell'olio lubrificante 2 Contagiri 12 V, 3.4 W 3 Termometro dell'acqua di raffreddamento 12 V, 3.4 W 4 Indicatore integrale dell'ora 5 Interruttore del zumbatore 6 Interruttore di illuminazione 7 Interruttore di avviamento 8 Fusibile (3A) 9 Interruttore di arresto del motore 10 Temperatura dell'acqua di raffreddamento 11 Pressione dell'olio lubrificante del motore 12 Pressione olio scatola del cambio 13 Carica 14 Accoppiatore a 3 poli* (*Non usato per la serie JH) 15 Arresto del motore (opzione) 16 Solenoide 17 Relais 18 Sensore dell'indicatore di pressione dell'olio lubrificante 19 Sensore dell'indicatore di temperatura dell'acqua di raffreddamento 20 Sensore dei contagi 21 Interruttore della temperatura dell'acqua di raffreddamento 22 Interruttore della pressione dell'olio lubrificante 23 Bullone di messa a terra (alloggiamento del volante) 24 Alternatore 25 Motore di avviamento 26 Interruttore della batteria 27 Batteria 28 Riscaldatore dell'aria (opzionale) 29 Estensione del fascio conduttori 30 Connettore M a 6 poli 31 Connettore M a 4 poli 32 Connettore F a 4 poli 33 Al cicalino di allarme</p>	<p>1 Måtare för smörjoljetryck 2 Takometer 3 Kylvattenthermometer 4 Timrätare 5 Summenschaltare 6 Belysningskontrollare 7 Startkontrollare 8 Säkring (3A) 9 Motorspöppkontrollare 10 Kylvattentemperatur 11 Motorns smörjoljetryck 12 Växellådas oljetryck 13 Laddning 14 3P koppling (*används inte i serien JH) 15 Motorsöpp (tillval) 16 Solenoid 17 Relä 18 Givare för smörjoljetrycksmåttaren 19 Givare för kylvattentemperaturmätaren 20 Takometergivare 21 Öppningsbrytare för kylvattentemperatur 22 Öppningsbrytare för smörjoljetryck 23 Jordningsbult (svängulshuset) 24 Generator 25 Startmotor 26 Batterikontrollare 27 Batteri 28 Luftvärmare (tillval) 29 Förlängningskabelbunt 30 6P kontakt M 31 4P kontakt M 32 4P kontakt F 33 Till varningssummer</p>
12-2 Pannello degli strumenti di tipo C						
12-2 Fur instrumententafel Typ C						
12-2 Tableau de bord de type C						
12-2 Instrumentbräde av typ C						

12. Wiring diagram

12-2 C-type instrument panel



12-3 D-type instrument panel

English

- 1 Lube oil pressure gauge
- 2 Cooling water thermometer
- 3 Tachometer/light bulb
- 4 Integral hour meter
- 5 Buzzer stop switch
- 6 Light switch
- 7 Starter switch
- 8 Fuse (3A)
- 9 Eng. stop switch
- 10 Engine L.O. pressure lamp
- 11 Clutch L.O. pressure lamp
- 12 C.W. temperature lamp
- 13 Charge lamp 12V 1.7W
- 14 3P Coupler
- 15 Engine stop (option)
- 16 Solenoid
- 17 Relay
- 18 L.O. pressure gauge sensor
- 19 C.W. temp. gauge sensor
- 20 Tachometer sensor
- 21 C.W. temp. switch
- 22 L.O. pressure switch
- 23 Earth bolt (Flywheel housing)
- 24 Alternator
- 25 Starting motor
- 26 Battery switch
- 27 Battery
- 28 Air heater (option)
- 29 Extension wireharness
- 30 6P connector M
- 31 4P connector M
- 32 4P connector F
- 33 To alarm buzzer

Color coding	
R	Red
W	White
B	Black
L	Blue
Y	Yellow
O	Orange
G	Green

Note: (A) (B) wireharness for additional, 80A alternator (optional) use.

12-3 Tableau de bord de type D

Français

- 1 Jauge de pression d'huile de lubrification
- 2 Thermomètre d'eau de refroidissement
- 3 Lampe d'éclairage de compte-tours
- 4 Compteur horaire intégré
- 5 Contacteur d'arrêt de ronfleur
- 6 Contacteur d'éclairage
- 7 Contacteur de démarrage
- 8 Fusible (3A)
- 9 Contacteur d'arrêt du moteur
- 10 Lampe de pression d'huile de lubrification
- 11 Pression d'huile de boîte de vitesses
- 12 Lampe de température d'eau de refroidissement
- 13 Lampe de charge
- 14 \*Coupleur à 3 broches
- 15 Arrêt du moteur (Option)
- 16 Solénoïde
- 17 Relais
- 18 C.W. temp. gauge sensor
- 19 Capteur de jauge de pression d'huile de lubrification
- 20 Capteur de jauge de température d'eau de refroidissement
- 21 Capteur de compte-tours
- 22 Contacteur de température d'eau de refroidissement
- 23 Contacteur de pression d'huile de lubrification
- 24 Boulon de masse (carter de volant moteur)
- 25 Alternateur
- 26 Moteur de démarreur
- 27 Contacteur de batterie
- 28 Batterie
- 29 Réchauffeur d'air (Option)
- 30 Faisceau de fils prolongateur
- 31 Connecteur M à 6 broches
- 32 Connecteur M à 4 broches
- 33 Vers le ronfleur d'alarme

Code des couleurs	
R	Rouge
W	Blanc
B	Noir
L	Bleu
Y	Jaune
Or	Orange
G	Vert

Note: (A) (B) Faisceau de fils supplémentaires, utilisation d'un alternateur 80A (en option).

12-3 Für Instrumententafel Typ D

Deutsch

- 1 Schmierölmanometer
- 2 Kühlwasserthermometer
- 3 Tachometer/Leuchtmittel
- 4 Betriebsstundenzähler
- 5 Summierstoppschalter
- 6 Lichtschalter
- 7 Motorschalter
- 8 Sicherung (3A)
- 9 Motorschleppschalter
- 10 Motorschmierdrucklampe
- 11 Getriebekastenöldruck
- 12 Kühlwassertemperaturlampe
- 13 Ladekontrolllampe
- 14 3 poliger Kuppler
- 15 \*bei Serie JH nicht vorhanden
- 16 Motorschlepp (Option)
- 17 Relais
- 18 Schmierdrucksensor
- 19 Kühlmassensensor
- 20 Tachometersensor
- 21 Kühlwassertempersensor
- 22 Schmierdruckschalter
- 23 Drehmomentschraube (Schwungradgehäuse)
- 24 Drehstromlichtmaschine
- 25 Startermotor
- 26 Batterieschalter
- 27 Batterie
- 28 Luftvorwärmer (Option)
- 29 Verlängerungskabelbaum
- 30 Spigoliger Stecker M
- 31 4poliger Stecker M
- 32 4poliger Stecker F
- 33 Zum Alarmsummer

Farbcode	
R	Rot
W	Weiß
B	Schwarz
L	Blau
Y	Gelb
O	Orange
G	Grün

Zur Bezeichnung: (A) (B) bezeichnen Kabelbaum bei Verwendung einer zusätzlichen 80-A-Lichtmaschine (Option).

12-3 Panel de mando tipo D

Español

- 1 Indicador de presión del aceite de lubricación
- 2 Tacómetro del agua de enfriamiento
- 3 Bulbo de luz del tacómetro
- 4 Medidor de horas integral
- 5 Interruptor del apagado del zumbador
- 6 Interruptor de lámparas
- 7 Interruptor de arranque
- 8 Fusible (3A)
- 9 Interruptor de paro del motor
- 10 Lámpara indicadora de la presión del aceite de lubricación del motor
- 11 Caja de engranaje de la presión de aceite
- 12 Lámpara indicadora de la temperatura del agua de enfriamiento
- 13 Lámpara indicadora de la carga
- 14 Acoplador
- 15 (No se usa para la serie JH)
- 16 Solenoide
- 17 Relé
- 18 Sensor del indicador de la presión del aceite de lubricación
- 19 Sensor del indicador de la temperatura del agua de enfriamiento
- 20 Sensor del tacómetro
- 21 Interruptor de la temperatura del agua de enfriamiento
- 22 Interruptor de la presión de aceite del lubricación
- 23 Perno de tierra
- 24 Alternador
- 25 Motor de volante
- 26 Motor de arranque
- 27 Batería
- 28 Cámara de calefacción (Optional)
- 29 Cableado de extensión
- 30 6P Conector M
- 31 4P Conector M
- 32 4P Conector F
- 33 Al zumbador de alarma

Código de Colores	
R	Rojo
W	Blanco
B	Negro
L	Azul
Y	Amarillo
O	Naranja
G	Verde

Note: Cableado preferido (A) (B) para uso de XX adicional del alternador 80A (opcional)!

12-3 Pannelo degli strumenti di tipo D

Italiano

- 1 Misuratore della pressione olio lubrificante
- 2 Termometro dell'acqua di raffreddamento
- 3 Bulbo della luce del contagin (12 V, 3.4 W)
- 4 Misuratore ore di integrazione
- 5 Interruttore di arresto del cicalino
- 6 Interruttore dell'illuminazione
- 7 Interruttore di avviamento
- 8 Fusibile (3A)
- 9 Interruttore di arresto del motore
- 10 Spia della pressione dell'olio di lubrificazione del motore
- 11 Pressione olio scatola del cambio
- 12 Spia temperatura acqua di raffreddamento
- 13 Spia della ricarica (12 V, 1.7 W)
- 14 Connettore a 3 poli\* (\*Non usato per la serie JH)
- 15 Arresto del motore (opzione)
- 16 Solenoide
- 17 Relais
- 18 Sensore dell'indicatore di pressione dell'olio lubrificante
- 19 Sensore dell'indicatore di temperatura dell'acqua di raffreddamento
- 20 Sensore del contagin
- 21 Interruttore della temperatura dell'acqua di raffreddamento
- 22 Interruttore della pressione dell'olio lubrificante
- 23 Bulone di messa a terra (alloggiamento del volante)
- 24 Alternatore
- 25 Motore di avviamento
- 26 Interruttore della batteria
- 27 Batteria
- 28 Riscaldatore dell'aria (opzionale)
- 29 Estensione del fascio condution
- 30 Connettore M a 6 poli
- 31 Connettore M a 4 poli
- 32 Connettore F a 4 poli
- 33 Al cicalino di allarme

Codice colori	
R	Rosso
W	Bianco
B	Nero
L	Blu
Y	Giallo
Or	Arancione
G	Verde

Nota: I fasci conduttori (A) e (B) sono per l'uso addizionale con un alternatore (opzionale) da 80A.

12-3 Instrumentbräde av typ D

Svensk


- 1 Mätare för smörjoljetryck
- 2 Kylvattentermometer
- 3 Glödlampa för taktometer
- 4 Timmätare
- 5 Summers stoppskopplare
- 6 Belysningskopplare
- 7 Startomkopplare
- 8 Säkring
- 9 Motorstoppskopplare
- 10 Lampa för motorns smörjoljetryck
- 11 Växellådas oljetryck
- 12 Lampa för kylvattentemperatur
- 13 Laddningslampa
- 14 \*3P koppling (\*används inte i serien JH)
- 15 Motorstopp (tillval)
- 16 Solenoid
- 17 Relä
- 18 Givare för smörjoljetrycksmätaren
- 19 Givare för kylvattentemperaturmätaren
- 20 Takometergivare
- 21 Omkopplare för kylvattentemperatur
- 22 Omkopplare för smörjoljetryck
- 23 Jordningsbult (Svänggljushuset)
- 24 Generator
- 25 Startmotor
- 26 Batteriomkopplare
- 27 Batteri
- 28 Luftvärmare (tillval)
- 29 Fördängningskabelbåt
- 30 6P kontakt M
- 31 4P kontakt M
- 32 4P kontakt F
- 33 Till varningssummer

Färgkod	
R	Röd
W	Vit
B	Svart
L	Blå
Y	Gul
Or	Orangefärgad
G	Grön

OBS: Kabelbåt (A) (B) för övrig användning med 80A generator (tillval).

## 12. Wiring diagram


### 12-3 D-type instrument panel



English	Français	Deutsch	Español	Italiano	Svensk
12-4 E-type instrument panel	12-4 Tableau de bord de type E Série 4JH2 uniquement	12-4 Für Instrumententafel Typ E Nur Serie 4JH2	12-4 Panel de mando tipo E Solo para la serie 4JH2(2)	12-4 Pannello degli strumenti di tipo E Solo per la serie 4JH2.	12-4 Instrumentbräde av typ E Endast serien 4JH2
1 Detail of coupler (viewed from A-A)	1 Détail du coupleur (Vue A-A)	1 Detail-Kupplung (Ansicht A-A)	1 Detalle del acoplador (Vista desde A-A)	1 Dettaglio del connettore (visto dalla sezione A-A)	1 Detalj av koppling (Sjdd från A-A)
2 Buzzer tilt switch	2 Contacteur d'arrêt de roufleur	2 Summer-Kippschalter	2 Interruptor del zumbador	2 Interruttore di interruzione del cicalino	2 Summers vippskopplare
3 Illumination lamp	3 Contacteur d'éclairage	3 Beleuchtungsschalter	3 Interruptor de encendido de iluminación	3 Interruttore di illuminazione	3 Belysningskopplare
4 Illumination lamp	4 Lampe d'éclairage	4 Beleuchtungslampe	4 Lámpara de iluminación	4 Lampadina di illuminazione	4 Belysningslampa
5 LCD drive circuit	5 Circuit d'alimentation LCD	5 LCD-Treiber	5 Circuito impulsor de LCD	5 Circuito diretto LCD	5 Drivkrets med flytande kristaller
6 Hour meter	6 Compteur horaire	6 Betriebsstundenzähler	6 Medidor de horas	6 Misuratore dell'ora	6 Timmätare
7 Alarm	7 ALARME	7 Alarm	7 Alarma	7 Allarme	7 Alarm
8 Charge	8 CHARGE	8 Laden	8 Carga	8 Carica	8 Laddning
9 Fuse (3A)	9 Fusible	9 Sicherung	9 Fusible	9 Fusibile	9 Säkring
10 Starter switch	10 Contacteur de démarrage	10 Startschalter	10 Interruptor de arranque	10 Interruttore di avviamento	10 Startomkopplare
11 Instrument panel (No. 1 station)	11 Tableau de bord (station No. 1)	11 Instrumententafel (Nr. 1)	11 Panel de mando "Estación No. 1"	11 Pannello degli strumenti (Stazione No. 1)	11 Instrumentbräde (station No. 1)
12 Buzzer	12 Roufleur	12 Summer	12 Zumbador	12 Cicalino	12 Summer
13 Sea water switch	13 Contacteur d'eau de mer	13 Salzwasserschalter	13 Interruptor del agua salada	13 Interruttore dell'acqua di mare	13 Havsvattenomkopplare
14 Engine stop (option)	14 Arrêt du moteur (Option)	14 Motorstopp (Option)	14 Paro del motor (Opcional)	14 Arresto del motore (opzione)	14 Motorstopp (tillval)
15 Solenoid	15 Solénoïde	15 Elektromagnet	15 Solenoide	15 Solenoide	15 Solenoid
16 Relay	16 Relais	16 Relais	16 Relé	16 Relais	16 Relä
17 Tacho sensor	17 Capteur de compte-tours	17 Tachometersensor	17 Sensor del tacómetro	17 Sensore dei contagiri	17 Takometergivare
18 C.W. temp. sender	18 Émetteur de température d'eau de refroidissement	18 Kühlwassertempersensor	18 Transmisor de temperatura del agua de enfriamiento	18 Sensore dell'indicatore di temperatura dell'acqua di raffreddamento	18 Givare för kylvattentemperaturmätaren
19 Eng. oil pressure sender	19 Émetteur de pression d'huile moteur	19 Motoröldrucksensor	19 Transmisor de la presión del aceite del motor	19 Sensore dell'indicatore di pressione dell'olio lubrificante	19 Givare för smörjoljetrycksmätaren
20 C.W. temp. switch	20 Contacteur de température d'eau de refroidissement	20 Kühlwassertemperswitch	20 Interruptor de la temperatura del agua de enfriamiento	20 Interruttore della temperatura dell'acqua di raffreddamento	20 Omkopplare för kylvattentemperatur
21 Eng. oil pressure switch	21 Contacteur de pression d'huile moteur	21 Motoröldruckschalter	21 Interruptor de la presión del aceite del motor	21 Interruttore della pressione dell'olio lubrificante	21 Omkopplare för smörjoljetryck
22 Alternator	22 Alternateur	22 Drehstromlichtmaschine	22 Alternador	22 Alternatore	22 Generator
23 Earth bolt	23 Boulon de masse	23 Erdungsschraube	23 Perno de tierra	23 Bulone di messa a terra	23 Jordingsbult
24 Starter	24 Démarrateur	24 Batterieschalter	24 Motor de arranque	24 Motore di avviamento B	24 Startare
25 Battery switch	25 Contacteur de batterie	25 Luftvorwärmer (Option)	25 Interruptor de la batería	25 Interruttore della batteria	25 Batteriomkopplare
26 Battery 12 V-120AH	26 Batterie	26 Verlängerungskabel	26 Cámara de calefacción (Opcional)	26 Riscaldatore dell'aria (opzionale)	26 Batteri
27 Air heater (option)	27 Réchauffeur d'air (Option)	27 Mit 6m oder längerem Verlängerungskabel	27 Cordon de extension	27 Codice di estensione	27 Luftvärmare (tillval)
28 Extension wireharness is 6m or longer	28 Code prolongement	28 Starterrelais	28 Quando il cordón de extensión es de 6 m o más	28 Quando il cavo collegamento è di 6 o più metri	28 Förlängningskabel
29 When extension wireharness is 6m or longer	29 Lorsque le code prolongement est 6m ou plus	29 Starter	29 Relais de arranque	29 Relais di avviamento	29 När förlängningskabeln är 6 meter eller längre
30 Starter relay	30 Relais de démarrage	31 Starter	31 Arranque	31 Avviamento	30 Startrelä
31 Starter	31 Démarrateur				31 Startare
Color coding	Code des couleurs	Farbcode	Codigos de colores	Codice colori	Flagkod
R Red	R Rouge	R Rot	R Rojo	R Rosso	R Röd
W White	W Blanc	W Weiß	W Blanco	W Bianco	W Vit
B Black	Blk Noir	Blk Schwarz	B Negro	Blk Nero	B Svart
L Blue	L Bleu	L Blau	L Azul	L Blu	L Blå
Y Yellow	Y Jaune	Y Gelb	Y Amarillo	Y Giallo	Y Gul
O Orange	Or Orange	Or Orange	O Naranja	Or Arancione	Or Orange/flaggad
G Green	G Vert	G Grün	G Verde	G Verde	G Grön
Note: (A)+(B)+(C) < 2.8 m → 40 mm² (cross sectional area)	Note: (A)+(B)+(C) < 2.8 m → 40 mm² (surface de la section)	Zur Beachtung: (A)+(B)+(C) < 2.8 m → 40 mm² (Querschnitt)	Note: (A)+(B)+(C) < 2.8 m → 40 mm² (Area sectional transversal)	Note: (A)+(B)+(C) < 2.8 m → 40 mm² (area della sezione)	OBS: (A)+(B)+(C) < 2.8 m → 40 mm² (tvärsnittsarea)

## 12. Wiring diagram

### 12-4 E-type instrument panel



12-5 New C-type instrument panel	12-5 Tableau de bord de Nouveau type C	12-5 Für Instrumententafel Neuer Typ C	12-5 Panel de mando Nuevo tipo C	12-5 Pannello degli strumenti di tipo C nuovo	12-5 Instrumentbräde av Ny typ C
English	Français	Deutsch	Español	Italiano	Svensk
1 Tacho with Hour meter 2 Buzzer 3 Buzzer stop 4 Illumination 5 FUSE 6 Stop switch 7 Starter switch 8 Relay 9 Eng. oil pressure 10 C.W. Temp 11 Fuel Drive 12 Exhaust 13 Fuel amp. 14 Instrument panel 15 Charge 16 (No2 station) (Option) 17 Instrument panel 18 Wire harness 19 Option 20 Eng. stop solenoid 21 Air heater 22 Option for JH2 23 Procured by customer 24 (Cross sectional area) 25 Battery switch 26 Starter relay 27 Battery 28 Starter 29 C.W. Temp. switch 30 Eng. oil pressure switch 31 Alternator 32 Earth bolt 33 Tacho sensor 34 (C.W. Temp. sender) 35 (Fuel filler switch) 36 (Fuel filler sender) 37 Eng. oil pressure sender 38 Details of coupler 39 (View B-B) 40 Details of coupler 41 (View A-A) 42 Details of coupler 43 (View C-C)	1 Tachymètre avec compteur horaire 2 Vibreur sonore 3 Dispositif d'arrêt du vibreur sonore 4 Dispositif d'éclairage 5 Fusible 6 Commutateur d'arrêt 7 Commutateur du démarreur 8 Relais 9 Pression de l'huile du moteur 10 Temp. de l'eau de refroidiss. 11 Bar. de marche 12 Échappement 13 Fus de combustion 14 Tableau de bord 15 Charge 16 (Poste No 2) (En option) 17 Tableau de bord 18 Harnais de câbles 19 Harnais de câbles pour le tableau No 2 20 En option 21 Solénoïde d'arrêt du moteur 22 Réchauffeur d'air (En option pour JH2) 23 Procure par le client 24 (Zone en coupe transversale) 25 Commutateur de batterie 26 Relais du démarreur 27 Batterie 28 Démarreur 29 Commutateur de temp. de l'eau de refroidiss. 30 Avertisseur de pression de l'huile du moteur 31 Boulon de mise à la masse 32 Palpeur du tachymètre 33 (Transmetteur de temp. de l'eau de refroidiss.) 34 (Bar. de marche) 35 (Commutateur du filtre de carburant) 36 (Transmetteur de la pression d'huile du moteur) 37 Détails du coupleur (Vue B-B) 38 Détails du coupleur (Vue A-A) 39 Détails du coupleur (Vue C-C)	1 Drehzahlmesser mit Betriebsstundenzähler 2 Warnsummier 3 Warnsummier-Absteller 4 Beleuchtung 5 SICHERUNG 6 Stoppeschalter 7 Anlasserschalter 8 Relais 9 Motoröldruck 10 Kühlwassertemperatur 11 Segelantrieb 12 Auspuff 13 Krafstoffhahn 14 Armaturenbrett (Station Nr. 2) 15 Sonderzubehör 16 Läden 17 Armaturenbrett 18 Kabelbaum 19 Kabelbaum für Station Nr. 2 20 Sonderzubehör 21 Motorabstell-Solenoid 22 Gabelheizung (Sonderzubehör für JH2) 23 Beschaffung durch Kunde 24 Querschnitt 25 Batterieschalter 26 Anlasserrelais 27 Batterie 28 Anlasser 29 Kühlwassertemperatur-Schalter 30 Motoröldruck-Schalter 31 Lichtmaschine 32 Drehtachymessensor 33 (Kühlwassertemperaturgeber) 34 Segelantrieb 35 (Kraftstofffilter-Schalter) 36 (Motoröldruck-Schalter) 37 Einzelheiten für Steckerkupplung 38 Einzelheiten für Steckerkupplung 39 Einzelheiten für Steckerkupplung 40 Einzelheiten für Steckerkupplung 41 Einzelheiten für Steckerkupplung 42 Einzelheiten für Steckerkupplung 43 Einzelheiten für Steckerkupplung	1 Tacómetro con contador horario 2 Avisor sonoro 3 Parada del avisor sonoro 4 Iluminación 5 FUSIBLE 6 Interruptor de parada 7 Interruptor de arranque 8 Relé 9 Presión del aceite del motor 10 Temperatura del agua de enfriamiento 11 Aconductor de navegación 12 Escape 13 Combustible vacío 14 Panel de instrumentos (estación nr 2) (opción) 15 Carga 16 Panel de instrumentos 17 Cableado preformado 18 Cableado preformado para panel 2 19 Opción 20 Solenoide de parada del motor 21 Adquisitor por el cliente 22 Calentador de aire (opción para JH2) 23 (Área de la sección transversal) 24 Interruptor de la batería 25 Relé del arrancador 26 Batería 27 Arrancador 28 Interruptor de temperatura del agua de enfriamiento 29 Interruptor de presión del aceite del motor 30 Alternador 31 Clavija de puesta a tierra 32 Sensor del tacómetro 33 (Transmisor de temperatura del agua de enfriamiento) 34 (Accionador de navegación) 35 (Interruptor del filtro de combustible) 36 (Transmisor de presión del aceite del motor) 37 Detalles del acoplador (vista B-B) 38 Detalles del acoplador (vista A-A) 39 Detalles del acoplador (vista C-C)	1 Contagiri con Contatore 2 Segnale acustico 3 Arresto segnale acustico 4 Illuminazione (abbr.: illum) 5 FUSIBILE 6 Comando di arresto 7 Comando motore di avviamento 8 Relè 9 Pressione olio motore 10 Temperatura acqua di raffreddamento (abbr.: Temp. A. R.) 11 Comando navigazione a vela 12 Scarico 13 No combustible (abbr.: No comb.) 14 Pannello strumenti 15 (2 Postazione) (Opzionale) 16 Carica 17 Pannello strumenti 18 Cablaggio preassemblato 19 Cablaggio preassemblato per 2° pannello 20 Opzionale 21 Solenoide di arresto motore (abbr.: Solenoide arresto mot.) 22 Riscaldatore d'aria (Opzionale per JH2) 23 Procurato dal cliente 24 Superficie in sezione trasversale 25 Comando batteria 26 Relè motore di avviamento 27 Batteria 28 Motorino di avviamento 29 Comando Temp. A.R. 30 Comando pressione olio mot. 31 Alternatore 32 Bullone di terra elettrica 33 Sensore contagiri 34 (Trasmittitore Temp. A. R.) 35 (Trasmittitore pressione olio motore) 36 (Comando navigazione a vela) 37 (Comando filtro combustibile) 38 (Trasmittitore pressione olio motore) 39 Dettagli dell'accoppiatore (Vista B-B) 40 Dettagli dell'accoppiatore (Vista A-A) 41 Dettagli dell'accoppiatore (Vista C-C)	1 Takometer med timtallare 2 Sumner 3 Sumneravstängning 4 Belysning 5 SÄKRING 6 Stoppomkopplare 7 Startomkopplare 8 Källa 9 Oljetryck i motor 10 Kylvattentemperatur 11 Marschörnt 12 Avgasör 13 Bränsle slut 14 Instrumentpanel 15 Laddning 16 Instrumentpanel 17 Kabelnat 18 Kabelnat för 2:a panel 19 Extra tillbehör 20 Motors stoppsolenoid 21 Luftvärmare 22 (extra tillbehör mod JH2) 23 Inköpt av kunden 24 (Tvarsnitt) 25 Batteriomkopplare 26 Startrelä 27 Batteri 28 Startare 29 Kylvattens temperaturomkopplare 30 Motors oljetryckomkopplare 31 Jordbult 32 Takometersensor 33 (Kylvattentemperaturändare) 34 (Marschörnt) 35 (Bränsleflöets omkopplare) 36 (Skåtare för motors oljetryck) 37 Kopplingsdetaljer (fran B-B) 38 Kopplingsdetaljer (fran A-A) 39 Kopplingsdetaljer (fran A-A)

Cable	Coloris
R	Rouge
B	Noir
W	Blanc
Y	Jaune
L	Bleu
G	Vert
O	Orange
Lg	Vert clair
Lb	Bleu clair
Br	Brun
P	Rose
Gr	Gris
Pu	Pourpre

Label	Farbe
R	Rot
B	Schwarz
W	Weiß
Y	Gelb
L	Blau
G	Grün
O	Orangefarben
Lg	Heilgrün
Lb	Heilblau
Br	Braun
P	Rosa
Gr	Grau
Pu	Lila


Cable	Color
R	Rojo
B	Negro
W	Blanco
Y	Amarillo
L	Azul
G	Verde
O	Naranja
Lg	Verde claro
Lb	Azul claro
Br	Marrón
P	Rosa
Gr	Gris
Pu	Púrpura

Cavo	Colore
R	Rosso
B	Nero
W	Bianco
Y	Giallo
L	Blu
G	Verde
O	Arancione
Lg	Verde chiaro
Lb	Celeste
Br	Marrone
P	Rosa
Gr	Grigio
Pu	Porpora

Lämnig	Färg
R	Röd
B	Svart
W	Vit
Y	Gul
L	Blå
G	Grön
O	Brandgul
Lg	Ljusgrön
Lb	Ljusblå
Br	Brun
P	Skär
Gr	Grå
Pu	Violet

## 12. Wiring diagram

### 12-5 New C-type instrument panel





# 12-6 New D-type instrument panel

## English

- 1 Tacho with Hour meter
- 2 Buzzer
- 3 Buzzer stop
- 4 Fuel gauge
- 5 FUSE
- 6 Stop switch
- 7 Starter switch
- 8 Relay
- 9 Oil pressure
- 10 C.W. Temp
- 11 Sail Drive
- 12 Exhaust
- 13 Fuel emp.
- 14 Instrument panel (No2 station) (Option)
- 15 Charge
- 16 Instrument panel
- 17 Wire harness
- 18 Option
- 19 Eng. stop solenoid
- 20 Air heater
- 21 (Option for JH2)
- 22 Procured by customer
- 23 (Cross sectional area)
- 24 Battery switch
- 25 Instrument relay
- 26 Starter
- 27 Starter
- 28 C.W. Temp. switch
- 29 Eng. oil pressure switch
- 30 Alternator
- 31 Earth bolt
- 32 Tacho sensor
- 33 (C.W. Temp. sender)
- 34 (Sail drive)
- 35 (Fuel filter switch)
- 36 (Eng. oil pressure sender)
- 37 Details of coupler
- 38 Details of coupler
- 39 (View A-A)
- 40 Eng. oil pressure meter
- 41 C.W. Temp meter
- 42 Fuel filter

Cable	Color
R	Red
B	Black
W	White
Y	Yellow
L	Blue
G	Green
O	Orange
Lg	Light green
Lb	Light blue
Br	Brown
P	Pink
Gr	Grey
Pu	Purpl

# 12-6 Tableau de bord de Nouveau type D

## Français

- 1 Tachymètre avec compteur horaire
- 2 Vibreur sonore
- 3 Dispositif d'arrêt du vibreur sonore
- 4 Dispositif d'éclairage
- 5 Fusible
- 6 Commutateur d'arrêt
- 7 Commutateur du démarreur
- 8 Relais
- 9 Pression de l'huile du moteur
- 10 Temp. de l'eau de refroidiss.
- 11 Etat de marche
- 12 Echappement
- 13 Pas de combustion
- 14 Tableau de bord (Passe No 2) (En option)
- 15 Charge
- 16 Tableau de bord
- 17 Harnais de câbles
- 18 Harnais de câbles pour le tableau No 2
- 19 En option
- 20 Solénoïde d'arrêt du moteur
- 21 Réchauffeur d'air (En option pour JH2)
- 22 (Zone en coupe transversale)
- 23 Procure par le client
- 24 Commutateur de batterie
- 25 Relais du démarreur
- 26 Batterie
- 27 Démarreur
- 28 Commutateur de temp. de l'eau de refroidiss.
- 29 Avertisseur de pression de l'huile du moteur
- 30 Alternateur
- 31 Boulon de mise à la masse
- 32 Palpeur du tachymètre
- 33 (Transmetteur de temp. de l'eau de refroidiss.)
- 34 (Etat de marche)
- 35 (Commutateur du filtre de carburant)
- 36 (Transmetteur de la pression d'huile du moteur)
- 37 Détails du coupleur (Vue B-B)
- 38 Détails du coupleur (Vue A-A)
- 39 Détails du coupleur (Vue C-C)
- 40 Manomètre de l'huile du moteur
- 41 Compteur de temp. de l'eau de refroidiss.
- 42 Filtre du carburant

Cable	Coloris
R	Rouge
B	Noir
W	Blanc
Y	Jaune
L	Bleu
G	Vert
O	Orange
Lg	Vert clair
Lb	Bleu clair
Br	Brun
P	Rose
Gr	Gris
Pu	Pourpre

# 12-6 Für Instrumententafel Neuer Typ D

## Deutsch

- 1 Drehzahlmesser mit Betriebsbestundenzähler
- 2 Warnsummen
- 3 Warnsummen-Absteller
- 4 Dispositif d'éclairage
- 5 FUSE
- 6 SICHERUNG
- 7 Stoppschalter
- 8 Relais
- 9 Ölwanne
- 10 Kühlwassertemperatur
- 11 Segelantrieb
- 12 Auspuff
- 13 Kraftstofftank
- 14 Amaturenbrett (Station Nr. 2) (Sonderzubehör)
- 15 Laden
- 16 Amaturenbrett
- 17 Kabelbaum
- 18 Kabelbaum für Station Nr. 2
- 19 Sonderzubehör
- 20 Motorabstell-Solenoid
- 21 Gebläseheizung (Sonderzubehör für JH2)
- 22 Beschaffung durch Kunde
- 23 (Querschnitt)
- 24 Batterieschalter
- 25 Anlasserrelais
- 26 Batterie
- 27 Anlasser
- 28 Kühlwassertemperatur-Schalter
- 29 Motoröl-Druck-Schalter
- 30 Lichtmaschine
- 31 Masseerschraube
- 32 Drehzahlmessensensor
- 33 (Kühlwassertemperaturgeber)
- 34 (Kraftstoff-Schalter)
- 35 (Motoröl-Druck-Schalter)
- 36 Einzelheiten für Steckerkupplung
- 37 (Ansicht B-B)
- 38 Einzelheiten für Steckerkupplung
- 39 (Ansicht A-A)
- 40 Motoröl-Druckmesser
- 41 Kühlwassertemperaturmesser
- 42 Kraftstofffilter

Kabel	Farbe
R	Rot
B	Schwarz
W	Weiß
Y	Gelb
L	Blau
G	Grün
O	Orange
Lg	Hellgrün
Lb	Hellblau
Br	Braun
P	Rosa
Gr	Grau
Pu	Lila

# 12-6 Panel de mando Nuevo tipo D

## Español

- 1 Tachómetro con contador horario
- 2 Vibrador sonoro
- 3 Parada del vibrador sonoro
- 4 Iluminación
- 5 FUSIBLE
- 6 Interruptor de parada
- 7 Relé del arranque
- 8 Presión del aceite del motor
- 9 Temperatura del agua de enfriamiento
- 10 Accionador de navegación
- 11 Combustible vacío
- 12 Panel de instrumentos (estación n° 2) (opción)
- 13 Carga
- 14 Panel de instrumentos
- 15 Cableado preformado para panel 2
- 16 Cableado preformado para panel 2
- 17 Opción
- 18 Solenoide de parada del motor
- 19 Caleador de aire (opción para JH2)
- 20 Adquirido por el cliente
- 21 (Área de la sección transversal)
- 22 Interruptor de la batería
- 23 Relé del arranque
- 24 Batería
- 25 Arrancador
- 26 Interruptor de temperatura del agua de enfriamiento
- 27 Alternador
- 28 Sensor del tachómetro
- 29 (Transmisor de temperatura del agua de enfriamiento)
- 30 (Interrupción del filtro de combustible)
- 31 (Transmisor de presión del aceite del motor)
- 32 Detalles del acoplador (Vista B-B)
- 33 Detalles del acoplador (Vista A-A)
- 34 Detalles del acoplador (Vista C-C)
- 35 Medidor de temperatura del agua de enfriamiento
- 36 Medidor de combustible

Cable	Color
R	Rojo
B	Negro
W	Bianco
Y	Amarillo
L	Azul
G	Verde
O	Naranja
Lg	Verde claro
Lb	Azul claro
Br	Marrón
P	Rosa
Gr	Gris
Pu	Púrpura

# 12-6 Pannello degli strumenti di tipo D nuovo

## Italiano

- 1 Contagiri con Contatore
- 2 Segnale acustico
- 3 Interruttore acustico
- 4 Illuminazione (abor. - Illum.)
- 5 FUSIBILE
- 6 Comando di arresto
- 7 Comando motore di avviamento
- 8 Relè
- 9 Pressione olio motore
- 10 Temperatura acqua di raffreddamento (abbr. Temp. A. R.)
- 11 Comando navigazione a vela
- 12 Scarico
- 13 No combustibile (abbr. No comb.)
- 14 Pannello strumenti
- 15 Carica
- 16 Pannello strumenti
- 17 Cablaggio preassemblato per 2° pannello
- 18 Cablaggio preassemblato per 2° pannello
- 19 Opzionale
- 20 Solenoide di arresto motore (abbr. : Solenoide arresto mot.)
- 21 Riscaldatore d'aria (Opzionale per JH2)
- 22 Procurato dal cliente
- 23 Superficie in sezione trasversale
- 24 Comando batteria
- 25 Relè motore di avviamento
- 26 Batteria
- 27 Motorino di avviamento
- 28 Motorino Temp. A. R.
- 29 Comando pressione olio mot.
- 30 Alternatore
- 31 Bullone di terra elettrica
- 32 Sensore contagiri
- 33 (Trasmettore Temp. A. R.)
- 34 (Comando navigazione a vela)
- 35 (Comando filtro combustibile)
- 36 (Trasmettore pressione olio motore)
- 37 Dettagli dell'accoppiatore (Vista B-B)
- 38 Dettagli dell'accoppiatore (Vista A-A)
- 39 Dettagli dell'accoppiatore (Vista C-C)
- 40 Manometro pressione olio motore
- 41 Misuratore Temp. A. R.
- 42 Filtro combustibile

Cavo	Colore
R	Rosso
B	Nero
W	Bianco
Y	Giallo
L	Blu
G	Verde
O	Arancione
Lg	Verde chiaro
Lb	Celeste
Br	Marrone
P	Rosa
Gr	Grigio
Pu	Porpora

# 12-6 Instrumentbräde av Ny typ D

## Svensk

- 1 Tachometer med lufthälsare
- 2 Svarnare
- 3 Svarnareavstängning
- 4 Belysning
- 5 SÄKRING
- 6 Stoppskopplare
- 7 Startkopplare
- 8 Relä
- 9 Oljetryck i motor
- 10 Kylvätsketemperatur
- 11 Mätskärft
- 12 Avgasrör
- 13 Bränsle slut
- 14 Instrumentpanel
- 15 Laddning
- 16 Instrumentpanel
- 17 Kabelbakt
- 18 Kabelbakt för 2:a panel
- 19 Extra tillbehör
- 20 Motors stoppsolenoid
- 21 Luftvärmare
- 22 (extra tillbehör med JH2)
- 23 (Färdskift)
- 24 Batteriskopplare
- 25 Startrelä
- 26 Batteri
- 27 Startare
- 28 Kylvätsketemperaturkopplare
- 29 Motors oljetryckskopplare
- 30 Våtskiftsgenerator
- 31 Jordbult
- 32 Taktensensor
- 33 (Kylvätsketemperaturändare)
- 34 (Mätskift)
- 35 (Bränslediffräns kopplare)
- 36 (Standard för motors oljetryck)
- 37 Kopplingsidealjer (Fram B-B)
- 38 Kopplingsidealjer (Fram A-A)
- 39 Kopplingsidealjer (Fram C-C)
- 40 Måttare för motors oljetryck
- 41 Kylvätsketemperaturmätare
- 42 Bränslemätare

Leining	Färg
R	Röd
B	Svart
W	Vit
Y	Gul
L	Blå
G	Grön
O	Brandgul
Lg	Ljusgrön
Lb	Ljusblå
Br	Brun
P	Skar
Gr	Grå
Pu	Violett

## 12. Wining diagraf

## 12-6 New D-type instrument panel

