

Diagnostic and Setup Application Notes

Products: Rudder Reference Transducer

Purpose: Onboard or bench diagnostic procedure

Equipment required: Digital multimeter, tools required to gain access to unit

Test data:

Rudder Reference Cable Colors	Resistance Measurements	Comments
Green-Red	5 K Ohms	Measurement is taken between red and green
Green-Blue	Normal rudder travel will display a range of approximately 1.7 to 3.3 K Ohms.	Measurement is taken between blue and green
Red-Blue	Normal rudder travel will display a range of approximately 1.7 to 3.3 K Ohms.	Measurement is taken between blue and red

Test procedure:

Multimeter should be set to:

1. DC Voltage
2. 200 ohm scale

The following procedure should then be followed:

1. Disconnect the transducer from the system.
2. Connect one multimeter lead to the green wire and the other multimeter lead to the red wire. A reading as indicated in the test data table should be present.
3. Connect one multimeter lead to the green wire and the other multimeter lead to the blue wire and a reading as indicated in the test data table should be present. The rudder reference transducer will have to be rotated through 360 degrees to see the full resistance range.

4. If all readings match those in the test data table then assume the rudder reference transducer is functioning correctly.

Diagnostic tests completed.

Diagnostic and Setup Application Notes

Product: Fluxgate Compass

Purpose: Onboard or bench diagnostic procedure

Equipment required: Digital multimeter, tools required to gain access to unit

Test data:

Compass Cable Colors	Resistance Measurements	Comments
Red-Green	4-10 ohms	Measurement is taken between the two colors
Red-Yellow	4-10 ohms	As above
Green Yellow	8-10 ohms	As above
Screen-Blue	8-10 ohms	As above
All other combinations	Open circuit	---

Test procedure:

Multimeter should be set to:

1. Resistance scale
2. 200 ohm scale

The following procedure should then be followed:

1. Disconnect the transducer from the system.
2. Connect one multimeter lead to the red wire and the other lead to the green wire and a reading as indicated in the test data table should be present.
3. Follow the above procedure for all the color combinations indicated in the test data table.
4. If all readings match those indicated, assume the transducer is functioning correctly.
5. If readings do not match those indicated, repeat the procedure at the compass core, bypassing the cable.

Diagnostic tests completed.

Diagnostic and Setup Application Notes

Products: Gyro Plus Transducer, Gyro Plus 2, Pathfinder Smart Heading System

Purpose: Onboard or bench diagnostic procedure

Equipment required: Digital multimeter, tools required to gain access to unit

Test data:

Gyro Transducer Cable Colors	Resistance Measurements	Comments
Red	12 Volts DC	Measurement is taken between red and screen
Screen	0 Volts DC	Reference point for measurements
Yellow	Variable 1 to 4 Volts DC	Reading taken between screen and yellow

Test procedure:

Multimeter should be set to:

1. DC Voltage
2. 20 Volt scale

The following procedure should then be followed:

1. Connect the negative multimeter lead to the transducer screen wire and the positive multimeter lead to the transducer red wire. A reading, as indicated in the test data table, should be present. If the reading is NOT present, then one of the following apply:
 - a. The course computer (T100/300, S2, S3) or Gyro Plus 2/SHS electronics module is faulty.
 - b. If the measurement is taken along the cable run there may be a faulty connection in some other position along the cable run.
2. With the multimeter negative lead connected to the transducer screen wire and the multimeter positive lead connected to the transducer yellow wire, a reading as indicated in the test data

table should be present. This reading will be a variable voltage dependent upon lateral movement of the transducer.

Bench Test:

This procedure is for testing the gyro plus transducer when not connected to a system.

1. Apply 12 volts DC to the unit from a bench power supply. Connective the negative (-ve) power supply lead to the transducer screen wire. Connect the positive (+ve) power supply lead to the transducer red wire. This simulates the voltage supplied by the course computer to the gyro plus transducer.
2. With the multimeter negative lead connected to the transducer screen wire and the multimeter positive lead connected to the transducer yellow wire, a reading as indicated in the test data table should be present. This reading will be a variable voltage dependent upon lateral movement of the transducer.
3. If these readings are present then assume the transducer is functioning correctly.

Diagnostic tests completed.

Diagnostic and Setup Application Notes

Product: ST30, 40, 50, 60, 80, 290 Depth Transducer

Purpose: Onboard or bench diagnostic procedure

Equipment required: Spare depth transducer, tools required to gain access to unit

Test data:

Instrument Cable Color	Transducer Cable Color	Measurement	Comments
Red	Blue	+ve signal output	---
Screen	Black and Screen	-ve	---

Test procedure:

The testing of the depth system on board a vessel is a difficult task with out sophisticated test equipment, so the following procedures are very basic and simple methods of test.

1. Make sure the true depth if water is known under the vessel at the time of testing.
2. Gain access to the back of the depth instrument and disconnect the transducer.
3. Connect the spare transducer to the instrument and place the transducer over the side of the vessel. The depth reading reported should match the known depth.
4. It is advisable to check all connections, splices, extensions, junction boxes, etc. the original depth transducer is connected to.

Note:

The depth transducer is known to be very reliable if installed correctly and cleaned periodically. Any faults would tend to be within the depth instrument, thus requiring further bench testing.

Onboard diagnostic test completed.

Diagnostic and Setup Application Notes

Products: ST30, ST40, ST50, ST60, ST80, ST290 Speed/Bidata/Tridata Speed Transducers

Purpose: Onboard or bench diagnostic procedure

Equipment required: Digital multimeter, 10 K ohm resistor, tools required to gain access to unit

Test data:

Instrument Cable Color	Transducer Cable Color	Measurement	Comments
Red	Red	5 Volts DC	Measurement is taken between red and screen
Screen	Screen	0 Volts DC	Reference point for measurements
Green	Green	Variable 0 to 5 volts	Log pulse signal. Reading taken between screen and green
Yellow	Yellow	Temperature 1	See test Procedure
Blue	Blue	Temperature 2	See test procedure

Test procedure:

Multimeter should be set to:

1. DC Voltage
2. 20 Volt scale

When testing the system for the voltage measurements listed in the table above, access to the rear of the speed master instrument, speed transducer pod (ST80, 290), or junctions within the cable run is required. Care must be taken not to short circuit or break any of the connections. The following procedure should then be followed:

Testing the Speed Transducer Power Supply

1. Connect the negative multimeter lead to the screen wire, and the positive multimeter lead to the red wire. A reading of 5 volts DC should be present. This 5 volts is the supply from the

speed instrument or host pod to the transducer. If it is not present, one of the following will apply:

- a. The speed instrument or speed transducer pod is not energized.
- b. The speed instrument or speed transducer pod is faulty.
- c. If the measurement is taken along the cable run, there may be an open connection in some other position on the run.


Testing the Boat Speed Elements

2. With the multimeter negative lead connected to the screen and the positive lead connected to the green wire, a variable voltage as indicated in the test data table should be observed, and varies in proportion to the speed of rotation of the paddle wheel. The voltage will increase as the transducer spins faster.
3. If these readings are present then assume the speed transducer is functioning correctly.

Testing the Water Temperature Element

The following should be carried out with the speed transducer disconnected.

4. With the instrument or pod power on, place a 10 K ohm transducer between the blue and yellow terminals on the instrument or pod. The device should register a temperature reading on the instrument of 25 degrees centigrade. Additional combinations of temperature vs. resistance can be tested using either of the charts provided below.



Airmar Standard Thermistor–Resistance vs. Temperature

Part #07-045

Nominal Resistance: 10,000 ohm at 25° C

Temp.(°C)	Resistance	Temp. (°C)	Resistance	Temp.(°C)	Resistance	Temp. (°C)	Resistance
–20	97083.62	–5	42344.54	10	19911.1	25	10000.0
–19	91626.82	–4	40177.6	11	18980.03	26	9571.689
–18	86507.95	–3	38134.17	12	18098.44	27	9164.221
–17	81704.43	–2	36206.02	13	17262.34	28	8776.205
–16	77198.14	–1	34387.08	14	16469.68	29	8406.722
–15	72967.79	0	32670.43	15	15717.99	30	8054.942
–14	68994.43	1	31048.25	16	15004.33	31	7719.596
–13	65258.81	2	29516.63	17	14327.51	32	7400.123
–12	61748.23	3	28069.29	18	13684.99	33	7095.607
–11	58448.13	4	26701.02	19	13074.77	34	6805.281
–10	55344.09	5	25407.34	20	12494.98	35	6528.319
–9	52422.74	6	24184.14	21	11944.42	36	6264.156
–8	49673.03	7	23026.11	22	11420.69	37	6012.082
–7	47083.13	8	21930.8	23	10923.14	38	5771.551
–6	44644.56	9	20892.93	24	10450.07	39	5541.918
						40	5322.632

- If this reading is present then assume the instrument or pod is functioning correctly, and any temperature error is due to a faulty temperature circuit within the transducer.

Diagnostic tests completed.

Diagnostic and Setup Application Notes

Products: ST50, ST60, ST80, ST290 Masthead Wind Transducer

Purpose: Onboard or bench diagnostic procedure

Equipment required: Digital multimeter, tools required to gain access to unit

Test data:

Instrument Cable Color	Transducer Cable Color	Measurement	Comments
Red	Red	8 Volts DC	Measurement is taken between red and screen
Screen	Screen	0 Volts DC	Reference point for measurements
Blue	Blue	Variable 2 to 6 Volts DC	Reading taken between screen and blue
Green	Green	Variable 2 to 6 Volts DC	Reading taken between screen and green
Yellow	Yellow	Variable 0 to 5 Volts DC	Reading taken between screen and yellow

Test procedure:

Multimeter should be set to:

1. DC Voltage
2. 20 Volt scale

When testing the system for the voltage measurements listed in the table above, access to the rear of the wind instrument, wind transducer pod (ST80, 290), or junctions within the masthead cable run is required. Care must be taken not to short circuit or break any of the connections. The following procedure should then be followed:

Testing the Masthead Unit Power Supply

1. Connect the negative multimeter lead to the screen wire, and the positive multimeter lead to the red wire. A reading of 8 volts DC should be present. This 8 volts is the supply from the wind instrument or host pod to the transducer. If it is not present, one of the following will apply:
 - a. The wind instrument or wind transducer pod is not energized.
 - b. The wind instrument or wind transducer pod is faulty.
 - c. If the measurement is taken along the cable run, there may be an open connection in some other position on the run.

Testing the Wind Directional Elements

2. With the multimeter negative lead connected to the screen and the positive lead connected to the blue wire, a variable voltage as indicated in the test data table should be observed, and varies in proportion to wind vane rotation.
3. With the multimeter negative lead connected to the screen wire and the positive lead connected to the green wire a variable voltage as indicate in the test data table should be observed and varies in proportion to wind vane rotation.
4. If it is possible to view both directional lines simultaneously, you should see the voltage changing in opposition between the two lines (e.g. one increase as the other decreases.)
5. If these readings are present then assume the directional transducer is functioning correctly.

Testing the Wind Speed Elements

6. With the multimeter negative lead connected to the screen wire and the positive lead connected to the yellow wire, a variable voltage of 0 to 5 volts DC should be present. The voltage will increase as the transducer spins faster.
7. If these readings are present then assume the speed transducer is functioning correctly.

Diagnostic tests completed.

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part2
 Stand: 23.03.2003



SeaTalk Technical Reference Part 2:

Recognized Datagrams (in hexadecimal notation):

Com Att Dat Dat...

```

00 02 YZ XX XX Depth below transducer: XXXX/10 feet
                        Display units: Y=0 => feet, Y=4 => meter
                        Flags: Z&1 Shallow Depth Alarm (Z=1)
                              Z&2 Transducer defective (Z=4)
                        Corresponding NMEA sentences: DPT, DBT

01 05 00 00 00 60 01 00 Sent by course computer 400G shortly
                        after power on.
01 05 FA 03 00 30 07 03 Sent by ST80 Maxi Display shortly
                        after power on.
01 05 04 BA 20 28 01 00 Sent by ST60 Tridata shortly after power on

10 01 XX YY Apparent Wind Angle: XXYY/2 degrees right of bow
                        Used for autopilots Vane Mode (WindTrim)
                        Corresponding NMEA sentence: MWV

11 01 XX 0Y Apparent Wind Speed: (XX & 0x7F) + Y/10 Knots
                        Units flag: XX&0x80=0 => Display value in Knots
                              XX&0x80=0x80 => Display value in Meter/Second
                        Corresponding NMEA sentence: MWV

20 01 XX XX Speed through water: XXXX/10 Knots
                        Corresponding NMEA sentence: VHW

21 02 XX XX 0X Trip Mileage: XXXXX/100 nautical miles

22 02 XX XX 00 Total Mileage: XXXX/10 nautical miles

23 41 XX YY Water temperature (ST50): XX deg Celsius, YY deg Fahrenheit
                        Corresponding NMEA sentence: MTW

24 02 00 00 XX Display units for Mileage & Speed
                        XX: 00=nm/knots, 06=sm/mph, 86=km/kmh

25 Z4 XX YY UU VV AW Total & Trip Log
                        total= (XX+YY*256+Z* 4096)/ 10 [max=104857.5] nautical miles
  
```

trip = (UU+VV*256+W*65536)/100 [max=10485.75] nautical miles

- 26 04 XX XX YY YY D1 Speed through water:
 Sensor 1: XXXX/100 Knots, valid if D1&64=64
 Sensor 2: YYYY/100 Knots, valid if D1&128=128
 Corresponding NMEA sentence: VHW
- 27 01 XX XX Water temperature: (XXXX-100)/10 deg Celsius
 Corresponding NMEA sentence: MTW
- 30 00 0X Set lamp Intensity; X=0: L0, X=4: L1, X=8: L2, X=C: L3
 (only sent once when setting the lamp intensity)
- 36 00 01 Cancel MOB (Man Over Board) condition
- 38 X1 YY yy Codelock data
- 50 A2 XX YY YY LAT position: XX degrees, (YYYY & 0x7FFF)/100 minutes
 MSB of Y = YYYY & 0x8000 = South if set, North if cleared
 Corresponding NMEA sentences: RMC, GAA, GLL
- 51 A2 XX YY YY LON position: XX degrees, (YYYY & 0x7FFF)/100 minutes
 MSB of Y = YYYY & 0x8000 = East if set, West if cleared
 Corresponding NMEA sentences: RMC, GAA, GLL
- 52 01 XX XX Speed over Ground: XXXX/10 Knots
 Corresponding NMEA sentences: RMC, VTG
- 53 X0 XX Course Magnetic: XXX/8 Degrees
 Least significant 2 bits are always 0,
 giving a resolution of 0.5 degrees
 Corresponding NMEA sentences: RMC, VTG
- 54 T1 TT HH GMT-time: HH hours,
 6 MSBits of TTT = (TTT & 0xFC0) / 64 = minutes
 6 LSBits of TTT = TTT & 0x3F = seconds
 Corresponding NMEA sentences: RMC, GAA, BWR, BWC
- 55 X1 YY yy TRACK keystroke on GPS unit
 keycodes identical with autopilot ([command 86](#))
- 56 M1 DD YY Date: YY year, M month, DD day in month
 Corresponding NMEA sentence: RMC
- 57 S0 DD Sat Info: S number of sats, DD horiz. dillution of position
 Corresponding NMEA sentences: GGA, GSA
- 58 Z5 LA XX YY LO QQ RR LAT/LON
 LA Degrees LAT, LO Degrees LON

minutes LAT = (XX*256+YY) / 1000
 minutes LON = (QQ*256+RR) / 1000
 Z&1: South (Z&1 = 0: North)
 Z&2: East (Z&2 = 0: West)
 Corresponding NMEA sentences: RMC, GAA, GLL

59 22 SS MM XH Set Count Down Timer
 MM=Minutes (00..3B) (00 .. 63 Min), MSB:0 Count up start
 flag

SS=Seconds (00..3B) (00 .. 59 Sec)
 H=Hours (0..9) (00 .. 09 Hours)
 X= Counter Mode: 0 Count up and start if MSB of MM set
 4 Count down
 8 Count down and start
 (Example 59 22 3B 3B 49 -> Set Countdown Timer to 9.59:59)

59 22 0A 00 80 Sent by ST60 in countdown mode when counted down to 10 Seconds.

6C 05 04 BA 20 28 2D 2D Second datagram sent by ST60 Tridata shortly after power on

6E 07 00 00 00 00 00 00 00 00 MOB (Man Over Board), (ST80), preceded
 by a Waypoint 999 command: 82 A5 40 BF 92 6D 24 DB

80 00 0X Set Lamp Intensity: X=0 off, X=4: 1, X=8: 2, X=C: 3

81 01 00 00 Sent by course computer during setup when going past USER CAL.

81 00 00 Sent by course computer immediately after above.

82 05 XX xx YY yy ZZ zz Target waypoint name
 XX+xx = YY+yy = ZZ+zz = FF (allows error detection)
 Takes the last 4 chars of name, assumes upper case only
 Char= ASCII-Char - 0x30
 XX&0x3F: char1
 (YY&0xF)*4+(XX&0xC0)/64: char2
 (ZZ&0x3)*16+(YY&0xF0)/16: char3
 (ZZ&0xFC)/4: char4
 Corresponding NMEA sentences: RMB, APB, BWR, BWC

83 07 XX 00 00 00 00 00 80 00 00 Sent by course computer.
 XX = 0 after clearing a failure condition, also sent once after
 power-up.

XX = 1 failure, auto release error. Repeated once per second.

84 U6 VW XY 0Z 00 RR SS TT Compass heading Autopilot course and
 Rudder position (see also command 9C)
 Compass heading in degrees:
 The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 the two higher bits of U / 2 =
 (U & 0x3) * 90 + (VW & 0x3F) * 2 + (U & 0xC) / 8

Autopilot course in degrees:

The two higher bits of $V * 90 + XY / 2$

Z & 0x2 = 0 : Autopilot in Standby-Mode

Z & 0x2 = 2 : Autopilot in Auto-Mode

Z & 0x4 = 4 : Autopilot in Vane Mode (WindTrim), requires regular

"10" datagrams

Rudder position: RR degrees (positive values steer right,

negative values steer left. Example: 0xFE = 2° left)

SS & 0x01 : when set, turns off heading display on 600R control.

SS & 0x02 : always on with 400G

SS & 0x08 : displays "NO DATA" on 600R

SS & 0x10 : displays "LARGE XTE" on 600R

SS & 0x80 : Displays "Auto Rel" on 600R

TT : Always 0x08 on 400G computer

85 X6 XX VU ZW ZZ YF 00 yf Navigation to waypoint information

Cross Track Error: XXX/100 nautical miles

Example: X-track error 2.61nm => 261 dec => 0x105 => X6XX=5_10

Bearing to destination: $(U \& 0x3) * 90^\circ + WV / 2^\circ$

Example: GPS course 230°=180+50=2*90 + 0x64/2 => VUZW=42_6

U&8: U&8 = 8 -> Bearing is true, U&8 = 0 -> Bearing is magnetic

Distance to destination: Distance 0-9.99nm: ZZZ/100nm, Y & 1 = 1

Distance >=10.0nm: ZZZ/10 nm, Y & 1 = 0

Direction to steer: if Y & 4 = 4 Steer right to correct error

if Y & 4 = 0 Steer left to correct error

Example: Distance = 5.13nm, steer left: 5.13*100 = 513 = 0x201 =>

ZW ZZ YF=1_ 20 1_

Distance = 51.3nm, steer left: 51.3*10 = 513 = 0x201 =>

ZW ZZ YF=1_ 20 0_

Track control mode:

F= 0x1: Display x-track error and Autopilot course

F= 0x3: Enter Track Control Mode, i.e. lock on to GPS.

Display x-track error, autopilot course and bearing to destination

F= 0x5: Display x-track error, distance to waypoint, autopilot course and bearing to destination

normal--> F= 0x7: Enter Track Control Mode, i.e. lock on to GPS.

Display x-track error, distance to waypoint, autopilot course and bearing to destination

F= 0xF: As 0x7 but with x-track error alarm

F= 2, 4, 6, 8 ... causes data errors

Corresponding NMEA sentences: RMB, APB, BWR, BWC, XTE

86 X1 YY yy Keystroke

X=1: Sent by Z101 remote control to increment/decrement course of autopilot

11 05 FA -1

11 06 F9 -10

11 07 F8 +1

11 08 F7 +10

11	20	DF	+1 & -1	
11	21	DE	-1 & -10	
11	22	DD	+1 & +10	
11	28	D7	+10 & -10	
11	45	BA	-1	pressed longer than 1 second
11	46	B9	-10	pressed longer than 1 second
11	47	B8	+1	pressed longer than 1 second
11	48	B7	+10	pressed longer than 1 second
11	60	DF	+1 & -1	pressed longer than 1 second
11	61	9E	-1 & -10	pressed longer than 1 second
11	62	9D	+1 & +10	pressed longer than 1 second
11	64	9B	+10 & -10	pressed longer than 1 second (why not 11 68 97 ?)

Sent by autopilot (X=0: ST 1000+, X=2: ST4000+ or ST600R)

X1	01	FE	Auto	
X1	02	FD	Standby	
X1	03	FC	Track	
X1	04	FB	disp (in display mode or page in auto chapter = advance)	
X1	05	FA	-1 (in auto mode)	
X1	06	F9	-10 (in auto mode)	
X1	07	F8	+1 (in auto mode)	
X1	08	F7	+10 (in auto mode)	
X1	09	F6	-1 (in resp or rudder gain mode)	
X1	0A	F5	+1 (in resp or rudder gain mode)	
X1	21	DE	-1 & -10 (port tack, doesn't work on ST600R?)	
X1	22	DD	+1 & +10 (stb tack)	
X1	23	DC	Standby & Auto (wind mode)	
X1	28	D7	+10 & -10 (in auto mode)	
X1	2E	D1	+1 & -1 (Response Display)	
X1	41	BE	Auto pressed longer	
X1	42	BD	Standby pressed longer	
X1	43	BC	Track pressed longer	
X1	44	BB	Disp pressed longer	
X1	45	BA	-1 pressed longer (in auto mode)	
X1	46	B9	-10 pressed longer (in auto mode)	
X1	47	B8	+1 pressed longer (in auto mode)	
X1	48	B7	+10 pressed longer (in auto mode)	
X1	63	9C	Standby & Auto pressed longer (previous wind angle)	
X1	68	97	+10 & -10 pressed longer (in auto mode)	
X1	6E	91	+1 & -1 pressed longer (Rudder Gain Display)	
X1	80	7F	-1 pressed (repeated 1x per second)	
X1	81	7E	+1 pressed (repeated 1x per second)	
X1	82	7D	-10 pressed (repeated 1x per second)	
X1	83	7C	+10 pressed (repeated 1x per second)	
X1	84	7B	+1, -1, +10 or -10 released	

87 00 0X Set Response level
 X=1 Response level 1: Automatic Deadband
 X=2 Response level 2: Minimum Deadband


```

88 03 WW XX YY ZZ Autopilot Parameter: Sent by AP every
                    second while in parameter setting mode.
                    (User or Dealer Calibration Mode)
                    WW Parameter Number
                    XX Current Setting
                    YY Max Parameter Value
                    ZZ Min Parameter Value
                    Known Paramters: Parameter (min-max) [default]

Number
                    rudder gain (1-9)
[2]                    1
                    counter rudder (1-9)
[2]                    2
                    rudder limit (10-40)
[30]                   3
                    turn rate limit (1-30)
[off]                  4
                    speed (4-60)
[8]                    5
                    off course limit (15-40)
[20]                   6
                    auto trim (0-4)
[1]                    7
                    power steer [Joy Stick] ON/OFF (not on new
400G)                  9
                    drive type (3,4,5)
[3]                    A
                    rudder damping (1-9)
[2]                    B
                    variation: (full degrees)(-30 to +30)
[0]                    C
                    auto adapt: 0=Off,1=North,2=South
[1]                    D
                    auto adapt latitude (0-80)
[0]                    E
                    auto release (only for stern drive)
ON/OFF                 F
                    rudder alignment (-7 to +7)
[0]                    10
                    Wind Trim (Wind Response) (1-9) [5] (only for
sail)                  11
                    Response (1-9)
[5]                    12
                    Boat type:1=displ,2=semi-
displ,3=plan,4=stern,5=work,6=sail 13
                    Cal Lock: 0=OFF, 1=ON
[0]                    15
                    Auto Tack Angle (40-125) [100] (only for
sail)                  1d

89 U2 VW XY 2Z Compass heading sent by ST40 compass instrument
                    (it is read as a compass heading by the ST1000(+) or ST2000(+)
autopilot)

```

Compass heading in degrees:

The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 the two higher bits of U / 2 =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 2$

Locked stear reference (only send by the ST40 compass):

The two higher bits of V * 90 + XY / 2
 $Z \& 0x2 = 0$: St40 in Standby mode
 $Z \& 0x2 = 2$: St40 in Locked stear mode

Corresponding NMEA sentences: HDM, HDG, HDT, VHW

90 00 XX Device Indentification
 XX=02 sent by ST600R ~every 2 secs
 XX=05 sent by type 400G course computer
 XX=A3 sent by NMEA <-> SeaTalk bridge ~every 10 secs

91 00 0X Set Rudder gain to X

92 02 XX YY 00 Set Autopilot Parameter: Sent by the remote head
 (e.g. ST600R) to set a particular parameter.
 XX Parameter Number (see 88)
 YY Value to set to.

93 00 00 Enter AP-Setup: Sent by course computer before
 finally entering the dealer setup. It is repeated
 once per second, and times out after ten seconds.
 While this is being sent, command 86 X1 68 97 is
 needed for final entry into Setup. (600R generates
 this when -1 & +1 are pressed simultaneously in this
 mode).

95 U6 VW XY 0Z 00 RR 00 0T Replaces command 84 while autopilot is in value
 setting mode
 e.g. lamp intensity or response level

99 00 XX Compass variation sent by ST40 compass instrument
 or ST1000, ST2000, ST4000+ autopilot every 10 seconds
 but only if the variation is set on the instrument
 Positive XX values: Variation West, Negative XX values:
 Variation East
 Examples (XX => variation): 00 => 0, 01 => -1 west, 02 => -2
 west ...
 FF => +1 east, FE => +2 east ...
 Corresponding NMEA sentences: RMC, HDG

9A 09 L11 L12 L13 L14 L21 L22 L23 00 00 00 Version String:
 L11 means line 1 char 1. There are two lines, line 1
 Can have 4 characters and line two can have 3
 Characters. Char: "A"= 0x00, "B"= 0x01,.....
 Char: "0"= 0x25, "1"= 0x26,

Some special characters are mapped to the range
Between alphas and numeric chars. It seems modulo
masked at 0x36, and wraps around from there.

9C U1 VW RR Compass heading and Rudder position (see also command 84)
Compass heading in degrees:
The two lower bits of U * 90 +
the six lower bits of VW * 2 +
the two higher bits of U / 2 =
(U & 0x3) * 90 + (VW & 0x3F) * 2 + (U & 0xC) / 8
Rudder position: RR degrees (positive values steer right,
negative values steer left. Example: 0xFE = 2° left)
The rudder angle bar on the ST600R uses this record

9E FC 49 49 03 XX AA BB YY OO PP GG HH II JJ Waypoint definition
XX: Degrees LAT, YY: Degrees LON
min&sec LAT= AA+(BB&0x1F)*256, BB&0x80 = 0: North, BB&0x80 =
0x80: South
min&sec LON= OO+(PP&0x1F)*256, PP&0x80 = 0: West, PP&0x80 =
0x80: East
GG HH II JJ: Last four characters of waypoint name

A1 XD 49 49 GG HH II JJ C1 C2 C3 C4 C5 C6 C7 C8 Destination Waypoint Info
GG HH II JJ: Last four characters of waypoint name
C1...C8: Up to 8 characters of WP name, unused are 0
Longer names (> 8 chars) create an additional record:
X=0: single record (short name)
X=1: 1st record, more follows
X=3: last record
Corresponding NMEA sentences: RMB, APB, BWR, BWC

A2 X4 00 00 00 00 00 Arrival Info
X&0x2=Arrival perpendicular passed, X&0x4=Arrival circle entered
Corresponding NMEA sentences: APB, AAM

A5 GPS and DGPS Info

A5 57 QQ HH ?? AA GG ZZ YY DD GPS and DGPS Fix Info
Signal Quality= QQ&0xF, QQ&0x10: Signal Quality available flag
HDOP= HH&0x7C, HH&0x80: HDOP available flag
Antenna Height= AA
Number of Sats= (QQ&0xE0)/16+(HH&0x1), HH&0x2: NumSats available
flag
GeoSeperation= GG*16 (-2048....+2047 meters)
Differential age=(ZZ&0xE0)/2+(YY&0xF), YY&0x10: Diff. age
available flag
Differential Station ID=(YY&0xC0)*4+DD, YY&0x20: Diff.St.ID
available flag
Corresponding NMEA sentences: GGA, RMC, GSV, GLL, GGA

A5 74 ID ID ID ID ID GPS Info: ID numbers of satellites
 A5 XD NN AA EE SS MM BB FF GG OO CC DD XX YY ZZ GPS Info: Sat Position and
 Signal
 Data of up to three satellites [1,2,3] per datagram
 Satellite number: [1] $NN \& 0xFE$, [2] $(MM \& 0x70)/2 + (BB \& 0x7)$, [3]
 $CC \& 0x3F$
 Satellite azimuth: [1] $AA * 2 + (EE \& 0x1)$, [2] $(BB \& 0xF8) * 2 + (FF \& 0xF)$,
 [3] $(CC \& 0xC0) * 2 + DD \& 0x7F$
 Satellite elevation: [1] $(EE \& 0xFE)/2$, [2] $(FF \& 0xF0)/2 + GG \& 0x7$, [3]
 $XX \& 0x7F$
 Satellite signal: [1] $(SS \& 0xFE)/2$, [2] $(GG \& 0x80)/2 + OO \& 0x3F$, [3]
 $(YY \& 0xFC)/2 + ZZ \& 0x1$

It seems that there will be 4 sat info
 datagrams generated, the first with X=0
 carries the position and signal data of the
 1st 3 satellites. The second also with X=0,
 but NN&0x1 set and a length of 0x0C carries
 the data of the next 2 satellites and then
 the ID numbers of the 1st 4 sats. A
 datagram like the 1st one, but with X=2
 carries data of 3 more sats [6,7,8]. It was
 not possible to get more than 8 sats mapped
 to SeaTalk. Finally a datagram with X=7
 carries the next 5 ID numbers.

Corresponding NMEA sentences: GSV, GSA

[Return to Top of Page](#)
 [Overview](#)
 [Part 1](#)
 [Part 3](#)