
MAIN DC BUS
Turn on Main DC Breaker to provide power to:
Cabin, Courtesy and Panel Lights, Radio, Macerators, Antenna, Winch, Windlass CC, Water & Sump Pumps, Ship's Navigational Lighting, Bilge Pump, Autopilot, Blower, LP Gas, Refrigerator
Windlass
Main Engine Starter
Generator Starter
On/Off Switch
Panel Switch 1
Panel Switch 2
Battery #1
Battery #2
Starting Battery
Solar Panel
Main Engine Alternator
Inverter Draw Selector Switch
Inverter / Charger
AC Shore Power #1
Blocking Relay
Interlocked Breaker
AC Bus 1
Microwave, Cabin Heater, Outlets, Water Heater, Refrigerator
Auxiliary Generator
Interlocked Breaker
AC Shore Power #2
AC Bus 2
Air Conditioning