

Hunter Interior Care

2003 H44

3/15/2011 Al Fooks, Hunter Customer Service

Kitchen Rail, cabinets, walls (lacquer finish)

Top Coat – Mohawk #M102-0452 Precatalized Satin Lacquer, Ultra Flow Clear

Deep Scratches – Sanding Sealer 1-3 coats, Mohawk #M102-0423

Water in the wood – White milky look. Mohawk No Blush #M103-0476

Walls Cleaning – if lacquer finish use pledge lightly and if refinish is needed: Mohawk #M102-0452 Precatalized Satin Lacquer, Ultra Flow Clear

Purchase from: David at: Industrial Wood Finishes 14622 Southlawn Lane Rockville MD 20850

301-424-3033 (Phone) www.industrial-finishes.com (Website)

Dining Table Top –

Light Scratches use fine polish – Liquid Polish 3M

Deeper scratches:

1. TR311 Buffing (slow buffing), then
2. Perfect It 3M, then
3. Liquid Polish 3M
4. Buff Slow
5. Usually they have to strip it and start over ☹

Windows and hatches:

Light Scratches: 3M Perfect Finish, buff real slow, NO HEAT, then clean with soapy water only.

Deeper Scratches: 1000,1200, 1600, 2000 wet sand by hand or use a block of wood. Buy wet sandpaper at paint store or auto store, then 3m Perfect Finish