



Spinnaker Sheets

Spinnaker sheets lead aft to the eyes near the stern of the boat, and then forward to the cleats.

Foreguy

Tie a twist pin shackle to the foreguy. The shackle connects to the forward end of the spinnaker pole. The foreguy leads downward thru the eye on the deck (36" aft of the bow), back through the eye at the forward starboard corner of the cabin top, to the cleat starboard of the jib sheet cleat.

Topping lift

Tie a twist pin shackle to the topping lift. The shackle connects to the strap on the pole. The topping lift leads upward to the eye on the mast 10' above the deck, down to the eye on the forward port corner of the cabin top, and back to the cleat to port of the jib sheet cleat.

Self-Tending Jib Boom, V22, V24

Install the boom and hardware as shown on the drawing. Attach 2' of poly line to the jib clew with a bowline and pass the line through the pad eye on the boom end and tie to the cleat. The jib sheet goes through the swivel block on the boom and through the nylon fairleads on the cabin top and then to the jib sheet cleats.

