



CUTAWAY
AND SLIDE HOSE OVER EACH END.



TWIST
SS METALWIRE
TO HOLD IN PLACE.