

# **Interior Furniture & Bulkhead Spray Finish**

## **TEAK CARE**

"TEAK WOOD IS A HIGH QUALITY, EXTREMELY DURABLE WOOD WITH A HIGH OIL" CONTENT. IN ORDER TO HELP YOU PROTECT THE ORIGINAL BEAUTY OF YOUR "TEAK IN YOUR INTERIOR, WE HAVE SEALED THE INTERIOR WITH A (3 TO 4) SPRAY COAT FINISH, USING SEALER & VARNISH FOR MARINE CABINETS, MANUFACTURED BY "CHEMCRAFT INTERNATIONAL INC". THIS MATERIAL WILL SEAL AND PROTECT THE WOOD FROM MOISTURE AND WEATHERING.IT ALSO REDUCES WORK AND MAINTENANCE COST, EASY TO MAINTAIN.

## **REPAIRS**

WHEN WOODWORK IS DAMAGED FROM SCAPES OR ABRASIONS (THAT GO INTO OR THRU THE FINISH)

TAKE THE FOLLOWING STEPS:

- 1) TAKE 320 GRIT SAND PAPER TO SMOOTH OUT ROUGH SPOTS, SANDING WITH THE GRAIN. IF THE SPOT IS DOWN TO THE RAW WOOD, RAG (100% COTTON) WIPE THE SPOT WITH 99% ISOPROPAL ALCOHOL AND ALLOW TO DRY. *(NOTE: ALCOHOL ONLY NEEDS TO BE APPLIED TO THE RAW TEAK.)*
- 2) RESEAL RAW WOOD WITH "MOHAWK" SPRAY SEALER (AREOSOL CAN) AND ALLOW TO DRY.
- 3) LIGHTLY SAND WITH 320 GRIT, SANDING LARGER THAN ORIGINAL SPOT.
- 4) WIPE CLEAN OF DUST AND DIRT OFF WITH A CLEAN DRY RAG.
- 5) USING "MOHAWK" (TOUCH UP AND REPAIR SUPPLIES) USE CLEAR LACQUER SPRAY (AREOSOL CAN). APPLY (1) COAT ON THE SPOT EVENLY AND ALLOW TO DRY.
- 6) THIS PROCESS (STEPS 3 – 5) MAY BE REPEATED AS MANY TIMES AS NEEDED TO BRING DAMAGED AREA BACK UP TO ITS ORIGINAL FINISH.ON YOUR FINAL SPRAYING BE SURE TO FEATHER INTO EXSISTING FINISH.

### **"CHEMCRAFT INTERNATIONAL"**

TELEPHONE: 910-723-1846  
U.S.WATTS 1-800-334-8556

### **"MOHAWK FINISHING PRODUCTS, INC."**

U.S.WATTS 1-800-545-0047