

356 SOP WINDSHIELD TRIM INSTALLATION



#	#Ea.	Description	Size	Part #
1	1	Port ABS Plastic Trim	356	
2	1	Starboard ABS Plastic Trim	356	
3	8	Trim Fasteners	#8 x 3/4" T H Beige	467985

1. Fit the trim to the windshields. Make adjustments by cutting the top edge of the trim at the windshield.
2. The trim will fit flush against the whisper and just off the windshield.
3. Using a 1/8" drill bit, drill four holes in each piece of trim. The port and starboard holes should be centered on each side of the trim and the fwd and aft holes should be 1-1/2" inboard of the whisper seam.
4. Run a bead of black caulk around the windshield at the glass edge then smooth in the caulk.
5. Place trim into position and secure using designated fasteners.

Revision Dates:

Expected Time: 90 min.

Page