


1-2.2 Cooling water passage of engine model 2GM



← When the cooling water is at the correct temperature
 ←... When the cooling water temperature is lower than the correct temperature