

Spring pre-launch	Spring post launch	Mid-Summer	Winterization in-water	Winterization after haul	Item	Time	Notes	Supplies
Uncover	Beneteau Annual	Bilge pump	Anti-siphon	Open seacocks	Windlass	0:45	Disassemble, inspect, clean, grease	Mineral spirits, Lewmar grease, rags
Windlass	Burp shaft seal	Clutches	Water Strainer	Cover	Winches	3:30	Disassemble, inspect, clean, grease	Mineral spirits, Lewmar grease, rags, basin
Winches	Clutches	Water Strainer	Water Separator		Thruster	0:30	Remove/inspect/clean/replace zincs	Sandpaper or new anode, Loctite
Thruster	Bilge pump	Water separator	Engine 100/250/Annual		Volvo shaft Seal	0:45	Inspect; inject grease	Volvo grease, straw
Volvo shaft seal	Engine quarterly	Air conditioner	Water Heater		Engine zinc	0:30	Remove/inspect/clean/replace zinc	Sandpaper or new anode
Engine zinc	Lubricate hatch	Engine quarterly	Air conditioner		Sand bottom	3:30	Sand	Sandpaper, vacuum sander, PPE, drop cloths, extension cord
Sand bottom	Lubricate power jacks	Lubricate hatch	Bilge Pump		Paint bottom	7:00	Paint - 0.8 Gal/coat	PPE, drop cloths, paint stirrer, drill, brushes/rollers/tray, mineral spirits, rags
Paint bottom	Lubricate outhaul	Lubricate power jacks	Engine quarterly		Clean/Wax hull	4:00	Clean and wax	Soap, bucket, sponge, chamois, rags, wax, extension cord, buffer
Clean/Wax hull	Commission water tanks	Lubricate outhaul	Check lights		Steering system	1:00	Inspect, clean, grease, rebed compass	Mineral spirits, grease, rags, butyl tape
Steering system	Install headsail	Check lights	Remove / fold headsail		Engine quarterly	1:00	Check oil, Check for leaks	
Engine quarterly	Install mainsail	Water heater	Remove / fold mainsail		Clean bilge	2:00	Remove floorboards, vacuum, replace	Shop-vac
Clean bilge	Install canvas	Defrost refrigerator	Change oil		Beneteau Annual	4:00	See checklist	See checklist
Check lights	Open propane valve	Inspect rigging	Run AF through engine		Clutches	1:00	Clean and lubricate	Silicone spray
Clean/wax deck/cockpit	Inspect rigging		Remove canvas		Bilge Pump	1:00	Check function; dry sump	
Inspect/clean batteries			Remove impeller		Lubricate hatch	0:30	Clean and lubricate	Silicone spray
Burnish bottom			Winterize fresh water		Lubricate power jacks	0:30	Clean and lubricate	Silicone spray
			Winterize AC		Lubricate outhaul	0:30	Clean and lubricate	Silicone spray
			Winterize toilet		Commission water tanks	9:00	Purge AF; bleach, purge to clean; Most of time isn't dedicated	Bleach
			Defrost / clean / drain refrigerator		Water strainer	0:30	Clean	
			Winterize ice box drain		Water separator	0:30	Drain and inspect fuel	Closable clear container
			Winterize bilge pumps		Air conditioner	1:00	Clean air filter; clean water filter; check condensate pump	
			Winterize shower sump		Check lights	0:30	Verify all lights on	
			Close propane valve		Anti-siphon	0:45	Disassemble, clean, reassemble	
			Inspect rigging		Water heater	0:15	Check relief valve; Check for leaks	
			Change coolant		Clean/wax deck/cockpit	4:00	Clean and wax	Soap, bucket, sponge, chamois, rags, wax, extension cord, buffer
					Remove / fold headsail	0:30		
					Remove / fold mainsail	0:30		
					Change oil	1:00		
					Run AF through engine	0:15		5 gallons EG AF
					Install / Remove canvas	0:20		
					Remove impeller	0:10		
					Winterize Fresh water	2:00	Purge water; Aft tank; front tank	15 gallons PG AF
					Winterize AC	0:45		2 gallons EG AF
					Winterize toilet	0:15		0.5 gallons EG AF
					Defrost refrigerator	0:10		
					Winterize ice box drain	0:10		0.25 gallons PG AF
					Winterize bilge pumps	0:15		1 gallon EG AF
					Winterize shower sump	0:15		0.5 gallons EG AF
					Close / open propane valve	0:05		
					Install headsail	0:20		
					Install mainsail	0:40		
					Cover	3:00		Two 15x19 heavy duty tarps, tie-down line, wood support frame
					Uncover	0:45		
					Burp shaft seal	0:10		
					Inspect rigging	0:45	Especially nuts for mast step blocks	
					Burnish bottom	1:30		400-600 grit Sandpaper, PPE, Water source
					Change coolant	1:30		1.25 gallons Shell Rotella ELC Coolant, funnel, storage jug