

## Fuel Capacity DE38

*Fuel Capacity DE38*

**Note:**

Innage = hight of fuel surface above bottom of the tank  
Ullage = distance between fuel surface and the top of the tank

---

Ullage	Innage	Gallons	Gal/Inch	Left
34	1	1.0	1.0	1.3%
33	2	2.0	1.0	2.6%
32	3	3.0	1.0	3.9%
31	4	4.0	1.0	5.3%
30	5	5.0	1.0	6.6%
29	6	6.1	1.0	8.0%
28	7	7.1	1.1	9.4%
27	8	8.2	1.1	10.8%
26	9	9.3	1.1	12.2%
25	10	10.4	1.1	13.7%
24	11	11.5	1.1	15.1%
23	12	12.6	1.1	16.6%
22	13	13.7	1.1	18.1%
21	14	14.8	1.1	19.6%
20	15	16.0	1.1	21.1%
19	16	17.1	1.2	22.6%

---

18	17	18.3	1.2	24.2%
17	18	19.5	1.2	25.7%
16	19	20.7	1.2	27.3%
15	20	21.9	1.2	28.9%
14	21	23.1	1.2	30.5%
13	22	24.7	1.6	32.6%
12	23	26.8	2.0	35.3%
11	24	29.2	2.4	38.5%
10	25	32.0	2.8	42.3%
9	26	35.3	3.2	46.5%
8	27	38.9	3.6	51.3%
7	28	43.0	4.1	56.7%
6	29	47.4	4.5	62.6%
5	30	52.3	4.9	69.0%
4	31	57.6	5.3	75.9%
3	32	63.2	5.7	83.4%
2	33	69.3	6.1	91.5%
1	34	75.8	6.5	100.0%

---

Table provided by **Carmine Pizzariello**

---