

These parts diagrams are used by our staff in determining the proper parts for your equipment. Please note that the information is current as of the creation date of this document. As time passes prices increase and part numbers may be replaced by other assemblies. For the most current information please visit our website which is able to display some (not all) additional information regarding the parts that you may need. If there is ever any question of what you are looking at do not hesitate to contact us.


This is an active PDF document. Click on the links to be directed to our website for pricing and ordering options.

The listed part information links to our website. You can click and visit for the most current information, pictures, and ordering options. We are a full service dealership and pride ourselves in giving world class support to all customers. If we can assist you in anyway, please call 877-260-3528 and our staff will help guide you.

Thanks for your inquiry.

The parts staff @ Messicks.com


Kubota B4200D ENGINE ACCELERATOR



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
67001-43400	010	ASSY ROD RELEASE		0	No	Add To Cart
67001-43420	020	MATERIAL L		0	No	Add To Cart
02014-50060	030	NUT		27	Yes	Add To Cart
67156-55150	040	GRIP		0	No	Add To Cart
02014-50060	050	NUT		27	Yes	Add To Cart
04013-50060	060	WASHER PLAIN		0	No	Add To Cart
05511-51612	070	PIN SPLIT		12	Yes	Add To Cart
04013-50060	080	WASHER PLAIN		0	No	Add To Cart
05511-51612	090	PIN SPLIT		12	Yes	Add To Cart
66711-43410	100	PEDAL ACCEL.		0	No	Add To Cart
05511-50318	110	PIN SPLIT		18	Yes	Add To Cart
66711-43420	120	RETAINER ACCEL.PEDAL		0	No	Add To Cart
05411-00314	130	PIN SPRING		15	Yes	Add To Cart
66711-43430	140	SPRING ACCEL.PEDAL		0	No	Add To Cart
66404-43430	150	ROD ACCEL.PEDAL		0	No	Add To Cart
04013-50060	160	WASHER PLAIN		0	No	Add To Cart
05511-51612	170	PIN SPLIT		12	Yes	Add To Cart
66704-43340	180	LEVER RELEASE		0	No	Add To Cart
06914-00100	190	GRIP LEVER		2	No	Add To Cart
66704-43320	200	ARM RELEASE		0	No	Add To Cart
66704-43350	210	LEVER ENGINE STOP		0	No	Add To Cart
66704-43360	220	PIN SPRING		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
05511-50320	230	PIN SPLIT		8	Yes	Add To Cart
32210-17190	240	SPRING		0	No	Add To Cart
04011-50100	250	WASHER PLAIN		20	Yes	Add To Cart
04015-50100	260	WASHER PLAIN		0	No	Add To Cart
02116-50100	270	NUT		8	Yes	Add To Cart
67001-54770	280	SPRING ENGINE STOP		0	No	Add To Cart
01023-50612	290	BOLT		14	Yes	Add To Cart
04013-50060	300	WASHER PLAIN		0	No	Add To Cart

Kubota B4200D ENGINE AIR CLEANER




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15372-11010	010	ASSY CLEANER AIR		0	No	Add To Cart
15972-11010	010	ASSY CLEANER AIR		0	No	Add To Cart
15241-11150	020	BODY AIR CLEANER		0	No	Add To Cart
15222-11220	030	ELEMENT AIR CLEANER		0	No	Add To Cart
15221-92620	040	BOLT WING		7	No	Add To Cart
15221-94430	050	WASHER WITH RUBBER		0	Yes	Add To Cart
15221-11410	060	COVER BAFFLE		1	No	Add To Cart
15221-11170	070	GASKET A/C COVER		0	No	Add To Cart
15241-11160	080	COVER AIR CLEANER		1	No	Add To Cart
15241-11350	090	CAP AIR CLEANER		0	No	Add To Cart
15372-87452	100	LABEL AIR CLEANER		0	No	Add To Cart
15972-87450	100	LABEL AIR CLEANER		0	No	Add To Cart
15227-87480	110	LABEL ELEMENT A/C		0	No	Add To Cart
15972-87480	110	LABEL ELEMENT A/C		0	No	Add To Cart
15371-11252	120	BAND AIR CLEANER		2	Yes	Add To Cart
15371-11870	130	CUSHION		1	No	Add To Cart
01222-50830	140	BOLT		0	No	Add To Cart
02114-50080	150	NUT		33	Yes	Add To Cart
04512-50080	160	WASHER SPRING		0	No	Add To Cart
01123-50816	170	BOLT		0	No	Add To Cart
15262-11620	180	PIPE INLET		0	No	Add To Cart
15221-11720	190	BAND PIPE		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-11720	200	BAND PIPE		0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010

Kubota B4200D ENGINE CAMSHAFT




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-15550	010	TAPPET		0	No	Add To Cart
15261-15110	020	PUSH ROD		0	No	Add To Cart
15261-16010	030	ASSY CAMSHAFT		0	No	Add To Cart
15261-16110	040	COMP.CAMSHAFT		0	No	Add To Cart
15261-96880	050	PLUG BLIND		0	No	Add To Cart
15261-16510	060	GEAR CAMSHAFT		0	No	Add To Cart
05712-00515	070	KEY FEATHER		0	Yes	Add To Cart
15261-16270	080	STOPPER CAMSHAFT		0	No	Add To Cart
04612-00180	090	CIR-CLIP EXTERNAL		12	Yes	Add To Cart
01023-50614	100	BOLT		0	No	Add To Cart
15532-24010	110	COMP.GEAR IDLE	<=599855	0	No	Add To Cart
15741-24010	110	COMP.GEAR IDLE	>=599856	0	No	Add To Cart
15532-24980	120	BUSH IDLE GEAR	<=599855	0	No	Add To Cart
15741-24980	120	BUSH IDLE GEAR	>=599856	0	No	Add To Cart
15532-24360	130	COLLAR IDLE GEAR	<=599855	0	No	Add To Cart
15741-24360	130	COLLAR IDLE GEAR	>=599856	0	No	Add To Cart
15532-24370	140	COLLAR IDLE GEAR	<=599855	0	No	Add To Cart
15741-24370	140	COLLAR IDLE GEAR	>=599856	0	No	Add To Cart
15532-24320	150	CIR-CLIP IDLE GEAR	<=599855	0	No	Add To Cart
15741-24320	150	CIR-CLIP IDLE GEAR	>=599856	0	No	Add To Cart
15532-24250	160	SHAFT IDLE GEAR	<=599855	0	No	Add To Cart
15741-24250	160	SHAFT IDLE GEAR	>=599856	0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
01023-50616	170	BOLT		9	Yes	Add To Cart
15532-99340	180	ASSY GEAR IDLE SER/V	<=599855	0	No	Add To Cart
15741-99340	180	ASSY GEAR IDLE	>=599856	0	No	Add To Cart

Parts Hotline : 877-260-3528


As of 11-09-2010

Kubota B4200D ENGINE CRANKCASE




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15951-01010	010	COMP.CRANKCASE		0	No	Add To Cart
15261-96170	020	PLUG		0	No	Add To Cart
15261-96160	030	PLUG		0	No	Add To Cart
15321-96260	040	CAP SEALING		1	No	Add To Cart
15221-03490	050	CAP SEALING		0	No	Add To Cart
15261-96010	060	PLUG		2	No	Add To Cart
15521-96020	070	PLUG		5	No	Add To Cart
15521-96030	080	PLUG		0	No	Add To Cart
05012-00609	090	PIN STRAIGHT		0	No	Add To Cart
05012-00814	100	PIN STRAIGHT		0	No	Add To Cart
15221-33650	110	PIN PIPE		0	No	Add To Cart
15231-33960	120	PIN PIPE		0	No	Add To Cart
15261-72880	130	PIPE WATER		0	No	Add To Cart
15901-02310	140	LINER CYLINDER		0	No	Add To Cart
15221-33700	150	O RING		8	No	Add To Cart
15261-73910	160	COVER WATER		0	No	Add To Cart
15261-73920	170	GASKET WATER COVER		0	No	Add To Cart
01023-50618	180	BOLT		4	Yes	Add To Cart
15531-39010	190	SWITCH OIL		0	Yes	Add To Cart

Kubota B4200D ENGINE CYLINDER HEAD



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15221-01750	010	HOOK ENGINE		0	No	Add To Cart
01513-50816	020	STUD		9	No	Add To Cart
01123-50816	030	BOLT		0	No	Add To Cart
02156-50080	040	NUT		13	Yes	Add To Cart
04512-50080	050	WASHER SPRING		0	No	Add To Cart
15951-03040	060	COMP.CYLINDER HEAD		0	No	Add To Cart
15261-03370	070	CAP SEALING		1	No	Add To Cart
15321-96260	080	CAP SEALING		1	No	Add To Cart
15261-96010	090	PLUG		2	No	Add To Cart
15261-13540	100	GUIDE INLET VALVE		0	No	Add To Cart
15261-13560	110	GUIDE EXHAUST VALVE		0	No	Add To Cart
19215-03450	120	BOLT CYLINDER HEAD		0	No	Add To Cart
19215-03450	120	BOLT CYLINDER HEAD		0	No	Add To Cart
15532-03410	130	STUD CYLINDER HEAD		0	No	Add To Cart
19215-03512	140	NUT CYLINDER HEAD		0	No	Add To Cart
15901-03314	150	GASKET CYLINDER HEAD		0	No	Add To Cart
15901-03320	160	SHIM CYL.HEAD GASKET		0	No	Add To Cart

Kubota B4200D ENGINE CYLINDER HEAD COVER




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15951-05140	010	PLATE ELEMENT		0	No	Add To Cart
15521-05150	020	PLATE ELEMENT		0	No	Add To Cart
15521-05670	030	ELEMENT BREATHER		0	No	Add To Cart
15951-05370	040	OIL SHIELD BREATHER		0	No	Add To Cart
03024-50510	050	SCREW WITH WASHER		5	No	Add To Cart
15521-05550	060	JOINT BREATHER PIPE		0	No	Add To Cart
15261-05510	070	PIPE BREATHER		1	No	Add To Cart
15951-05590	080	CLAMP PIPE		0	No	Add To Cart
15951-14510	090	COVER CYL.HEAD		0	No	Add To Cart
15261-14520	100	GASKET HEAD COVER		0	No	Add To Cart
15951-92330	110	NUT CAP		0	No	Add To Cart
15951-96660	120	GASKET		3	Yes	Add To Cart
15261-66630	130	COVER DECOMP.OPENING		0	No	Add To Cart
15261-66640	140	GASKET DECOMP.OPEN.		0	No	Add To Cart
01023-50614	150	BOLT		0	No	Add To Cart
15221-33140	160	PLUG OIL FILLER		0	No	Add To Cart
04811-50300	170	RING		0	Yes	Add To Cart
15951-66040	180	COMP.SHAFT DECOMP.		0	No	Add To Cart
15261-66350	190	BOLT DECOMPRESS		0	No	Add To Cart
02056-50050	200	NUT		0	No	Add To Cart
04811-00080	210	RING		15	No	Add To Cart
15261-66190	220	HOLDER DECOMP.WIRE		0	No	Add To Cart


Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
01023-50614	230	BOLT		0	No	Add To Cart
15221-66280	240	SPRING DECOMPRESS		0	No	Add To Cart
15221-66410	250	BOLT		0	No	Add To Cart
04512-50060	260	WASHER SPRING		0	No	Add To Cart

Parts Hotline : 877-260-3528


As of 11-09-2010




020 15261-1236-0



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15262-12310	010	MANIFOLD EXHAUST		0	No	Add To Cart
15261-12360	020	GASKET EX-MANIFOLD	<=532175	0	No	Add To Cart
15272-12360	020	GASKET EX-MANIFOLD	>=532176	0	No	Add To Cart
15381-91532	030	STUD		0	No	Add To Cart
02056-50060	040	NUT		16	Yes	Add To Cart
04512-50060	050	WASHER SPRING		0	No	Add To Cart
01513-50822	060	STUD		7	Yes	Add To Cart




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-25010	010	COMP.FLYWHEEL	<=507063	0	No	Add To Cart
15261-25012	010	COMP.FLYWHEEL	>=507064	0	No	Add To Cart
15261-63820	020	GEAR RING		0	No	Add To Cart
15261-25160	030	BOLT FLYWHEEL		0	No	Add To Cart
15261-25170	040	WASHER FLYWHEEL		0	No	Add To Cart
15261-04620	050	PLATE REAR END		0	No	Add To Cart
05012-00814	060	PIN STRAIGHT		0	No	Add To Cart
15261-91190	070	BOLT		0	No	Add To Cart



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15263-42010	010	ASSY PIPE FUEL		0	No	Add To Cart
14301-42750	020	CLIP PIPE		0	No	Add To Cart
66591-54250	030	SPRING PIPE PROTECT.		0	No	Add To Cart
14111-42410	040	JOINT		0	No	Add To Cart
15381-52030	050	ASSY PUMP FUEL		0	No	Add To Cart
15381-52040	060	COMP.DIAPHRAGM		0	No	Add To Cart
15241-52140	070	GASKET FUEL PUMP		0	No	Add To Cart
01513-50616	080	STUD		0	No	Add To Cart
02056-50060	090	NUT		16	Yes	Add To Cart
04512-50060	100	WASHER SPRING		0	No	Add To Cart

Kubota B4200D ENGINE GEAR CASE




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15381-04020	010	COMP.CASE GEAR		0	No	Add To Cart
15261-96020	020	PLUG		0	No	Add To Cart
04811-06130	030	RING		4	Yes	Add To Cart
15221-56280	040	PIN START SPRING		0	No	Add To Cart
15261-04132	050	GASKET GEAR CASE		0	No	Add To Cart
01023-50630	060	BOLT		0	Yes	Add To Cart
01023-50660	070	BOLT		0	No	Add To Cart
01023-50665	080	BOLT		3	Yes	Add To Cart
01023-50670	090	BOLT		0	No	Add To Cart
01023-50675	100	BOLT		0	No	Add To Cart
15241-32290	110	JOINT PIPE		0	No	Add To Cart
09550-00008	120	SEAL OIL		3	Yes	Add To Cart
15261-35010	130	ASSY PUMP OIL		0	No	Add To Cart
15261-35150	140	GASKET OIL PUMP		0	No	Add To Cart
15261-91022	150	BOLT		0	No	Add To Cart
15954-35660	160	GEAR OIL PUMP DRIVE		0	No	Add To Cart
05712-00410	170	KEY FEATHER		0	Yes	Add To Cart
02016-50100	180	NUT		0	No	Add To Cart
04211-50100	190	WASHER WITH CLAW		0	No	Add To Cart
15223-83340	200	COVER		0	No	Add To Cart
15221-88130	210	GASKET H/METER UNIT		0	No	Add To Cart
15221-88210	220	STUD		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
02056-50060	230	NUT		16	Yes	Add To Cart
04512-50060	240	WASHER SPRING		0	No	Add To Cart
15241-32090	250	CARTRIDGE OIL FILTER		0	Yes	Add To Cart
15261-36070	260	ASSY VALVE RELIEF		0	No	Add To Cart
04810-00150	270	RING		3	Yes	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010

Kubota B4200D ENGINE GOVERNOR




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15221-56480	010	SPRING START		0	No	Add To Cart
15381-56410	020	SPRING GOVERNOR		0	No	Add To Cart
15261-56020	030	COMP.LEVER GOVERNOR		0	No	Add To Cart
15381-56050	040	ASSY LEVER FORK		0	No	Add To Cart
15381-56040	050	COMP.LEVER FORK		0	No	Add To Cart
15261-56130	060	LEVER FORK		0	No	Add To Cart
15261-56150	070	SHAFT FORK LEVER		0	No	Add To Cart
01053-50516	080	BOLT		6	Yes	Add To Cart
04512-50050	090	WASHER SPRING		0	No	Add To Cart
15261-56230	100	HOLDER FORK LEVER		0	No	Add To Cart
15261-66410	110	BOLT		0	No	Add To Cart
01023-50628	120	BOLT		0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010


Kubota B4200D ENGINE HYDRAULIC GEAR PUMP



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
67211-76100	010	ASSY PUMP GEAR		0	No	Add To Cart
01123-50822	020	BOLT		13	Yes	Add To Cart
01513-50822	030	STUD		7	Yes	Add To Cart
04512-50080	040	WASHER SPRING		0	No	Add To Cart
02156-50080	050	NUT		13	Yes	Add To Cart
15231-87130	060	GASKET HYD.PUMP		0	No	Add To Cart


Parts Hotline : 877-260-3528

As of 11-09-2010



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
67211-76100	010	ASSY PUMP GEAR		0	No	Add To Cart
67211-76120	020	COVER		0	No	Add To Cart
04810-00220	030	RING		10	No	Add To Cart
04810-00050	040	RING		5	Yes	Add To Cart
04810-50500	050	RING		6	No	Add To Cart
67211-76240	060	BOLT		0	No	Add To Cart
04512-50080	070	WASHER SPRING		0	No	Add To Cart
31381-76190	080	SEAL OIL		1	No	Add To Cart
04611-00280	090	CIR-CLIP INTERNAL		6	Yes	Add To Cart

Kubota B4200D ENGINE INJECTION PUMP




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-51010	010	ASSY PUMP INJECTION		0	No	Add To Cart
15221-52110	020	SHIM INJECTION PUMP		0	No	Add To Cart
15261-52110	020	SHIM INJECTION PUMP		0	No	Add To Cart
01123-50822	030	BOLT		13	Yes	Add To Cart
15221-91530	040	STUD		7	No	Add To Cart
02156-50080	050	NUT		13	Yes	Add To Cart
04512-50080	060	WASHER SPRING		0	No	Add To Cart
15262-16020	070	ASSY CAMSHAFT FUEL		0	No	Add To Cart
15262-16170	080	CAMSHAFT FUEL		0	No	Add To Cart
08153-06004	090	BEARING BALL		0	No	Add To Cart
15261-51150	100	GEAR INJECTION PUMP		0	No	Add To Cart
05712-00520	110	KEY FEATHER		0	No	Add To Cart
15261-55450	120	SLEEVE GOVERNOR		0	No	Add To Cart
15261-55470	130	CIR-CLIP GOV.SLEEVE		0	No	Add To Cart
15261-55690	140	CASE GOVERNOR BALL		0	No	Add To Cart
07715-03205	150	BALL		0	No	Add To Cart
15261-55740	160	CIR-CLIP		0	No	Add To Cart
07715-03217	170	BALL		0	No	Add To Cart
04612-00180	180	CIR-CLIP EXTERNAL		12	Yes	Add To Cart
08103-06004	190	BEARING BALL		0	No	Add To Cart
04612-00200	200	CIR-CLIP EXTERNAL		17	Yes	Add To Cart
15261-16320	210	STOPPER		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
01023-50612	220	BOLT		14	Yes	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010

INJECTION PUMP (COMPONENT PARTS)


Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-51010	010	ASSY PUMP INJECTION		0	No	Add To Cart
15261-51050	020	PLUNGER PUMP		0	No	Add To Cart
15261-51030	030	VALVE DELIVERY		0	No	Add To Cart
15331-51230	040	SPRING DELIV.VALVE		0	No	Add To Cart
15331-51240	050	GASKET DELIV.VALVE		3	Yes	Add To Cart
15331-51220	060	HOLDER DELIV.VALVE		0	No	Add To Cart
15331-96760	070	O RING		0	No	Add To Cart
15331-51070	080	ASSY TAPPET		0	No	Add To Cart
15331-51250	090	PIN TAPPET GUIDE		0	No	Add To Cart
15331-51430	100	PIN CLAMP		0	No	Add To Cart
17331-51280	110	SPRING PLUNGER		0	No	Add To Cart
15331-51270	120	SEAT SPRING UPPER		0	No	Add To Cart
15331-51290	130	SEAT SPRING LOWER		0	No	Add To Cart
15261-51490	140	SHIM		0	No	Add To Cart
15241-51060	150	RACK CONTROL		0	No	Add To Cart
15331-51380	160	SLEEVE CONTROL		0	No	Add To Cart
15241-51320	170	SCREW HOLLOW		0	No	Add To Cart
15331-96650	180	GASKET		0	No	Add To Cart
14107-51352	190	SCREW		0	No	Add To Cart
14111-53380	200	GASKET		0	No	Add To Cart
15331-51480	210	COLLAR		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
04512-50060	220	WASHER SPRING		0	No	Add To Cart
15241-51390	230	PLATE ADJUSTING		0	No	Add To Cart
15331-91010	240	BOLT		0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010


Kubota B4200D ENGINE INLET MANIFOLD




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15262-11760	010	MANIFOLD INLET		0	No	Add To Cart
15261-11820	020	GASKET		0	No	Add To Cart
15261-11830	030	GASKET		0	No	Add To Cart
01023-50620	040	BOLT		12	Yes	Add To Cart
01053-50650	050	BOLT		0	No	Add To Cart
04512-50060	060	WASHER SPRING		0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010


Kubota B4200D ENGINE
MAIN BEARING CASE

020 15261-0454-0
030 15261-0457-0
110 15261-0456-0
120 15261-0459-0



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-04090	010	ASSY CASE MAIN BRG.		0	No	Add To Cart
15261-04540	020	BOLT BEARING CASE	<=596387	0	No	Add To Cart
15381-04540	020	BOLT BEARING CASE	>=596388	0	No	Add To Cart
15261-04570	030	WASHER BEARING CASE	<=596387	0	No	Add To Cart
15261-04360	040	GASKET BRG.CASE		0	No	Add To Cart
15549-04810	050	COVER BEARING CASE		0	No	Add To Cart
15261-04820	060	GASKET BRG.CASE COV.		0	No	Add To Cart
01023-50620	070	BOLT		12	Yes	Add To Cart
01023-50625	080	BOLT		0	No	Add To Cart
19215-04460	090	SEAL OIL		2	No	Add To Cart
15261-04040	100	ASSY CASE MAIN BRG.		0	No	Add To Cart
15261-04560	110	BOLT BEARING CASE	<=596387	0	No	Add To Cart
15381-04560	110	BOLT BEARING CASE	>=596388	0	No	Add To Cart
15261-04590	120	WASHER BEARING CASE	<=596387	0	No	Add To Cart

Kubota B4200D ENGINE MUFFLER




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
66811-54510	010	COVER MUFFLER		0	No	Add To Cart
01202-50612	020	BOLT		17	Yes	Add To Cart
04013-50060	030	WASHER PLAIN		0	No	Add To Cart
66711-54530	040	STAY MUFFLER		0	No	Add To Cart
01123-50814	050	BOLT		0	No	Add To Cart
01123-50818	060	BOLT		20	Yes	Add To Cart
04013-50080	070	WASHER PLAIN		0	No	Add To Cart
67001-54510	080	PIPE MUFFLER		0	No	Add To Cart
67800-53420	090	BAND PIPE		0	No	Add To Cart
01153-50865	100	BOLT		3	No	Add To Cart
04013-50080	110	WASHER PLAIN		0	No	Add To Cart
04512-50080	120	WASHER SPRING		0	No	Add To Cart
02114-50080	130	NUT		33	Yes	Add To Cart
66711-54550	140	COVER MUFFLER FLANGE		1	No	Add To Cart
66711-54560	150	COVER MUFFLER FLANGE		1	No	Add To Cart
01053-50628	160	BOLT		1	Yes	Add To Cart
04512-50060	170	WASHER SPRING		0	No	Add To Cart
02014-50060	180	NUT		27	Yes	Add To Cart
66811-54560	190	PLATE SHUTTER	<=51365	0	No	Add To Cart
66811-54565	190	PLATE SHUTTER	>=51366	0	No	Add To Cart
66711-54620	200	TAPE SOFT		2	No	Add To Cart
01123-50818	210	BOLT		20	Yes	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
04013-50080	220	WASHER PLAIN		0	No	Add To Cart
15262-12110	230	MUFFLER		0	Yes	Add To Cart
66496-54510	230	MUFFLER		0	No	Add To Cart
15263-12370	240	GASKET MUFFLER		2	Yes	Add To Cart
02114-50080	250	NUT		33	Yes	Add To Cart
04512-50080	260	WASHER SPRING		0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010


NOZZLE HOLDER (COMPONENT PARTS)

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-53020	010	ASSY HOLDER NOZZLE	<=585583	0	No	Add To Cart
15271-53020	010	ASSY HOLDER NOZZLE	<=585582	0	No	Add To Cart
15271-53000	015	ASSY HOLDER NOZZLE	<=585582	0	No	Add To Cart
15221-92020	020	NUT		0	No	Add To Cart
15221-94020	030	WASHER PLAIN		0	No	Add To Cart
15221-53170	040	SPRING NOZZLE		0	No	Add To Cart
15221-53350	050	PIECE DISTANCE		0	No	Add To Cart
15221-53160	060	PUSH ROD		0	No	Add To Cart
15221-53280	070	NUT NOZZLE		0	No	Add To Cart
15021-53610	080	PIECE NOZZLE		0	No	Add To Cart
15221-98110	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98120	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98130	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98140	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98150	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98160	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98170	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98180	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98190	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98200	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98210	090	WASHER ADJUSTING		0	No	Add To Cart


Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15221-98220	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98230	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98240	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98250	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98260	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98270	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98280	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98290	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98300	090	WASHER ADJUSTING		0	No	Add To Cart
15221-98100	100	ASSY WASHER		0	No	Add To Cart
15221-95680	110	JOINT	< =585582	0	No	Add To Cart
15221-95690	120	JOINT	< =585582	0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010




010 15261-4250-0
 020 15261-4251-0
 030 14971-4275-0
 070 15271-5300-0
 080 15271-5302-0




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-42500	010	ASSY PIPE OVER FLOW	<=585582	0	No	Add To Cart
15262-42502	010	ASSY PIPE OVER FLOW	>=585583	0	No	Add To Cart
15261-42510	020	PIPE FUEL OVER FLOW	<=585582	0	No	Add To Cart
14971-42750	030	CLIP PIPE	<=585582	4	No	Add To Cart
15241-51650	040	COVER INJECTION PUMP		0	No	Add To Cart
15231-05130	050	GASKET BREATHER		0	No	Add To Cart
01023-50614	060	BOLT		0	No	Add To Cart
15271-53000	070	ASSY HOLDER NOZZLE	<=585582	0	No	Add To Cart
15261-53020	080	ASSY HOLDER NOZZLE	>=585583	0	No	Add To Cart
15271-53020	080	ASSY HOLDER NOZZLE	<=585582	0	No	Add To Cart
17011-53620	090	GASKET		21	Yes	Add To Cart
15261-53710	100	PIPE INJECTION		0	No	Add To Cart
15261-53720	110	PIPE INJECTION		0	No	Add To Cart
15841-53850	120	CLAMP PIPE		3	Yes	Add To Cart
15841-53860	130	CLAMP PIPE		3	Yes	Add To Cart
03024-50520	140	SCREW WITH WASHER		7	Yes	Add To Cart
15951-65510	150	PLUG GLOW		0	No	Add To Cart
15261-65560	160	CORD GLOW PLUG		0	No	Add To Cart

Kubota B4200D ENGINE OIL PAN



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15262-01610	010	OIL PAN		0	No	Add To Cart
15261-01620	020	GASKET OIL PAN		0	No	Add To Cart
15381-91092	030	BOLT		0	No	Add To Cart
15221-33750	040	PLUG		1	No	Add To Cart
15109-33660	050	GASKET		0	No	Add To Cart
15262-32110	060	FILTER OIL		0	No	Add To Cart
01123-50816	070	BOLT		0	No	Add To Cart
04811-00140	080	RING		0	Yes	Add To Cart
15261-36410	090	GAUGE OIL		0	No	Add To Cart
15262-36420	100	GUIDE OIL GAUGE		0	No	Add To Cart
15261-36430	110	GASKET OIL GAUGE		0	No	Add To Cart
01023-50618	120	BOLT		4	Yes	Add To Cart
15262-36440	130	SUPPORT OIL GAUGE		0	No	Add To Cart
01153-50820	140	BOLT		4	Yes	Add To Cart
02114-50080	150	NUT		33	Yes	Add To Cart
04013-50080	160	WASHER PLAIN		0	No	Add To Cart

Kubota B4200D ENGINE PISTON/CRANKSHAFT




Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15956-21110	010	PISTON		0	No	Add To Cart
15956-21910	010	PISTON		0	No	Add To Cart
15901-21050	020	ASSY PISTON RING		0	No	Add To Cart
15901-21090	020	ASSY PISTON RING		0	No	Add To Cart
15261-21310	030	PIN PISTON		0	No	Add To Cart
15261-21330	040	CIR-CLIP PISTON PIN		0	No	Add To Cart
15381-22010	050	ASSY CONNECTION ROD	>=599856	0	No	Add To Cart
15531-22010	050	ASSY CONNECTING ROD	<=599855	0	No	Add To Cart
15694-22010	050	ASSY CONNECTION ROD	>=751430	2	No	Add To Cart
15261-21980	060	BUSH PISTON PIN		0	No	Add To Cart
15261-22140	070	BOLT CONNECTING ROD	<=599855	0	No	Add To Cart
15381-22140	070	BOLT CONNECTING ROD	>=599856	0	No	Add To Cart
15531-22310	080	METAL CRANKPIN	<=751429	0	No	Add To Cart
15531-22970	080	METAL CRANKPIN	<=751429	0	No	Add To Cart
15531-22980	080	METAL CRANKPIN	<=751429	0	No	Add To Cart
15694-22310	080	METAL CRANKPIN	>=751430	3	No	Add To Cart
15694-22970	080	METAL CRANKPIN	>=751430	0	No	Add To Cart
15694-22980	080	METAL CRANKPIN	>=751430	0	No	Add To Cart
15263-23010	090	COMP.CRANKSHAFT	<=599855	0	No	Add To Cart
15263-23012	090	COMP.CRANKSHAFT	>=599856	0	No	Add To Cart
15131-01380	100	PLUG PIN		0	No	Add To Cart
09400-14247	110	SEAL OIL		2	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
66621-14120	120	BEARING DRY		3	Yes	Add To Cart
19215-23280	130	SLEEVE CRANKSHAFT		0	No	Add To Cart
15261-24110	140	GEAR CRANKSHAFT		0	No	Add To Cart
05712-00515	150	KEY FEATHER		0	Yes	Add To Cart
15261-23310	160	SLINGER OIL		0	No	Add To Cart
15532-23250	170	COLLAR CRANKSHAFT		0	No	Add To Cart
04811-10220	180	RING		5	Yes	Add To Cart
15261-23470	190	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15261-23910	190	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15261-23920	190	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15694-23470	190	METAL CRANKSHAFT	>=751430	0	No	Add To Cart
15694-23910	190	METAL CRANKSHAFT	>=751430	0	No	Add To Cart
15694-23920	190	METAL CRANKSHAFT	>=751430	0	No	Add To Cart
15261-23480	200	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15261-23930	200	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15261-23940	200	METAL CRANKSHAFT	<=751429	0	No	Add To Cart
15694-23480	200	METAL CRANKSHAFT	>=751430	3	No	Add To Cart
15694-23930	200	METAL CRANKSHAFT	>=751430	0	No	Add To Cart
15694-23940	200	METAL CRANKSHAFT	>=751430	0	No	Add To Cart
15261-23530	210	METAL SIDE		2	Yes	Add To Cart
15261-23950	210	METAL SIDE		0	No	Add To Cart
15261-23960	210	METAL SIDE		0	No	Add To Cart
15261-23540	220	METAL SIDE		0	No	Add To Cart
15261-23970	220	METAL SIDE		0	No	Add To Cart
15261-23980	220	METAL SIDE		0	No	Add To Cart

Parts Hotline : 877-260-3528


As of 11-09-2010

Kubota B4200D ENGINE SPEED CONTROL PLATE



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15261-54090	010	ASSY APPARATUS I/D.		0	No	Add To Cart
15261-54100	020	ASSY BOLT ADJUSTING		0	No	Add To Cart
15261-92020	030	NUT		0	No	Add To Cart
15261-92330	040	NUT CAP		0	No	Add To Cart
15021-33660	050	GASKET		6	No	Add To Cart
15261-54270	060	CAP		0	No	Add To Cart
15381-54020	070	APPARATUS FUEL LIMIT		0	No	Add To Cart
15381-54030	080	APPARATUS FUEL LIMIT		0	No	Add To Cart
15261-54370	090	NUT LOCK		0	No	Add To Cart
15109-33660	100	GASKET		0	No	Add To Cart
15261-54220	110	NUT CAP		0	No	Add To Cart
14301-54420	120	CAP		0	No	Add To Cart
15371-57150	130	LEVER SPEED CONTROL		0	No	Add To Cart
15261-95010	140	KEY FEATHER		0	No	Add To Cart
04811-00070	150	RING		8	No	Add To Cart
04013-50060	160	WASHER PLAIN		0	No	Add To Cart
02012-50060	170	NUT		0	No	Add To Cart
15261-57380	180	DISK FRICTION		0	No	Add To Cart
15261-57110	190	PLATE SPEED CONTROL		0	No	Add To Cart
15261-57210	200	GASKET		0	No	Add To Cart
01023-50620	210	BOLT		12	Yes	Add To Cart

Kubota B4200D ENGINE VALVE/ROCKER ARM



Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
15393-13110	010	VALVE INLET		0	No	Add To Cart
15393-13120	020	VALVE EXHAUST		0	No	Add To Cart
15261-13240	030	SPRING VALVE		0	No	Add To Cart
15261-13330	040	RETAINER VALVE SP.	<=536567	0	No	Add To Cart
16241-13330	040	RETAINER VALVE SP.	>=536568	0	No	Add To Cart
15261-13360	050	COLLET VALVE SPRING		0	No	Add To Cart
15261-13150	060	SEAL VALVE STEM		6	No	Add To Cart
15261-13280	070	CAP VALVE		0	No	Add To Cart
15901-14053	080	ASSY SHAFT R-ARM		0	No	Add To Cart
15381-93610	090	SCREW SET		0	No	Add To Cart
15381-14350	100	BRACKET ROCKER ARM		0	No	Add To Cart
15952-14410	110	STUD		0	No	Add To Cart
15261-92010	120	NUT		0	No	Add To Cart
15261-94010	130	WASHER PLAIN		0	No	Add To Cart
15261-14420	140	SCREW SET		0	No	Add To Cart
15261-14430	150	WASHER		0	No	Add To Cart
15261-14310	160	SPRING ROCKER ARM		0	No	Add To Cart
04612-00110	170	CIR-CLIP EXTERNAL		0	No	Add To Cart
15381-14030	180	ASSY ROCKER ARM	>=581057	0	No	Add To Cart
19264-14030	180	ASSY ROCKER ARM	<=581056	0	No	Add To Cart
15261-14232	190	SCREW ADJUSTING		0	No	Add To Cart
15261-14240	200	NUT		0	No	Add To Cart

Part Number	Position	Description	Serial Break	Stock	Picture?	Cart
19264-14180	210	BUSH ROCKER ARM	<=581056	0	No	Add To Cart

Parts Hotline : 877-260-3528

As of 11-09-2010