



HUNTER 216 RUDDER POD REMOVAL^{L-4-3-06}

Procedure:

1. Remove the 4 self-tapping screws from tiller and remove tiller and the 2 eye straps holding the bungee cord. (this will keep it flat when you turn it upside down)



2. Remove rudder pod assembly from boat by unscrewing the 6-#10 x 2" pan head screws around the circumference of the pod, break loose the sealant, put your hand in the rudder blade slot and lift straight up.