


Typical SeaTalk Cabling



5.3 NMEA Interface

ST7000 Plus accepts NMEA navigation data for display and use in Track and Wind modes. The required NMEA data formats are shown in the table at the end of this section.

Cabling

The NMEA port should be connected to a Navigator or Wind instrument.