


## **FOREWORD**

Thank you for selecting a Westerbeke marine product for your use. We at Westerbeke are pleased to have you as a customer.

Read this manual carefully and observe all safety precautions included throughout. Operating procedures, periodic preventive maintenance procedures, installation checks, system descriptions and minor adjustment procedures are included herein so you can operate your equipment safely and properly, maintain the equipment at a high level of efficiency, and expect dependable performance and long service life in return.

Should your unit require special attention, contact your Westerbeke dealer for assistance. The Westerbeke Service Organization is trained to provide the support necessary to ensure long-term dependable performance.

<b>from:</b>	WESTERBEKE CORPORATION AVON INDUSTRIAL PARK AVON, MA 02322
<b>Mail To:</b>	<div><b>WESTERBEKE</b> <small>AVON INDUSTRIAL PARK, AVON, MA 02322 - TEL: (617) 540-7700 TELEX: 52-6666 - FAX: (617) 540-9323 - CABLE: WESTCON</small></div> <b>CUSTOMER IDENTIFICATION</b> Adam Smith 85 Maple Street Alden, IN 12234 Model W 12 TWO      Ser. # 1234C786 Expires 7/7/88

## **Inspection of Equipment**

The engine is shipped from the factory mounted securely and properly crated. Accessory equipment is shipped in a separate small box, usually packed within the engine's crate.

Before accepting shipment of the engine from the transportation company, the crate should be opened and the contents inspected for concealed damage. If either visible or concealed damage is noted, you should require that the delivery agent sign "Received in damaged condition" on the proper delivery receipt. Also check the contents of the shipment against the packing list and make sure that the proper notation is made if any discrepancies exist. These noted discrepancies are your protection against loss or damage. Claims concerning loss or damage *must* be made to the *carrier*, not to Westerbeke Corporation.