
= brown = braun
= red = rot
= green = grün
= black = schwarz
= blue = blau
= yellow = gelb
= white = weiss
WATER TEMP. GAUGE
13
15 TACHOMETER
17
OIL PRESSURE GAUGE
2 ACOUSTIC ALARM
FUSES FOR START / TEMP. GAU
19
W/L ELECTRICAL CHAR 4
W/L OIL PRESSURE 3
W/L WATER TEMP. 5
1 KEY SWITCH
STOP SOLENOID
9
CHARGING ALTERNATO
7
B+
61+
D-
1.5 mm² grøn
18
OIL PRESSURE TRANSMITTER
1.5 mm² brun
1.5 mm² rød
1.5 mm² grøn
1.5 mm² sort
1.5 mm² blå
1.5 mm² gul
1.5 mm² sort
1.5 mm² brun
1.5 mm² sort
1.5 mm² rød
2.5 mm² hvid
2.5 mm² blå
2.5 mm² gul
1.5 mm² grøn
1.5 mm² gul/grøn
Rød
Blå
14
WATER TEMP. TRANSMITTER
TACHOMETER TRANSMITTER
16
1.5 mm² gul
1.5 mm² blå
1.5 mm² gul/grøn
1.5 mm² sort
2.5 mm² gul
1.5 mm² grøn
2.5 mm² hvid
2.5 mm² blå
50 mm²
1.5 mm² rød
1.5 mm² brun
8 STARTER
10 MAIN SWITCH
6 SWITCH FOR OIL PRESSURE
12
THERMOSTAT
0,6 - 1,3 mm
6 mm²
BATTERY
11
FIND & CHECK FUSES
FIND RED & BLUE JUNCTION BOXES
Her kan forlængerkabel 008E 2292 indskydes